


# Volute Dewatering Press Model ES131 Operation and Maintenance Manual for

## Concannon Winery Project Arroyo Grande, CA



PROCESS WASTEWATER TECHNOLOGIES LLC

Process Wastewater Technologies, LLC.

9004 Yellow Brick Road, Suite D, Rosedale, MD 21237

Phone: 410-238-7977, Fax: 410-238-7559

## **Project and Main Components Information**

Section 1: Volute Dewatering Press O&M

Section 2: Physical Drawings

Section 3: Main Electrical Components

- Control Panel Data Sheet
- Electrical Drawings
- Altivar Adjustable Speed Drives
- ASCO Solenoid Valve
- GTR Drum & Mixing Tank Gearmotor
- Programmable Logic Controller
- Ametek Level Sensor

Section 4: Polymer Preparation System



## Project Data and Main Component Information

### PROJECT DATA

The following information regarding this project should be referenced when contacting PWT about replacement parts.

<b>Project name:</b>	Concannon Winery Project
<b>Project address:</b>	Cloacina Package Treatment Solutions 2385 Precision Drive Arroyo Grande, CA 93420
<b>Customer:</b>	Fluid Resource Management 2385 Precision Drive Arroyo Grande, CA 93420
<b>Customer PO number:</b>	CL16-005-003
<b>Customer PO date:</b>	21 November 2016
<b>PWT Project number:</b>	VDPCA16116
<b>Local Sales Representative:</b>	JBI Water - Brent Cromar
<b>PWT Supply:</b>	One (1) PWT Volute Dewatering Press Model ES 131 unit w/2 foot taller skid One (1) Velodyne Polymer Preparation System One (1) Control system for the above



## MAIN COMPONENTS AND CONTACT INFORMATION

The following are the main components supplied on this project along with the project specific data for this system and the contacts for supplying parts and equipment for this system. While PWT may be contacted for any parts supplied, particularly following the expiration of the warranty period, contacting the manufacturer directly may expedite the supply of parts.

<b>Component:</b>	Volute Dewatering System
<b>Manufacturer:</b>	Process Wastewater Technologies LLC (PWTech)
<b>Model Designation:</b>	ES131
<b>Serial Number:</b>	D13104A123
<b>Job Number:</b>	VDPCA16116
<b>O&amp;M Manual location:</b>	TAB 1, TAB 2, TAB 3
<b>Contact name:</b>	Bill Love
<b>Phone:</b>	410 238 7977
<b>Fax:</b>	410 238 7559
<b>Email:</b>	volute@PWTech.us
<b>Address:</b>	9004 Yellow Brick Road, Suite D Rosedale, MD 21237
<b>Website:</b>	www.pwtech.us




<b>Component:</b>	Control Panel
<b>Manufacturer:</b>	Control Interface Inc.
<b>Job Number:</b>	J-978
<b>O&amp;M Manual location:</b>	TAB 3
<b>Phone:</b>	888 874 2062
<b>Email:</b>	engineering@controlinterface.com
<b>Address:</b>	4835 Business Center Way, Cincinnati, OH 45246
<b>Website:</b>	www.controlinterface.com

<b>Component:</b>	Liquid Polymer Preparation System
<b>Manufacturer:</b>	Velocity Dynamics, Inc. (Velodyne)
<b>Model Designation:</b>	VMN-0.5D-120-X0D-O-A-X
<b>Serial Number:</b>	1216-3461-2161
<b>Sales Order Number:</b>	3461
<b>O&amp;M Manual location:</b>	TAB 4
<b>Phone:</b>	303 530 3298
<b>Email:</b>	bdunkerson@polymersolution.com
<b>Address:</b>	543 S. Pierce Ave. Louisville, CO 80027
<b>Website:</b>	www.polymersolution.com

## Tab 1: Volute Dewatering Press O&M

# Volute Dewatering Press



## Operation and Maintenance Manual





**Revision:** B  
**Date:** July 2014  
**For Models** ES Series – ES101 - 353

**Process Wastewater Technologies, LLC.**  
**9004 Yellow Brick Road, Suite D, Baltimore, MD 21237**  
**Phone: 410 238 7977, Fax: 410 238 7559,**  
**Email: [volute@PWTech.us](mailto:volute@PWTech.us)**



**This Manual is for the day to day operation of the PWTech Volute Dewatering press – ES Series from model ES101-353.**

**It does not contain information on Design, Installation, Overhaul procedures, or other system component information. These items are covered in separate documents.**

# Contents

<b>1.</b>	<b>Introduction .....</b>	<b>1</b>
1.1.	Process Wastewater Technologies, LLC .....	1
1.2.	The Volute Dewatering Press .....	1
1.3.	Use of this manual .....	1
1.4.	Exclusions From This Manual .....	2
1.5.	Velodyne Polymer system instructions .....	2
1.6.	Additional information .....	2
<b>2.</b>	<b>Health and Safety .....</b>	<b>3</b>
2.1.	Warnings 3	
2.2.	Introduction .....	3
2.3.	Health and Safety during Operation and Maintenance .....	4
2.4.	General Warnings .....	5
<b>3.</b>	<b>Volute Dewatering Press Main Components .....</b>	<b>7</b>
<b>4.</b>	<b>General Operation Description .....</b>	<b>12</b>
4.1.	Introduction .....	12
4.2.	Main Process Functions .....	12
4.3.	Polymer Feed System .....	12
4.4.	Flash-Mixing and Flocculation Tank .....	12
4.5.	Dewatering Drums .....	13
4.6.	Electrical Control Panel .....	13
<b>5.</b>	<b>Operating the Volute Dewatering Press .....</b>	<b>14</b>
5.1.	External Panel Controls .....	14
5.2.	Pre-Operation Checks .....	15
5.3.	Starting the unit up .....	15
5.4.	E-Stop Button .....	15
5.5.	System H-O-A Switch and modes of operation .....	16
5.6.	Time Clock Operation .....	16
5.7.	Conditions for operation in Auto mode .....	16
5.8.	Unit Shutdown and Clean-up .....	17
<b>6.</b>	<b>PLC and HMI Operating Instructions .....</b>	<b>18</b>
6.1.	General PLC operating instructions .....	18
6.2.	Navigating around the PLC .....	19
6.3.	Basic Operating Screens .....	20
6.4.	Overview Display .....	20

6.5. Control Screens .....	22
6.6. Equipment VFD Device Screens .....	28
6.7. Admin Screens .....	29
<b>7. Adjustments and Optimization.....</b>	<b>2</b>
7.1. Sludge Feed Rate.....	2
7.2. Dewatering Drum Speed .....	2
7.3. Polymer Feed Rate.....	3
7.4. Flash-mixer and flocculation tank mixer speed .....	4
7.5. End Plate Gap .....	5
7.6. Spray Valve Timer Settings .....	5
7.7. Other Timer Settings.....	5
7.8. Polymer Dilution Water Flow rate .....	6
7.9. Polymer System: VeloBlend Mixing Chamber .....	6
<b>8. Inspection &amp; Maintenance Schedule .....</b>	<b>7</b>
8.1. Introduction .....	7
8.2. Cake discharge inspection.....	7
8.3. Flocculation tank high-level probe.....	7
8.4. Unit performance .....	7
8.5. End-plate settings .....	8
8.6. High and low-level probe operation inspection.....	8
8.7. Drive motors .....	8
8.8. Tank mixers .....	8
8.9. Polymer preparation system .....	8
8.10. Lubrication Schedule .....	9
8.11. Maintenance Schedule .....	9
8.12. Inspection & Maintenance Schedule Table.....	10
<b>9. Trouble-Shooting Guide .....</b>	<b>11</b>
9.1. Unit operation troubleshooting chart .....	11
9.2. Unit performance troubleshooting chart .....	14
<b>10. Parts List &amp; Spares.....</b>	<b>15</b>
<b>11. Dewatering Press Materials and Coatings Schedule .....</b>	<b>16</b>

## 1. Introduction

### 1.1. Process Wastewater Technologies, LLC

Process Wastewater Technologies, LLC (PWT) has been established to provide clients with unique technologies to achieve cost-effective best management practice in water quality. The company is committed to its clients and the environment. Its focus is on development, manufacturing, installation, and operation of innovative technologies for water, wastewater and wet weather flow treatment.

### 1.2. The Volute Dewatering Press

The Volute Dewatering Press is designed to dewater sludge in a compact, automated and self-contained operation. The basis of this process is the “Dewatering Drum” designed by Amcon Inc. of Japan. It is a type of screw press that utilizes a screw inside a moving casing. At the time of printing, there are around 1800 units in operation around the world.

The scope of operations includes:

- Municipal Water (Alum, Ferric, Lime and PACL sludges)
- Wastewater plants (WAS, anaerobic and aerobic digested, MBR WAS, primary, fixed-film sludges, Lagoon sludges)
- Dairy processing
- Meat packing (DAF and Lagoon sludge)
- Processed food production (biological process waste sludge and DAF sludge)
- Tanker wash-down
- Winery, aquaculture, metal plating

### 1.3. Use of this manual

This operation and maintenance manual is written to act as a reference for operators to assist in the trouble free operation of the Volute Dewatering Press unit. It contains:

- 1.3.1. Detailed information on the setup and operation of the system
- 1.3.2. Suggested operation procedures for the ES Series Volute Dewatering Press.

- 1.3.3. Detailed descriptions of the PLC operation of the unit
- 1.3.4. Tips and techniques for optimization of the Dewatering Press operation
- 1.3.5. Inspection and maintenance schedules

This manual covers the information required for the most likely scenarios encountered during the service life of the Volute Dewatering Press unit. However, it does not cover all possible scenarios, and further information may be sought from PWT if required.

## **1.4. Exclusions From This Manual**

Things that are not in this manual are:

- 1.4.1. Information on design or manufacture of PWT Volute Dewatering Press units.
- 1.4.2. Design and Installation instructions – these are available in a separate document.
- 1.4.3. Detailed operating instructions for other components of the dewatering system. These documents will be appended to this manual should they be required.
- 1.4.4. Information on the overhaul of the dewatering drums. This is a major procedure and is best undertaken by qualified technicians.

## **1.5. Velodyne Polymer system instructions**

This manual includes information on the operation of the Velodyne Polymer systems that are commonly supplied with the Volute Dewatering Press. If a different polymer system is used, but it is still a liquid polymer preparation system, much of the information in this manual will still be pertinent, even if there are small differences in the design of the equipment.

## **1.6. Additional information**

PWT endeavors to provide its clients and partners with the best possible technical support. If there are questions relating to the Volute Dewatering Press, its use, this manual, or variations in setup and operating conditions that are not covered by this manual, please contact PWT for assistance.

## 2. Health and Safety

### 2.1. Warnings

The following warning symbols are used throughout this manual to describe the type of hazard that may be encountered during the installation, operation or maintenance of this equipment. All personnel should pay special attention to the procedures indicated.



Immediate hazard which **WILL** result in severe personal injury or death.



Hazard or unsafe practices which **COULD** result in severe personal injury or death.



Hazards or unsafe practices which **COULD** result in personal injury or product or property damage.

### 2.2. Introduction

This Operating and Maintenance Manual is provided to fulfill the responsibilities of PWT to supply sufficient documentation and instructions to enable the users of the equipment supplied under this contract to operate and maintain the equipment in a safe and reliable manner.

This Section of the Manual is designed to make the reader aware of general safety regulations that may impact on operation and maintenance of the unit. In addition, some specific safety measures for certain aspects of the Volute Dewatering Press are outlined.

The operation and maintenance of this plant and equipment must be carried out in compliance with all current and relevant federal Occupational Safety and Health Administration rules and regulations, the relevant state counterparts, any local or regional ordinances that regulate such matters, and any OH&S policies and procedures in effect by the equipment's owner.

The safety regulations applying in the State or Territory are to be strictly adhered to at all times.

Any party performing cleaning, inspections or maintenance on the unit is to be fully aware of all applicable safety regulations and ensure that all staff is adequately trained in safe working practices.

These safety regulations include but are not limited to:

- 2.2.1. Occupational Health and Safety Legislation

- 2.2.2. Confined Spaces Legislation
- 2.2.3. Motor Traffic Legislation
- 2.2.4. Scaffolding and Lifts Regulations
- 2.2.5. Health Regulations dealing with handling of hazardous substances
- 2.2.6. Hazardous Substances Legislation
- 2.2.7. Manual Handling Regulations
- 2.2.8. Plant Operating Instructions
- 2.2.9. Traffic and Pedestrian Safety Standards.

Adequate insurance should be carried to cover Public Liability and Worker Injury.

### **2.3. Health and Safety during Operation and Maintenance**

Equipment sub-suppliers documentation is contained within this manual that is specific to the individual piece of equipment or sub-system. The instructions in this introduction are offered as a general guideline and should be strictly observed but not be regarded as complete and exhaustive:

All work shall be carried out by appropriately trained and qualified personnel.

All equipment shall be made safe prior to any maintenance being undertaken. This will require isolation from electrical power and/or process liquid flows. Electrical switches and isolation valves or temporary dams shall be selected and locked in the 'OFF' position.

All work on electrical equipment must be completed in strict accordance with local electrical codes and the manufacturer's instructions.

Safe access must be provided to relevant parts of the plant and all lifting equipment shall be covered by a current safety inspection certificate.

Appropriate protective clothing and equipment shall be worn at all times.

When working in confined spaces, gas detection equipment, and breathing apparatus in accordance with safety procedures shall be used.

## 2.4. General Warnings

The following general WARNINGS must be observed before any maintenance work is carried out:



**HIGH VOLTAGES CAN KILL!**

**BEFORE WORKING ON ANY COMPONENT THAT HAS  
ELECTRICAL CONNECTIONS:**

**MAKE SURE THAT THE ELECTRICAL SUPPLY IS ISOLATED.**

**MAKE SURE THE CIRCUIT BREAKERS ARE TRIPPED AND TAGGED.**





**MOVING MACHINERY AND PINCH HAZZARDS!  
KEEP HANDS CLEAR OF ANY MOVING PARTS WHILE  
THE UNIT IS IN OPERATION:**

**MAKE SURE THAT THE ELECTRICAL SUPPLY IS ISOLATED.**

**MAKE SURE THE CIRCUIT BREAKERS ARE TRIPPED AND TAGGED.**



**SLIPPERY SURFACE!**


**CARE MUST BE TAKEN TO MINIMIZE POLYMER, SOLIDS  
CAKE, AND FILTRATE SPILLED IN THE AREA  
SURROUNDING THE VOLUTE DEWATERING PRESS.**

**CLEAN FLOORS IMMEDIATELY FOLLOWING ANY SPILLAGE OF POLYMER OR  
OTHER LIQUIDS CONTAINING POLYMER.**


**OPERATE UNIT WITH SIDE PANELS IN PLACE TO MINIMIZE FILTRATE SPILLAGE.**

### 3. Volute Dewatering Press Main Components


The following diagrams show the main components of the Volute Dewatering Press.




**Figure 3.1 – Control panel side elevation component drawing**




**Figure 3.2 – Plan view component drawing**




**Figure 3.3 – Solids discharge end elevation view component drawing**




**Figure 3.4 – Flocculation tank end elevation view component drawing**



**Figure 3.5 – Dewatering Drum Assembly**



**Figure 3.6 – VM-P-XXX-X0D polymer system components (Progressive cavity pump)**



**Figure 3.7 – VMN-D-XXX-X0D polymer system components (Diaphragm pump)**

## 4. General Operation Description

### 4.1. Introduction

This section describes the overall operation of the Volute Dewatering Press system and the functions and operation of each major component of the Volute Dewatering Press.

### 4.2. Main Process Functions

Sludge is fed via a pump to the unit. This pump is typically controlled by the control panel of the Volute Dewatering Press.

Polymer solution is injected into the flow of sludge just prior to the sludge entering the flash mixing tank that thoroughly mixes polymer and sludge together. The sludge mixture then flows into the base of a flocculation tank. The sludge and polymer flow up through the flocculation tank where it is gently mixed by a rotating impeller.

Flocculated sludge flows through tubing from the flocculation tank into the base of the dewatering drum. The screw inside the dewatering drum rotates, moving solids up the drum while filtrate flows from the dewatering drum into the effluent drain.

Dewatered cake is discharged from the end of the dewatering drum. In some cases, this is carried away by a conveyor that is also controlled by the unit.

### 4.3. Polymer Feed System

Polymer solution is made up and dosed continuously in an automated process that is separate from but controlled by the Volute Dewatering Press. Typically the process consists of a neat polymer feed pump and a mixing/activation chamber where the neat polymer is mixed with dilution water. Activated polymer solution is then injected into the sludge feed line to the Volute Dewatering Press.

### 4.4. Flash-Mixing and Flocculation Tank

The flash-mixing tank is where polymer and sludge are mixed rapidly to achieve thorough mixing of the polymer throughout the sludge to optimize polymer usage. This tank is equipped with a single or twin 3 blade aerofoil impellers driven by a 4-pole gear motor with a 5 or 10 to 1 gear ratio.

The flocculation tank is designed to achieve gentle continuous mixing of the sludge, allowing flocs to form. The tank is approximately square in layout and has a large cross-sectional area impeller driven by a 4 pole gear-motor with a 60:1 ratio.

The impeller speeds on both tanks are controlled by variable frequency drives (VFD) and are adjustable at the programmable logic controller (PLC). The design of this system allows for enough mixing energy and time for flocs to form under most operating circumstances. It also gives the operator significant scope to alter and optimize the mixing energy profile to optimize unit performance.

#### **4.5. Dewatering Drums**

The dewatering drums are the key to the Volute Dewatering Press operation and performance. The unique dewatering drum comprises of a variable pitch Archimedes screw within a casing of fixed and moving rings. The casing is assembled on a number of support rods which hold the fixed rings in place. Between each fixed ring on the support rods is a spacer which holds the fixed rings apart. Between each fixed ring is a smaller moving ring which has an inside diameter smaller than the outer diameter of the screw. In addition, the width of the moving rings is fractionally less than that of the spacers holding the fixed rings apart. The moving rings are then moved by the outside of the rotating screw

Flocculated sludge is fed in at the base of the dewatering drum and is transported up inside the drum by the screw. Initially, in the first part of the drum (the “Thickening Zone”), the pitch of the screw is about the same as its diameter and there is an average 0.5mm (1/50”) gap between the moving and fixed rings. Thickening of the sludge occurs in this section and the majority of the free water is released, mainly due to gravity.

The pitch of the screw and the gap between the moving and fixed rings decreases as the flocculated sludge is transported further up the dewatering drum. In the last part of the dewatering drum (the “Dewatering Zone”), the average gap between the moving and fixed rings is 0.075mm (3/1000”). An adjustable endplate sets the gap from where the solids exit at the end of the drum, providing the back pressure that forces interstitial water out of the cake.

#### **4.6. Electrical Control Panel**

The electrical panel controls and operates the entire Volute Dewatering Press system, including ancillary equipment such as feed pumps and conveyors, if connected. It is integrated with external components such as the polymer make-up system and feed pump to provide seamless operation for the whole process of sludge dewatering.



## 5. Operating the Volute Dewatering Press

This section covers the general operating conditions and procedures for the Volute Dewatering press. The actual operation and detailed instructions on monitoring and varying operating parameters is located in the next section that deals with the specific HMI/PLC operating procedures.

### 5.1. External Panel Controls


All regular activities associated with the operation of the press may be undertaken utilizing the controls on the external face of the unit control panel. Figure 5.1 shows the external panel design.

The external face of the panel includes the following items:

- 5.1.1. Main Circuit Breaker
- 5.1.2. System STOP button
- 5.1.3. HMI / PLC display and keypad\*
- 5.1.4. Power On light\*
- 5.1.5. System H-O-A switch\*
- 5.1.6. System Running light\*

\* Within an enclosed switch compartment with:

The power-on light indicates that the unit is switched on and has power. The system running light indicates that the unit is set to “Auto” and is operating.



**Figure 5.1 – External Panel Controls**

(Layout might vary slightly for some installations)

## 5.2. Pre-Operation Checks

Prior to operating the unit, the following checks should be undertaken.

- 5.2.1. Check that the flash-mixing and flocculation tanks are free of any objects that may interfere with the rotation of the mixing impellers.
- 5.2.2. Check that power is on at the unit (indicated by the white light on the outside door of the control panel).
- 5.2.3. Check the endplates of the unit. Check that these are free of dried solids, that the gap is set correctly, and that the set screws are tightened (S7.5)
- 5.2.4. Check that the polymer preparation and storage system is ready to be used with the dosing pump primed and water supply to the dosing system on.
- 5.2.5. Check that all relevant valves are open, allowing the flow of sludge to the unit.

## 5.3. Starting the unit up

PLC Initialization - When the PLC is powered up it will go through a 10-15 second initialization sequence. During this sequence, the operation of the Volute system is inhibited. The PLC will restore communication with the VFDs, reset VFD faults, reset shutdown alarms and place the system in a “ready to operate” mode. The PLC will also execute this sequence when the Push/Pull E-stop button is pulled out or the user presses the reset button on the PLC menu.

## 5.4. E-Stop Button

E-stop - A “Push to Stop / Pull to Start” E-stop red mushroom type button is mounted on the enclosure door. When pushed in, the PLC will immediately stop or close all motors, pumps, and valves.

**Note: This E-stop does not disconnect power to the control panel.**

Some single phase 120V or 24VDC power also remains active to power the PLC, cooling fan, and spare 115V terminals. Use the main circuit breaker on the external door to completely disconnect all power.

## 5.5. System H-O-A Switch and modes of operation

There are two (2) modes of operation for the Volute Dewatering Press these being “Manual” and “Auto”. To go between these two modes and the “Off” mode, the System H-O-A (Hand-Off-Auto) switch must be used.

- 5.5.1. Manual Operation Mode - The manual mode is primarily designed for checking operation of individual pieces of equipment, and maintenance. In this mode, the main items of equipment can be switched on and off individually on the PLC. Any level or fault indicators will not stop the operation of the components running in this mode, thus the unit should not be left running unattended in manual for any length of time. In addition, the Elapsed Time Meter (ETM) for the whole system does not operate in this mode so extended operation in this mode will mean that the ETM significantly understates the real operating time of the system.
- 5.5.2. Auto Operation Mode - Under this mode of operation the unit will run itself and will shut itself down in the event of any problems detected by the control system. The unit should always be run in Auto mode. Once the unit is operating in Auto mode, it will run either continuously or be controlled by the clock settings.

## 5.6. Time Clock Operation

In auto operation mode, the unit may be set time clock operation (setup described in Section 6). Under time clock operation, the unit will start and stop according to a programmable timer that allows the days and hours of operation to be set. There are typically two (2) time clocks to allow different regimes to operate simultaneously.

## 5.7. Conditions for operation in Auto mode

The following conditions must be met for the unit to run in Auto mode:

- 5.7.1. E-Stop button must be “out” and any other E-stops in the system (such as the conveyor pull cord) must not be activated.
- 5.7.2. System H-O-A switch must be set to “Auto”
- 5.7.3. Flocculation Tank fluid level must be below the High-Level Probe
- 5.7.4. Circuit breakers must not be tripped
- 5.7.5. VFDs must not be faulted
- 5.7.6. Polymer dilution system must have sufficient water pressure (>20psi)

5.7.7. There must be polymer supply to the polymer preparation system.

**Note that turning the main circuit breaker to the “On” position will start the unit if the H-O-A switch is set to Auto and the unit is set for continuous operation, or to be running at that time in Time Clock Mode.**

### **5.8. Unit Shutdown and Clean-up**

When operation of the unit is finished, there is no need to undertake any cleaning or shut down unless the unit is to sit unused for more than a few days, or is likely to be subjected to freezing conditions. Thus under a daily operating regime, the unit may simply be switched off or switched off by the time clocks with no further action required.

Should the unit need to be shut down for an extended period the following should be done:

- 5.8.1. Flash-mixing and flocculation tanks should be drained and cleaned out.
- 5.8.2. Dewatering drum should be run on its own for a minimum of thirty (30) minutes, the last ten (10) minutes of which the “Off” time on the Dewatering drum spray (Section 5.13) should be set to zero (0) so that the sprays operate constantly.
- 5.8.3. Polymer system should be cleaned out by running mineral oil or a dispersant through the raw polymer pump, check valve, mixer, and then leaving the system full.
- 5.8.4. Main circuit breaker and “H-O-A” switch should both be switched to the “Off” position.

## 6. PLC and HMI Operating Instructions

This section deals with the specific operating instructions for the Volute Dewatering Press system through the PLC that controls all of the functions of the operation.

### 6.1. General PLC operating instructions

The HMI is a touch screen design and all operation of the unit is done by pressing “buttons” on the screen. These buttons are visually shown as being “raised” on the screen with an outline and a shadow.

Once the PLC is on, moving between the various screens to operate the unit is easily done by pressing the gray buttons on the screen.

All operational adjustments made using the PLC are either:

- “on-off buttons” (or “select/deselect buttons”) which change the operating state of an item when pressed, or
- “Numerical value button” which when pressed brings up an on-screen numerical keypad to allow adjustments such as time, speed, or percentage input settings.

There are some “on-off” buttons that instantly change the operation of the equipment. These Buttons include:

- Manual on-off “switches” for operating individual devices while the H-O-A switch is set to manual operation
- Buttons that switch Conveyor direction and conveyor gate operation for systems that have reversible load-out conveyors.
- Buttons that switch between different devices such as feed pump selection if there are multiple feed pumps.

These buttons, that instantly make an operation change, require the operator to press the buttons down for at least two (2) seconds. This prevents accidental switching on and off of system components.

Buttons may be one of four (4) colors: Each color indicates the status of the button:

- A gray button indicates that the button is for moving to a different screen.
- There are also “grayed out” buttons that indicate a button is inactive. This means that the button will not operate because its function is not available. An example of this is the buttons for manually switching devices on and off will be gray when the H-O-A switch is

set to Auto as these buttons are only for operating when the H-O-A switch is set to Manual.

- A Blue button indicates that the button will be functional and pressing it will activate the buttons function
- A Green button indicates that an item has been selected. For example, if the system has two feed pumps, each one will have a button displaying its status. When the feed pump is able to be switched on, the button will be blue. Once it has been switched on and is in operation, the button will be green.
- A Red Button indicates that the button needs to be pressed, typically to either clear a fault or to stop a component of the system from operating.

## **6.2. Navigating around the PLC**

The PLC program, while being generally the same for all installations, is customized to each installation. This is primary because different installations will feature different components being controlled by the PLC such as the type or number of conveyors or sludge feed pumps. In addition, there may be variations due to the operator's site specific requirements.

**The position and range of options shown on the PLC screens herein may vary from this manual depending on the installation.**

Upon power up, the first screen will be the Overview Display which shows the status of all systems.

From the Overview Display (or any other screen), accessing the Main Menu allows the operator to access each operation screen. From each of the operations screens, the operator can return to Main Menu screen.

The Automatic and Manual Control Screens and Alarm History Log Screen may also be accessed directly from the Overview screen as these are the most likely to be used to make system adjustments.

### 6.3. Basic Operating Screens

While there are a large number of screens, the operator should only be concerned with being familiar with the small number of screens that are likely to be required during day to day operation. These screens are:

- 6.3.1. **Automatic Control Screen** – where the system device parameters are set and adjusted for operation.
- 6.3.2. **Time Clock Setup Screen** – where the time clocks are set for unmanned start-up and shutdown of the system
- 6.3.3. **Manual Control Screen** – where individual system devices can be started and stopped
- 6.3.4. **Alarms & Alarm History Log Screens** – where information on active alarms that may have shut the system down are displayed.

The other screens fall into a couple of categories.

- 6.3.5. **Information screens** – an example of this is the Device screens which are primarily there so that an operator can look at data on the operation of that device such as the current it is drawing or its Elapsed Time Meter (ETM or time of operation). Most of the screens under the PLC submenu and all the screens under the Help submenu fall into this category. Some of these screens may also allow adjustments of the system of devices but they are primarily for information, mainly for O&M and troubleshooting purposes.
- 6.3.6. **Initial Setup Screens** – some screens such as the Flow-Feed Pump PID Screen or the Alarm setup screen should be set up by the commissioning staff and should not need to be adjusted in any way unless there is a significant change to the system (such as adding a new Device).

Anytime these screens need to be accessed, it is more than likely that it would involve a PWTech engineer helping to modify the operation or undertake some troubleshooting and as such familiarity with them is not important to the operation of the Dewatering system on a day to day basis.

### 6.4. Overview Display

This screen (See figure 6.1) is the main operating information screen. It gives the operator an overview of the main things that are happening with the system. Items that are typically displayed here are:

- 6.4.1. **Auto operating regime** – continuous operation or time clocks.

- 6.4.2. **Sludge Flow Rate**
- 6.4.3. **Devices selected** – if there are multiple options for components in the system, such as a duty/standby feed pump arrangement, the one that is in use will be indicated.
- 6.4.4. **Devices in operation** – any device that is operating will be highlighted green on the screen.
- 6.4.5. **Important device speeds** – such as Dewatering Drum speed and the polymer pump speed.
- 6.4.6. **Alarm conditions present** – any active alarms causing shut down of the system will be displayed.
- 6.4.7. **Spray wash time status** – displays the time till the next spray wash or end of the spray wash of the dewatering drums.




Figure 6.1 – Overview Display

It shows the alarm that is active and has a button to clear the alarm as well as one to go to the current alarm screen to view details on the alarm. For the unit to be restarted the conditions leading to the alarm must be cleared and the alarm cleared at this screen.



From the Overview Display, the Main menu is accessed as well as the Automatic Control Screen and the Manual Control Screen as these are the two main screens for making operational changes.

## 6.5. Control Screens

### 6.5.1. Automatic Control

This screen allows for the selection of equipment in operation, the nature of the operation and timer settings for the operation. (See figure 6.2)


Feed Pump Settings – the feed pump can either be run at a constant pump speed or if a flowmeter has been installed in the system and is set up correctly, it can be set to run at a constant flow rate using a feedback loop. Normally there is an on/off button to switch the type of control desired on. Then, there is the typical numerical value button to set either the pump speed or desired flow rate.

Other speed settings – the speeds for the Dewatering Drums, Mixers, and Polymer pump are also set on this screen.

Run Mode Select – Continuous or Time Clock. Pressing the Continuous button will mean that the unit runs in Auto mode whenever the H-O-A switch is set to Auto. When the Continuous button has been pressed it will be green indicating that the unit is operating in Continuous mode. When the Time Clock button is pressed the unit will run according to the time clock settings (Section 6.9) whenever the H-O-A switch is set to Auto.

Device Select – where there are options with different devices in the dewatering system such as duty/standby sludge feed pumps, multiple conveyors, or load out conveyors with gates, they are selected on this screen. Please note that not all devices can be changed while the system is operating. Feed pumps, for example, are typically set up in a way that does not allow them to be switched unless the system is not in operation.

Timers – several system timers can be set on this screen. Details on how to set the timers are found in Section 7.



**Figure 6.2 – Automatic Control Screen**

### 6.5.2. Manual Control


When the H-O-A Switch is set to Hand or Manual, the Manual Control Screen (See figure 6.2) is where the various devices in the system can be switched on and off and adjusted to check their operation. As previously mentioned, the system should not be operated from this screen as it should always be run in Auto. However, for inspection and maintenance of individual devices, this is the only place items can be switched on and off individually.

Buttons must be pressed and held for two (2) seconds in order to switch any item off or on.

### 6.5.3. Time Clock

Typically Volute Dewatering Press systems are set up with two (2) time clocks and these are controlled from the Time Clock Setup screen (See figure 6.3). The time clocks are set by first selecting the day of the week they are to operate (press the button for that day and it will appear to be depressed), and then selecting the time to operate on that day.

Both time clocks can operate simultaneously. For example if you selected Monday only for time clock #1 and set the times from 08:00 to 16:00, and selected Tuesday only for time clock #2 and set the time from 00:00 to 08:00, the unit would switch on at 8am Monday and switch off at 4pm and then switch on again at midnight and run till 8am on Tuesday.



**Figure 6.3 – Time Clock Screen**


#### 6.5.4. Flow Setup Screens

The Flow – Feed Pump PID Tuning Screens (See figures 6.4 – 6.6) is used to tune the PID loop for feedback control of the sludge feed pump(s) based on the flow meter output so that the operator can set a flow rate and the unit would operate at this flow.


Typically the operator should not actually need to use this screen as the tuning should be done during start-up and once done, should not need to be changed unless a new pump or flow meter is added to the system.

The tuning that is done on this screen is setting the relationship between the signal from the flow meter to the signal going to the VFD for the sludge feed pump so that it responds to changes in the input feed flow in a timely manner but does not become unstable in its operation. Separate documentation on


generalized tuning of PID loops should be sought should the operator wish to make adjustments to this screen.



**Figure 6.4 – PID Screen**



**Figure 6.5 – Flow Setup Screen**



**Figure 6.6 – Polymer Flow Rate Screen**

6.5.5. Alarm Screens

These screens (See figures 6.7) allow for the initial set up and time delays for alarms, and for resetting an active alarm. To change setup parameter, and to override alarms, the user must be logged in as a supervisor. In addition, there is an alarm history screen (See figure 6.8) that displays all prior alarms.




Figure 6.7 – Alarms Page



Figure 6.8 – Alarm History Screen

## 6.6. Equipment VFD Device Screens

The following device screen is for any component of the system that is run off a Variable Frequency Drive (VFD). These screens are primarily for information purposes for specific components of the dewatering system. Typically the screen allows for resetting of the VFD and also in some cases allows for the device to be taken out of service. (See figure 6.9 – 6.10)




Figure 6.9 – VFD Screen



Figure 6.10 – VFD Fault Screen

## 6.7. Admin Screens

### 6.7.1. COMs Screens




Figure 6.11 – I/O COMs Screen




Figure 6.12 – Ethernet COMs Screen



6.7.2. Login Screen




Figure 6.13 – Login Screen

### 6.7.3. Elapsed Time Monitors Screen

The Elapsed Time Meters (ETM) Screen (See figure 6.14) has all the ETMs for the different system components in a single place. As for the Rate Calculations screen, this screen should not need to be accessed under normal conditions. The primary reason for this screen is that it allows modification of the ETMs if required. This is primarily so that if a device is replaced, its ETM can be reset to zero.




Figure 6.14 – Elapsed Timer Monitor Screen

## 7. Adjustments and Optimization

There are several places where adjustments and settings can be made on the Volute Dewatering Press. The following are the key ones and their effects on the operation:

### 7.1. Sludge Feed Rate

The maximum sludge feed rate depends on the solids concentration of the feed, the quality of the floc formed, the dewatering drum speed, and the end plate gap.

As a general rule, a lower sludge feed rate will result in drier solids cake.


When attempting to run the unit at or near its maximum flow rate, care must be taken not to feed sludge to the unit too fast as solids in the dewatering drum will build up and ultimately reduce the capacity of the unit by reducing the area available for water to escape the dewatering drum. In maximizing the sludge feed flow rate, incremental adjustments should be made, slowly increasing the rate up towards the maximum.

Sludge feed rate is adjusted either by setting the flow rate or the speed of the feed pump at the Automatic Control Screen on the PLC as per Section 6.8.

### 7.2. Dewatering Drum Speed

The dewatering drums should be set to run as slow as possible for the sludge feed rate set. Slower dewatering drum speeds typically result in drier cake. Ideally, the speed should be set so that the pipe out of the flocculation tank to the dewatering drums is half submerged. The dewatering drum drive speed is set by adjusting the Dewatering Drum VFD speed on the PLC as per Section 5 of this manual. The VFD may be adjusted from 15Hz up to 100Hz. If the unit has multiple Dewatering Drums, all Dewatering Drums should be set to run at the same speed all the time.

During calibration, the speed of all dewatering drums is verified, thus the calibration data below is valid for both all dewatering drums on the unit.



**Figure 7.1 – Relationship between input frequency and Dewatering Drum Rotational Speed**

### 7.3. Polymer Feed Rate

The polymer feed rate should be set such that the flocs appear to be well defined and large in the flocculation tank and filtrate is clear but not slippery to the touch. If the flocs in the flocculation tank are small (<math>\lt; \frac{1}{8}"</math>) and the filtrate is dirty, then more polymer needs to be added.

If altering the feed rate, and the polymer dose is correct at the initial sludge feed rate, the polymer dose should be adjusted proportionally.

The polymer feed rate is set on the PLC Device Screen as per section 6 of this manual.

If the polymer system uses a diaphragm pump, the stroke length can also be adjusted. To maintain the best operation and performance, the stroke length should be set to the highest setting that can be used across the range of doses required for successful operation. For example, it is better to have the frequency set to 10% and the stroke to 100% than to have the stroke at 50% and the frequency at 20%, even though it should achieve the same flow. This is done to prevent clogging in the pump.

### 7.4. Flash-mixer and flocculation tank mixer speed

The mixer speeds are adjustable in the same fashion as the dewatering drum drives and polymer dosing pump using the PLC as per Section 5 of this manual. The range of Adjustment is from 10 Hz up to 60 Hz. Typically the flash mixer should be left around 60Hz regardless of the sludge. The flocculation tank mixer will need to be adjusted based on the type of sludge.




Figure 7.2 – Mixer Speeds for the Flash-mixing tank




Figure 7.3 – Mixer Speeds for the Flocculation tank

## 7.5. End Plate Gap

The end plate gap should be set at the minimum gap that does not cause build-up of sludge inside the dewatering drums or excessive squeezing out of solids in the dewatering section of the drum for the set sludge feed speed and dewatering drum rotation speed.

Typically this gap will vary from unit to unit and application to application. For units up to the 200 series, the space should vary from  $\frac{1}{16}$ " to  $\frac{1}{2}$ ". For the 300 series units, the end plate gap should be between  $\frac{1}{4}$ " and  $\frac{3}{4}$ ".

## 7.6. Spray Valve Timer Settings

Spray settings have minimal effect on performance of the unit. The times should be set such that the build-up of solids on the outside of the dewatering drum is controlled over several hours of operation.

## 7.7. Other Timer Settings

Most of the other timer settings will have little impact on the performance of the system but setting them correctly may assist in the smooth operation of the system. The following describe the timer settings and their functions:

- 7.7.1. Polymer Fault Delay – This is a delay from when the polymer system detects a fault till it shuts the system down. The benefit of adjusting this is that if there are short periods of time where the water pressure drops due to other demands on the water supply system, setting the delay to act over a longer period will allow the polymer preparation system to keep operating so that the unit doesn't switch off every time a momentary fault occurs.
- 7.7.2. Extended Drum Run – If the unit is not used regularly, setting the extended drum run time to a longer period (say 20 minutes or more) will clean out solids from the dewatering drum so they will not cake and harden in the Dewatering Drum. If used regularly, setting the extended run time to a shorter period (say 2-5 minutes) will allow the unit to resume steady state operation quickly when re-started.
- 7.7.3. Conveyor extended run – In the event that a conveyor is controlled by the system, a timer to control the additional time a conveyor runs is included. This timer begins at the point that the Extended Drum Run Timer stops. This allows for the conveyor to run a little longer in order to remove any solids present on the conveyor. The settings for this are totally dependent on the specific design of the conveyor and the need, if any, to remove solids from it at the end of operation.

- 7.7.4. Flocculation Tank High Level – This delay should be minimal since any event causing this to fault indicates an operational problem. The use of a short delay, however (~10 seconds) means that minor splashes of fluid or other items temporarily contacting the level sensor electrodes will not shut the system down.
- 7.7.5. Unit Start Up – This delay should normally be set to zero (0) seconds. The delay is used for installations with remote starting of the unit, or when there are other system components that need to be engaged prior to starting the press. It is there so that the unit will not start up if conditions leading to a fault are still active, or the system could be damaged by starting too soon. An example of its use would be if there were automated valves in the feed sludge lines that needed time to open prior to the feed pump and the press starting up.

## **7.8. Polymer Dilution Water Flow rate**

The polymer dilution water flow rate is manually set on the polymer system. It should be set to achieve the recommended polymer concentration in solution as per the polymer manufacture's instruction.

## **7.9. Polymer System: VeloBlend Mixing Chamber**

The operation of the polymer system can result in significant variations in performance and it is important that the optimal mixing and make-down conditions are set for the polymer being used. While this is covered in detail in the polymer manual, the following is a guide for setting up the mixing chamber.

The Hydro-Mechanical VM Series VeloBlend produces mixing energy by the pressure drop across its water control valve and or by the mechanical impeller. The recommended differential pressure range is from 30 to 100 psid. The pressure is not controlled, but rather is the result of the available water pressure and the pressure downstream of the system. Therefore, simply setting the desired rate of water flow then verifying that adequate differential pressure is available is all that is required to operate the mixing chamber. In the event inadequate pressure exists, the impeller can be utilized by turning on the Mixer and adjusting the speed. The mixer is turned on by turning the speed potentiometer for the mechanical mixer. The speed potentiometer is located inside the control panel.

The need and benefit of the impeller must be verified by trial and error. After the system is set up for desired water and polymer flow rate, turn the impeller and set at approximately 10% of the impeller speed by gradually turning the potentiometer on the inside of the control panel. Allow the system to run for enough time to adjust to the changed setting. If the polymer flow rate can be reduced then the impeller is enhancing performance. Continue to increase impeller speed 10% at a time until the performance begins to decline. Your polymer system is optimized.

## 8. Inspection & Maintenance Schedule

### 8.1. Introduction

This section outlines the inspections that should be periodically carried out on the Volute Dewatering Press as preventative maintenance. Table 8.1 shows the recommended frequency although this can be altered to suit the installation.

### 8.2. Cake discharge inspection

The flow of cake from the unit should be even and continuous in its nature as the end plate rotates once the unit has reached steady state operation. The existence of any segments of the endplate where no solids are discharged each time that section comes into view indicates a blockage inside the end plate. This may be some dried cake lodged in the end of the dewatering drum, or possibly a foreign object. It is unlikely that the presence of anything blocking the flow of solids will cause any damage, however, it will degrade the performance and reduce the throughput of the unit.

It is recommended that this inspection be undertaken at least once a day while the unit is operating. While the unit is operating and discharging cake, the discharge from the end of the dewatering drum should be observed for a few minutes for each drum. If there are short periods where solids are not discharged at the bottom of the endplate, this indicates a blockage. In this situation, the endplate should be fully opened by loosening the fix screws holding it in place and the dewatering drums run for a few minutes to remove the blockage.

### 8.3. Flocculation tank high-level probe

The high-level probe in the flocculation tank should be checked and cleaned daily to prevent a build-up of dried sludge and rag material that could cause it to set off a high-level alarm when no such condition exists.

### 8.4. Unit performance

It is recommended that performance parameters (Throughput, Influent Solids, Filtrate solids, Cake solids) be checked regularly (once per week) such that any trends in performance such as declining cake solids due to wear can be detected over time.



## **8.5. End-plate settings**

The end plate gap should be checked once a week to ensure the plate has not slipped and opened up from the spacing they were originally set to.

## **8.6. High and low-level probe operation inspection.**

The operation of the level probes used to shut down the unit in the event of high or low fluid levels should be checked periodically.

It is recommended that the operation of the level probes is checked once a week. For the High-level probe in the flocculation tank, this may be done by using a screwdriver to “bridge” between the probes while the unit is running – this should switch the unit off and signal an alarm. If a low-level probe is connected for the polymer tank, then this should also be checked by removing the probe from the fluid while the unit is operating, triggering the alarm.

## **8.7. Drive motors**

Drive gear motors for the dewatering drums (except ES35X series) and the flocculation tanks are designed to run throughout their life with no regular maintenance.

However, it is recommended that the motors are inspected once a week during operation for vibration, noise or excessive heat that would indicate any damage to the motor. This inspection may simply consist of placing a hand on the drive during operation and feeling for excessive heat or vibration, and listening for any noises made by the drive.

The ES35X series drive gear motor gear box oil level should be checked once a month.

## **8.8. Tank mixers**

If the sludge being dewatered contains rags and fibrous material then it is likely that the mixing and flocculation tank impellers will accumulate rags over time that will wrap around the central shaft and catch on the impeller blades. This will reduce the effectiveness of the mixing and decrease the life of the drive.

It is recommended initially that once per week the tanks are drained and washed out, the impeller inspected and de-ragged if required. This schedule can be adjusted as necessary.

## **8.9. Polymer preparation system**

Regular checks should be made that the polymer preparation system has adequate polymer supply to keep the unit operating continuously as required. In addition, inspections including calibration checks and periodic cleaning of the polymer feed system should be undertaken as

per the manufacturer’s instructions. It is very important that water is not used when cleaning polymer system components.

### 8.10. Lubrication Schedule

All gear motors on the ES101 - ES303 are sealed units and do not require lubrication. Also, the dewatering auger rotates in a self-lubricating bearing. No lubrication is required.

The ES35X series dewatering drum drive gear motor gear box oil level should be checked once a month. Change oil at 10,000 operating hours or approximately 2 - 4 years. Figure 8.1 below shows a sample gear box reducer nameplate which has the recommended gear oil. If you use synthetic lubricants, you can effectively double the maintenance cycle.



Figure 8.1 – ES35X Series Drum Drive Gear Motor Gear Box Name Plate

The mixing tank gear motors on the ES35X series dewatering press are sealed units and do not require lubrication. Also, the dewatering auger rotates in a self-lubricating bearing. No lubrication is required.

### 8.11. Maintenance Schedule

No regular maintenance is required for the dewatering press.

## 8.12. Inspection & Maintenance Schedule Table

Item	Frequency	Operation	Method
Overall performance	Daily	Inspection	With unit operating ensure cake solids concentrations and solids capture goals are being met using lab analysis methods such as TSS and TS tests
Solids discharge/endplate	Daily	Inspection	As unit is in operation visually inspect endplate to ensure solids are being discharged with no visible signs of rags or other clogging items
Tank high level probe	Daily	Inspection and clean	With unit not operating ensure that no rags of build up of debris are coating either of the probes
Flocculation and flash tanks	Daily	Inspection and clean	With unit not in operation make sure flocculated solids are not building up a crust with the mixing tanks that would limit the volume of the tanks. Drain tanks or wash down with hose as needed.
Raw polymer supply	Daily	Inspection	Ensure there is an adequate amount of polymer in pail/drum/tote
Raw polymer injection check valve (Velodyne)	Monthly	Inspection and clean	With unit not in operation remove pin from the white check valve on top of the Velodyne mixing chamber. Ensure internal spring is not clogged with polymer and replace. Do not use water to clean.
Polymer TFS probe	Monthly	Inspection and clean	With unit not operating loosen nuts on the silver TFS probe and remove from polymer line. Ensure probe is not coated in polymer and clean as necessary. Do not use water.
Raw polymer pump	Monthly	Calibration	With unit operating ensure that the raw polymer pump is calibrated by filling the calibration column with mineral oil, switching valves to ensure the column is being pumped down, and timing the draw down using the measurements on the column.

**Table 8.1 – Inspection and Maintenance Schedule**

## 9. Trouble-Shooting Guide

### 9.1. Unit operation troubleshooting chart

<b>Problem</b>	<b>Possible causes</b>	<b>Actions</b>
No Power to unit - Control Panel Power Light (External Door) will not come on	<p>Main circuit breaker tripped</p> <p>External breakers are off/tripped</p> <p>Voltage at main circuit breaker does not match that shown on the drawing</p>	<p>Re-set unit and/or external breakers</p> <p>Switch external breakers on</p> <p>Check voltage at main circuit breaker*</p>
Unit will not start in Auto (H-O-A switch is in "Auto" position)	<p>E-Stop button must be "out" and any other E-stops in the system (such as the conveyor pull cord) must not be activated.</p> <p>Flocculation Tank fluid level must be below the High Level Probe</p> <p>Circuit breakers and fuses in the control panel must not be tripped or blown</p> <p>VFDs must not be faulted</p> <p>Polymer dilution system must have sufficient water pressure (&gt;20psi)</p> <p>There must be polymer supply to the polymer preparation system.</p> <p>Time clock operation (if being used)</p>	<p>Rectify any conditions not met</p>

No Sludge Entering Unit	Check feed pump drive is on and not faulted	Reset Feed Drive.
	Check feed pump is rotating	If not, Repair Pump
	Check for Pump Blockage	Clear Blockage
Unit continually trips Floc tank High level	Check Cleanliness of probes	Clean Probes
	Check fluid level flocculation tank	If too high, Reduce flow, Increase dewatering drum speed, open up end plate or adjust polymer dose as required.
Dewatering Drum VFDs Trip out	Check Current Drawn by VFD	Run screw backwards to clear potential blockage
		Remove screw from dewatering drum
No Polymer feed to unit	Check polymer pump is primed and feeding	Re-prime if required
	Check Water pressure is >20 psi	Locate other water use and shut off.
	Check for Blockage in line	Clear Blockage

Solenoid valve won't close	Hole in diaphragm designed to equalize pressure on up & down stream side of valve is plugged.	Disassemble valve according to instructions. Clean hole in diaphragm to allow equalization of pressure differential.
Metering pump won't pump	Check valve(s)  Air leak in suction hose / pipe	Clean check valves  Tighten hose clamps, check and fix leaks in piping.  Progressive Cavity Pump: Prime pump by filling calibration column until solution drains through suction cavity plug.
Ineffective polymer mixing	Low water pressure  Excessive solution concentration  Too low of dilution water flow	Increase water pressure by opening valves upstream of system or increase available pressure by adjusting pressure regulating valve up stream of system.  Verify there are no obstructions or closed valves down-stream of polymer system indicated by high mixing chamber pressure.  Verify proper solution concentration (not to exceed 1% in most cases)  Increase water flow. Utilize Mechanical Impeller to make up for low water pressure.

\* This operation involves using extreme caution and should be done by a qualified electrician.

**Table 9.1 – Troubleshooting chart for Volute Dewatering Press Unit Operation**

## 9.2. Unit performance troubleshooting chart

<b>Problem</b>	<b>Checks</b>	<b>Action</b>
Poor cake solids	<p>Check formation of flocs in flocculation tank</p> <p>Check Endplate is not too open or dewatering drum screw speed is not too fast.</p>	<p>Adjust polymer dose as necessary</p> <p>Adjust Endplate and screw setting as necessary</p>
Poor throughput	<p>Check that flocculation is good</p> <p>Check Endplate and Dewatering Drum Screw speed settings</p>	<p>Adjust polymer dose as necessary</p> <p>Adjust Endplate and screw setting as necessary</p>
Poor filtrate quality	<p>Check that flocculation is good</p> <p>Check not too many solids are being squeezed out of the thickening section of the dewatering drum.</p>	<p>Increase polymer dose to improve floc strength</p> <p>Open up end plate or lower feed rate.</p>

**Table 9.2 – Performance troubleshooting guide**

## 10. Parts List & Spares

This is a list of parts that may from time to time need replacement. This is not a complete list of all components of the volute dewatering press.

Item	#	Part # or Name	Contact
<b>Volute Dewatering Press</b>			
Dewatering Drum	1	ES131 Ring Set	PWT
Drum Gear Motor	1	FSW-30-375-T010 WEX	PWT
Drum Gear Plastic Cover	1	FSW-30-375 Cover	PWT
Drum Motor Fan Cover	1	T010 WEX Cover	PWT
End Plate Set Screw	1	ES131 Set Screw	PWT
Set Screw T-Wrench	1	ES131 T-Wrench	PWT
Flash Mixer Gear Motor	1	FSW-25-10-T010 WEXH3	PWT
Flash Mixer Gear Plastic Cover	1	FSW-25-10 Cover	PWT
Flash Mixer Motor Fan Cover	1	T010 WEXH3 Cover	PWT
Flocculation Tank Gear Motor	1	FSW-25-60-T010 WE	PWT
Floc. Mixer Gear Plastic Cover	1	FSW-25-60 Cover	PWT
Floc. Mixer Motor Fan Cover	1	T010 WE Fan Cover	PWT
Spray Valve	1	ASCO 8210G	Industrial supply Co




## 11. Dewatering Press Materials and Coatings Schedule

All materials utilized in the construction of the sludge dewatering equipment are entirely suitable in every respect for the service required. All metals in contact with polyelectrolyte or sludge, and all other components specified to be stainless steel are type 304 or 316 stainless steel. The following table indicates the materials and coatings that shall be provided for the Volute Dewatering Press. Materials and coating information for the drives are found in the motors and drives Section.

12. Item of Equipment	13. Material
All tanks and collection trays	Type 304 Stainless steel
Plumbing	Type 304 Stainless steel or Schedule 80 PVC
Dewatering Drums	Type 304 Stainless steel
Screw	Type 304 Stainless steel with Flame Coating 10Co-4Cr
Spray Bars	Type 304 Stainless steel
Spray Nozzles	Polypropylene
Junction Boxes	Fibreglass
Electrical wiring housing	Non-metallic, flexible liquid-tight conduit and Fittings
Tubing	PVC braid reinforced heavy duty hose
Frame / Skid mounting	Type 304 Stainless Steel
Spray Valves – Wetted Sections	Stainless Steel, EPDM Seating

## Tab 2: Physical Drawings



SIDE ELEVATION

DIMENSIONS: MM [INCH]

REVISION AND ISSUE HISTORY			
REV	DATE	DESCRIPTION	DRN/CHK/D
A	02/28/17	AS BUILT	JS BL

**DRAWING APPROVAL**

APPROVED: \_\_\_\_\_ DATE: 02/28/17 SIGNATURE: \_\_\_\_\_

A. DAVEY

**AS BUILT**

**PWTECH**  
PROCESS WASTEWATER TECHNOLOGIES


Process Wastewater Technologies, LLC  
9004 Yellow Brick Road, Suite D  
Rosedale, Maryland 21237  
Tel. 410.238.7977  
Fax 410.238.7559  
www.PWTEch.us

**DRAWING TITLE:**  
VOLUTE ES131 DEWATERING PRESS  
SIDE ELEVATION

**PROJECT TITLE:**  
CONCANNON VINEYARD  
LIVERMORE VALLEY, CA.

**PWT PROJECT NO:** VDP-CA16116  
**SCALE:** NTS  
**SHEET SIZE:** 11 X 17

**DRAWING NO:** 20170228 VDP-CA16116-ES131S-AB  
**SHEET:** 1 OF 5  
**REV:** A



PLAN VIEW

DIMENSIONS: MM [ INCH ]

**REVISION AND ISSUE HISTORY**

REV DATE	DESCRIPTION	DRN CHKD
A 02/28/17	AS BUILT	JS BL

**DRAWING APPROVAL**

APPROVED: A.DAVEY DATE: 02/28/17 SIGNATURE:

**AS BUILT**




Process Wastewater Technologies, LLC  
 9004 Yellow Brick Road, Suite D  
 Rosedale, Maryland 21237  
 Tel. 410.238.7977  
 Fax 410.238.7559  
 www.PWTech.us

DRAWING TITLE:  
**VOLUTE ES131 DEWATERING PRESS  
 PLAN VIEW**


PROJECT TITLE:  
**CONCANNON VINEYARD  
 LIVERMORE VALLEY, CA.**

PWT PROJECT NO: VDP-CA16116 SCALE: NTS SHEET SIZE: 11 X 17

DRAWING NO: 20170228 VDP-CA16116 ES131S AB SHEET: 2 OF 5 REV: A



PRESS END ELEVATION



TANK END ELEVATION

DIMENSIONS: MM [INCH ]

REVISION AND ISSUE HISTORY			
REV	DATE	DESCRIPTION	DRN/CHKD
A	02/28/17	AS BUILT	JS BL

**DRAWING APPROVAL**

APPROVED: A. DAVEY      DATE: 02/28/17      SIGNATURE:

**AS BUILT**

**PWTech**  
 PROCESS WASTEWATER TECHNOLOGIES  
 9004 Yellow Brick Road, Suite D  
 Rosedale, Maryland 21237  
 Tel. 410.238.7977  
 Fax 410.238.7559  
 www.PWTech.us

**DRAWING TITLE:**  
 VOLUTE ES131 DEWATERING PRESS  
 PRESS END & TANK END ELEVATION

**PROJECT TITLE:**  
 CONCANNON VINEYARD  
 LIVERMORE VALLEY, CA.





**PWT PROJECT NO:** VDP-CA16116      **SCALE:** NTS      **SHEET SIZE:** 11 X 17

**DRAWING NO:** 20170228\_VDP-CA16116\_ES131S\_AB      **SHEET:** 3 OF 5      **REV:** A



**PW TECH NOTES**

- N-01 CONNECTIONS:**
1. SLUDGE INLET, Ø1" FNPT.
  2. WATER INLET, Ø¾" NPT.
  3. FILTRATE OUTLET, Ø3" ANSI 150# FLANGE.
  4. FLOCCULATION TANK DRAIN, Ø2" FNPT.
- MOTORS:**
1. DEWATERING DRUM GEAR MOTOR, 0.1KW.
  2. FLASH TANK MIXER GEAR MOTOR, 0.1KW.
  3. FLOCC. TANK MIXER GEAR MOTOR, 0.1KW.
- N-02 DIMENSIONS SHOWN IN PLAN AND ELEVATION VIEWS.**



**REVISION AND ISSUE HISTORY**

REV DATE	DESCRIPTION	DRN	CHKD
A 02/28/17	AS BUILT	JS	BL

**DRAWING APPROVAL**

APPROVED: A. DAVEY DATE: 02/28/17 SIGNATURE:

**AS BUILT**

**PWTech**  
 Process Wastewater Technologies, LLC  
 9004 Yellow Brick Road, Suite D  
 Rosedale, Maryland 21237  
 Tel. 410.238.7977  
 Fax 410.238.7559  
 www.PWTech.us

**DRAWING TITLE:**  
 VOLUTE ES131 DEWATERING PRESS  
 CONNECTIONS AND COMPONENTS

**PROJECT TITLE:**  
 CONCANNON VINEYARD  
 LIVERMORE VALLEY, CA.

PWT PROJECT NO:	SCALE:	SHEET SIZE:
VDP-CA16116	NTS	11 X 17
DRAWING NO:	SHEET:	REV:
20170228 VDP-CA16116-ES131S-AB	5 OF 5	A

**CONNECTIONS AND COMPONENTS**

**DIMENSIONS: MM [INCH]**

## Tab 3: Main Electrical Components

- Control Panel Data Sheet
- Electrical Drawings
- Altivar Adjustable Speed Drives
- ASCO Solenoid Valve
- GTR Drum & Mixing Tank Gearmotor
- Programmable Logic Controller
- Ametek Level Sensor





517 Commercial Drive  
Fairfield, Ohio 45014  
p/888.874.2062 f/513.874.2099  
w/www.controlinterface.com

**Panel** J-978-1  
**Status** As Builts - Ship  
**Date** 22 Feb 2017

# Data sheet

## Panel Data

**Name** Press Control Panel  
**Desc**  
**Supply** 460/480V  
**Phase** 3 Phase, 3 Wire, (No Ntrl)  
**Control** Dual 24V-115/120V  
**FLA** 7.50  
**SCCR** 10k RMS Sym; 460/480V Max

## Job Data

**Name** Concannon Winery  
**Desc**  
**Created** 09 Nov 2016  
**Loc** CA  
**Loc #**  
**Client** Process Wastewater Technologies  
**Client #** VDPCA16116

## Motor Data

Name	Model	Qty	HP	Volt	Phase	FLA	AWG
Sludge Pump	STD	1	1	460	3	2.1	12
Dewatering Drum	STD	1	0.125	460	3	0.29	12
Flash Mixer	STD	1	0.125	460	3	0.29	12
Floc Mixer	STD	1	0.125	460	3	0.29	12

## Control Panel

Qty	Name	Manufacturer	Number	Description
1	Breaker	Square D	HDL36015	600V 15A 3P 25k/18k/14k AIC
1	Breaker Lugs	Square D	PDC6HD6	6-#14-#6 AWG H Frame
1	Breaker Oper Shaft	Square D	9421LS8	6-8 IN
1	Breaker Operator	Square D	9421LC43	3" Handle NEMA 4X CHROME PLATED
1	Breaker Operator	Square D	9421LJ7	Mech H/J Frame
2	Contact	Square D	9001KA1	30MM NO/NC Fingersafe
1	Contact	Square D	9001KA3	30MM NC Fingersafe
1	Contact - Aux	Square D	LADN40	IEC 4 NO
1	DC Drive	Dart Controls	125DV-C	115/120V 0.5HP 90VDC 6.5A
1	Dist Block	Marathon	1422570	600V 175A 2P (1-4)
1	Enclosure	Hoffman	A48H248SSLP3PT	48X24X8 NEMA 4X ***CUSTOM Enclosure*** Hoffman Ref #573CC
1	Enclosure - Handle	Hoffman	CWHNL	Non-Locking
1	Fan	Hoffman	A4AXFN	115/120V 4 IN Panel Fan
1	Fan/Bracket	Hoffman	ABRKT4	4 IN Fan Bracket
1	Flasher	Ingram Products	SSF150W	115/120V 150WATT Inline
5	Fuse	Bussman	AGC-1	250V 1A Non-Time-Del Glass
1	Fuse	Bussman	AGC-1/2	250V 0.5A Non-Time-Del Glass
7	Fuse	Bussman	AGC-2	250V 2A Non-Time-Del Glass
1	Fuse	Bussman	AGC-8	250V 8A Non-Time-Del Glass
1	Fuse	Bussman	FNQ-20	500V 20A Time-Dly Midget
2	Fuse	Bussman	FNQ-R-10	600V 10A Time-Dly Class CC

9	Fuse	Bussman	KTK-R-3	600V 3A Fast-Act Class CC
3	Fuse	Bussman	KTK-R-6	600V 6A Fast-Act Class CC
9	Fuse Block	Allen Bradley	1492-H4	115/120V 15A 1P Disconnect
5	Fuse Block	Allen Bradley	1492-H5	24V 12A 1P Disconnect
1	Fuse Block	Marathon	6SM30A1I	600V 30A 1P Midget Rail Mnt Trip Ind
1	Fuse Block	Marathon	6SM30A2I	600V 30A 2P Midget Rail Mnt Trip Ind
4	Fuse Block	Marathon	6SM30A3I	600V 30A 3P Midget Rail Mnt Trip Ind
2	Ground Lug	Square D	PK7GTA	#14-2/0 Ground Bar
1	Light	Ingram Products	LX40F	Top Mount With Flasher
1	Light - Pilot	Square D	9001SKP38LGG9	115/120V NEMA 4X LED Green
1	Light - Pilot	Square D	9001SKP38LWW9	115/120V NEMA 4X LED White
1	Operator - PB	Square D	9001SKR9P1R	30MM NEMA 4X III Push-Pull Red
1	Operator - SW	Misc Supply	7343K751	2 Pos SPDT 15A ON ON Toggle Quick Disconnect
1	Operator - SW	Square D	9001SKS46B	30MM NEMA 4X 3 POS Cam F
1	PLC - Base Unit	Unitronics	V700-T20BJ	24VDC 7 inch NEMA 4X Indoor Vision 700 800x480 Color HMI
1	PLC - I/O Module	Unitronics	V200-18-E3XB	24VDC 37 Dig/8 Alg Vision Snap-In Combo Block
1	PLC - Network	Square D	LU9GC3	Modbus Hub 10 Port
4	PLC - Network	Square D	VW3A8306R10	1M RS 485 Cable 2xRJ45 Connectors
1	PLC - Network	Square D	VW3A8306R30	3M RS 485 Cable 2xRJ45 Connectors
1	PLC - Network	Square D	VW3A8306RC	Modbus Terminator RJ45 120 ohm
1	PLC - Network	Unitronics	V100-17-RS4X	Vision 700 Isolated RS232/485 Port
1	PLC - SD Card	Standard	STD	Micro SD
1	Panel	Hoffman	A48P24	48X24 Steel
1	Power Supply	Puls	ML60.241	24VDC 2.5A (60W) Din Rail Mount
5	Relay	Idec	RH2B-ULAC120V	115/120V 2P 8 Mini Blade Light
2	Relay	Idec	RH3B-ULAC120V	115/120V 3P 11 Mini Blade Light
1	Relay - Industrial	Square D	CAD50G7	115/120V 5 NO IEC
1	Relay - Seal	Diversified Electronics	SPM-120-AAA-100K	115/120V 2P 11 Pin
5	Socket	Idec	SH2B-05	300V 2P 8 Mini Blade
2	Socket	Idec	SH3B-05	300V 3P 11 Mini Blade
1	Socket	Idec	SR3P-06	300V 3P 11 Pin
1	Tags	Pinnacle Industrial Engraving	W/B 4.5X4 LEGEND PLATE	4.5 X 4 Engraved Legend Plate 11 Lines
28	Term Block	Square D	NSYTRV42	600V 30A 26-10AWG Gray 6mm
18	Term Block	Square D	NSYTRV42BL	600V 30A 26-10AWG Blue 6mm
4	Term Block	Square D	NSYTRV62	600V 50A 24-8AWG Gray 8mm
3	Term End Anchor	Square D	NSYTRAABV35	Gray
6	Term End Barrier	Square D	NSYTRAP22	Gray Partition For 2.5-10mm Width TBs
1	Thermostat	Pfannenburg	17121000010	NO
1	Time Meter	Redington Counters	710-0002	115/120V 99,999.9 Hrs Non-Reset
3	Variable Frequency Drive	Square D	ATV320U04N4C	380-500V 3PH 1.6A in / 1.5A out 0.5HP (0.37kW) Altivar 320 Compact
1	Variable Frequency Drive	Square D	ATV320U07N4C	380-500V 3PH 2.8A in / 2.3A out 1HP (0.75kW) Altivar 320 Compact
1	Vent	Stahlin	BV4XKIT	NEMA 4X Breather
1	Window Kit	Hoffman	AWDH2016N4SS	20X16 316 Stainless Steel Deep Hinged

**Remote Mounted**












---

<b>Qty</b>	<b>Name</b>	<b>Manufacturer</b>	<b>Number</b>	<b>Description</b>
2	Electrode	Ametek	6013-SS-P-A-1	115/120V 1' Stainless Rod; PVC Insulated
1	Electrode Holder	Ametek	6012AE2	115/120V 2 Pole Electrode, w/ WaterProof Cover
1	Transformer	Square D	2S1FSS	240/480V 2 KVA 120V Sec SS Dry Type

**Spare Parts**

---

<b>Qty</b>	<b>Name</b>	<b>Manufacturer</b>	<b>Number</b>	<b>Description</b>
2	Fuse	Bussman	AGC-1	250V 1A Non-Time-Del Glass
2	Fuse	Bussman	AGC-1/2	250V 0.5A Non-Time-Del Glass
2	Fuse	Bussman	AGC-2	250V 2A Non-Time-Del Glass
2	Fuse	Bussman	AGC-8	250V 8A Non-Time-Del Glass
2	Fuse	Bussman	FNQ-20	500V 20A Time-Dly Midget
2	Fuse	Bussman	FNQ-R-10	600V 10A Time-Dly Class CC
3	Fuse	Bussman	KTK-R-3	600V 3A Fast-Act Class CC
3	Fuse	Bussman	KTK-R-6	600V 6A Fast-Act Class CC



CONTROL INTERFACE, INC.  
517 Commercial Drive  
Fairfield, OH 45014  
p/888.874.2062 f/513.874.2099  
www.controlinterface.com

The information in this document is the property of Control Interface, Inc. It is not to be copied, transmitted to others or used without permission from Control Interface, Inc. Recipient agrees to these conditions by acceptance of this document.

NOTES



REVISIONS

CLIENT	Process Wastewater Technologies	
CLIENT REF	VDPCA16116	
LOCATION	CA	
DRAWN BY	C Ingram	CHECKED BY
		M Rolfert





JOB	Concannon Winery	
PANEL	Press Control Panel	
DWG	J-978-1A	
STATUS	As Builts - Ship	DATE
		22 Feb 2017





CONTROL INTERFACE, INC.  
 517 Commercial Drive  
 Fairfield, OH 45014  
 p/888.874.2062 f/513.874.2099  
 www.controlinterface.com

The information in this document is the property of Control Interface, Inc. It is not to be copied, transmitted to others or used without permission from Control Interface, Inc. Recipient agrees to these conditions by acceptance of this document.


NOTES



TERMINAL BLOCK LAYOUT




NETWORKING LAYOUT



- (1) MODBUS SH-TP CABLE: RJ-11 PINS 1(+), 6(-) TO RJ-45 PINS 4(+), 5(-)
- (2) MODBUS SH-TP CABLE: RJ-45 PINS 4(+), 5(-), 8(GND)
- (3) CAT 5e CABLE - SUPPLIED BY OTHERS

POLYMER INTERCONNECTION



\*\*\* POLYMER TERMINALS SHOWN MAY NOT MATCH JUNCTION BOX LAYOUT

REVISIONS

CLIENT	Process Wastewater Technologies
CLIENT REF	VDPCA16116
LOCATION	CA
DRAWN BY	C Ingram
CHECKED BY	M Rolfert

JOB	Concannon Winery
PANEL	Press Control Panel
DWG	J-978-1B
STATUS	As Builts - Ship
DATE	22 Feb 2017



## **Volute Dewatering Press – Concannon Winery – Modbus Registers**

Modbus TCP available at the PLC for SCADA communication. IP address can be set from the HMI screen.

Memory Integers (16 bit) are addresses in the Unitronics PLC as MI 0 – 4095. SCADA software may need to add 40000 or 40001 to this address. Modbus function Read Holding Registers is supported.

### 2001 = Status Word 1

- bit 0: Panel ESTOP Switch
- bit 1: Panel Switch in Manual
- bit 2: Panel Switch in Auto
- bit 3: Running in Auto
- bit 4: Drums Running in Extended Run (Sludge Feed, Polymer and Mixers off)
- bit 5: Any Device Running in Manual
- bit 6: Press Auto Alarm Shutdown
- bit 7: Remote Start Signal Present
- bit 8: Cake Bin Full Signal Present

2002 = Status Word 2 (future)

### 2003 = Alarm Word 1

- bit 0: Panel ESTOP
- bit 1: Floc Tank High Level
- bit 2: Feed Low Flow
- bit 3: Feed High Flow
- bit 4: Flow Meter Signal Loss
- bit 5: Polymer Low Flow
- bit 6: Polymer Low Pressure
- bit 7: Cake Bin Full

### 2004 = Alarm Word 2

- bit 0: Feed Pump VFD Fault
- bit 1: Flash Mixer VFD Fault
- bit 2: Floc Mixer VFD Fault
- bit 3: Drum VFD Fault
- bit 4: Feed Pump VFD Comm Loss
- bit 5: Flash Mixer VFD Comm Loss
- bit 6: Floc Mixer VFD Comm Loss
- bit 7: Drum VFD Comm Loss

2005 = 1 second tick (from PLC clock) – Use to verify communication

2006 = Sludge Flow Rate (1 = 0.1 gpm)

2007 = Sludge Feed Pump Speed (VFD Output; 1 = 0.1 Hz)

2008 = Polymer Speed (1 = 0.1 %)

2009 = Drum Speed in Auto (VFD Output; 1 = 0.1 Hz) (highest speed if the two drums are different)

2010 = This Auto Run ETM (double word; 1 = 0.01 hr)

2012 = This Auto Run Flow Total (double word ; 1 = 1 gal)

2014 = Today's Flow Total (double word ; 1 = 1 gal)

2016 = Yesterday's Flow Total (double word ; 1 = 1 gal)

2018 = Lifetime Flow Total (double word ; 1 = 1 gal)

# Altivar Machine ATV320

## Variable Speed Drives for Asynchronous and Synchronous Motors

### Programming Manual

03/2016





---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2016 Schneider Electric. All rights reserved.

# Table of Contents




	<b>Safety Information</b> .....	<b>7</b>
	<b>About the Book</b> .....	<b>11</b>
	<b>General Overview</b> .....	<b>15</b>
<b>Chapter 1</b>	<b>Overview</b> .....	<b>17</b>
	Factory configuration .....	<b>18</b>
	Application functions .....	<b>19</b>
	Basic functions .....	<b>23</b>
	Graphic display terminal option .....	<b>24</b>
	Powering up the drive for the first time .....	<b>27</b>
	Remote display terminal option .....	<b>30</b>
	Structure of the parameter tables .....	<b>31</b>
	Finding a parameter in this document .....	<b>32</b>
	Description of the HMI .....	<b>33</b>
	Structure of the menus .....	<b>35</b>
<b>Chapter 2</b>	<b>Setup</b> .....	<b>37</b>
	Steps for setting-up the drive .....	<b>38</b>
	Initial steps .....	<b>39</b>
	<b>Programming</b> .....	<b>41</b>
<b>Chapter 3</b>	<b>Reference Mode (rEF)</b> .....	<b>43</b>
	Introduction .....	<b>44</b>
	Organization tree .....	<b>45</b>
	Menu .....	<b>46</b>
<b>Chapter 4</b>	<b>Monitoring Mode (MOn)</b> .....	<b>47</b>
	Introduction .....	<b>48</b>
	Organization tree .....	<b>49</b>
	Menu .....	<b>50</b>
	[MONIT. MOTOR] .....	<b>50</b>
	[I/O MAP] .....	<b>51</b>
	[MONIT. SAFETY] .....	<b>54</b>
	[MONIT. FUN. BLOCKS] .....	<b>55</b>
	[COMMUNICATION MAP] .....	<b>56</b>
	[MONIT. PI] .....	<b>62</b>
	[MONIT. POWER TIME] .....	<b>62</b>
	[ALARMS] .....	<b>63</b>
	[OTHER STATE] .....	<b>64</b>
	[DIAGNOSTICS] .....	<b>64</b>
	[PASSWORD] .....	<b>75</b>
<b>Chapter 5</b>	<b>Configuration Mode (ConF)</b> .....	<b>77</b>
	Introduction .....	<b>78</b>
	Organization tree .....	<b>79</b>
	My Menu .....	<b>80</b>

Factory Settings	81
Macro Configuration	82
Full	85
[SIMPLY START]	85
[SETTINGS]	89
[MOTOR CONTROL]	105
[INPUTS / OUTPUTS CFG]	125
[COMMAND]	154
[FUNCTION BLOCKS]	158
[APPLICATION FUNCT.] (FU <sub>n</sub> -)	162
REFERENCE SWITCHING	167
REFERENCE OPERATIONS	168
RAMP	170
STOP CONFIGURATION	173
AUTO DC INJECTION	176
JOG	178
PRESET SPEEDS	180
+/- SPEED	184
+/- SPEED AROUND A REFERENCE	186
REFERENCE MEMORIZING	188
FLUXING BY LOGIC INPUT	189
BRAKE LOGIC CONTROL	191
EXTERNAL WEIGHT MEASUREMENT	199
HIGH SPEED HOISTING	201
PID REGULATOR	206
PID PRESET REFERENCES	214
TORQUE LIMITATION	215
2ND CURRENT LIMITATION	218
DYN CURRENT LIMIT	219
LINE CONTACTOR COMMAND	220
OUTPUT CONTACTOR COMMAND	222
POSITIONING BY SENSORS	224
PARAMETER SET SWITCHING	229
MULTIMOTORS / MULTICONFIGURATIONS	232
AUTO TUNING BY LOGIC INPUT	236
TRAVERSE CONTROL	237
[COMMUNICATION]	275
Access Level	278
<b>Chapter 6</b>	
<b>Interface (ItF)</b>	279
Access Level (LAC)	280
Language (LnG)	282
Monitoring Configuration (MCF)	283
Display configuration (dCF)	287
<b>Chapter 7</b>	
<b>Open / Save as (trA)</b>	295
<b>Chapter 8</b>	
<b>Password (COd)</b>	299
<b>Chapter 9</b>	
<b>Multipoint Screen</b>	301
<b>Maintenance and Diagnostics</b>	303
<b>Chapter 10</b>	
<b>Maintenance</b>	305
<b>Chapter 11</b>	
<b>Diagnostics and Troubleshooting</b>	307
Error code	308
Clearing the detected fault	308
Fault detection codes which require a power reset after the detected fault is cleared	309
Fault detection codes that can be cleared with the automatic restart function after the cause has disappeared	311

	Fault detection codes that are cleared as soon as their cause disappears .....	314
	Option card changed or removed .....	314
	Control block changed .....	314
	Fault detection codes displayed on the remote display terminal .....	315
	<b>Annex .....</b>	<b>317</b>
<b>Chapter 12</b>	<b>Index of Functions .....</b>	<b>319</b>
<b>Chapter 13</b>	<b>Index of Parameter Codes .....</b>	<b>321</b>
<b>Chapter 14</b>	<b>Glossary .....</b>	<b>341</b>



## Safety Information



### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates a hazardous situation, which, if not avoided, **will result** in death or serious injury.

### **WARNING**

**WARNING** indicates a hazardous situation, which, if not avoided, **could result** in death, serious injury, or equipment damage.

### **CAUTION**

**CAUTION** indicates a potentially hazardous situation, which, if not avoided, **could result** in minor or moderate injury, or equipment damage.

### **NOTICE**

**NOTICE** is used to address practices not related to physical injury.

**PLEASE NOTE**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

**Qualification Of Personnel**

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product. In addition, these persons must have received safety training to recognize and avoid hazards involved. These persons must have sufficient technical training, knowledge and experience and be able to foresee and detect potential hazards that may be caused by using the product, by changing the settings and by the mechanical, electrical and electronic equipment of the entire system in which the product is used. All persons working on and with the product must be fully familiar with all applicable standards, directives, and accident prevention regulations when performing such work.

**Intended Use**

This product is a drive for three-phase synchronous and asynchronous motors and intended for industrial use according to this manual. The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements and the technical data. Prior to using the product, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety measures must be implemented. Since the product is used as a component in an entire system, you must ensure the safety of persons by means of the design of this entire system (for example, machine design). Any use other than the use explicitly permitted is prohibited and can result in hazards. Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.

**Product related information**

**Read and understand these instructions before performing any procedure with this drive.**

 **DANGER**
**HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation and who have received safety training to recognize and avoid hazards involved are authorized to work on and with this drive system. Installation, adjustment, repair and maintenance must be performed by qualified personnel.
- The system integrator is responsible for compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Many components of the product, including the printed circuit boards, operate with mains voltage. Do not touch. Use only electrically insulated tools.
- Do not touch unshielded components or terminals with voltage present.
- Motors can generate voltage when the shaft is rotated. Prior to performing any type of work on the drive system, block the motor shaft to prevent rotation.
- AC voltage can couple voltage to unused conductors in the motor cable. Insulate both ends of unused conductors of the motor cable.
- Do not short across the DC bus terminals or the DC bus capacitors or the braking resistor terminals.
- Before performing work on the drive system:
  - Disconnect all power, including external control power that may be present.
  - Place a "Do Not Turn On" label on all power switches.
  - Lock all power switches in the open position.
  - Wait 15 minutes to allow the DC bus capacitors to discharge. The DC bus LED is not an indicator of the absence of DC bus voltage that can exceed 800 Vdc.
  - Measure the voltage on the DC bus between the DC bus terminals (PA/+ and PC/-) using a properly rated voltmeter to verify that the voltage is <42 Vdc.
  - If the DC bus capacitors do not discharge properly, contact your local Schneider Electric representative. Do not repair or operate the product.
- Install and close all covers before applying voltage.

**Failure to follow these instructions will result in death or serious injury.**

Drive systems may perform unexpected movements because of incorrect wiring, incorrect settings, incorrect data or other errors.

## **WARNING**

### **UNEXPECTED EQUIPMENT OPERATION**

- Carefully install the wiring in accordance with the EMC requirements.
- Do not operate the product with unknown or unsuitable settings or data.
- Perform a comprehensive commissioning test.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Damaged products or accessories may cause electric shock or unanticipated equipment operation.

## **DANGER**

### **ELECTRIC SHOCK OR UNANTICIPATED EQUIPMENT OPERATION**

Do not use damaged products or accessories.

**Failure to follow these instructions will result in death or serious injury.**

Contact your local Schneider Electric sales office if you detect any damage whatsoever.

## **WARNING**

### **LOSS OF CONTROL**

- The designer of any control scheme must consider the potential failure modes of control paths and, for critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines.<sup>1</sup>
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

1. For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems".

## **NOTICE**

### **DESTRUCTION DUE TO INCORRECT MAINS VOLTAGE**

- Before switching on and configuring the product, verify that it is approved for the mains voltage.

**Failure to follow these instructions can result in equipment damage.**



**⚠ WARNING****HOT SURFACES**

- Ensure that any contact with hot surfaces is avoided.
- Do not allow flammable or heat-sensitive parts in the immediate vicinity of hot surfaces.
- Verify that the product has sufficiently cooled down before handling it.
- Verify that the heat dissipation is sufficient by performing a test run under maximum load conditions


**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**⚠ WARNING****EXPLOSION HAZARD**

Only use this device outside of hazardous areas (explosive atmospheres).

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

## About the Book



### At a Glance

#### Document scope

The purpose of this document is to:

- help you to set-up the drive,
- show you how to program the drive,
- show you the different menus, modes and parameters,
- help you in maintenance and diagnostics.

#### Validity note

**NOTE:** The products listed in the document are not all available at the time of publication of this document online. The data, illustrations and product specifications listed in the guide will be completed and updated as the product availabilities evolve. Updates to the guide will be available for download once products are released on the market.

This documentation is valid for the Altivar Machine drive.

The technical characteristics of the devices described in this document also appear online. To access this information online:

Step	Action
1	Go to the Schneider Electric home page <a href="http://www.schneider-electric.com">www.schneider-electric.com</a> .
2	In the Search box type the reference of a product or the name of a product range. <ul style="list-style-type: none"> <li>• Do not include blank spaces in the reference or product range.</li> <li>• To get information on grouping similar modules, use asterisks (*).</li> </ul>
3	If you entered a reference, go to the <b>Product Datasheets</b> search results and click on the reference that interests you. If you entered the name of a product range, go to the <b>Product Ranges</b> search results and click on the product range that interests you.
4	If more than one reference appears in the <b>Products</b> search results, click on the reference that interests you.
5	Depending on the size of your screen, you may need to scroll down to see the data sheet.
6	To save or print a data sheet as a .pdf file, click <b>Download XXX</b> product datasheet.

The characteristics that are presented in this manual should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the manual and online information, use the online information as your reference.

## Related documents

Use your tablet or your PC to quickly access detailed and comprehensive information on all our products on [www.schneider-electric.com](http://www.schneider-electric.com).

The internet site provides the information you need for products and solutions

- The whole catalog for detailed characteristics and selection guides
- The CAD files to help design your installation, available in over 20 different file formats
- All software and firmware to maintain your installation up to date
- A large quantity of White Papers, Environment documents, Application solutions, Specifications... to gain a better understanding of our electrical systems and equipment or automation
- And finally all the User Guides related to your drive, listed below:

Title of Documentation	Reference Number
ATV320 Getting Started	<a href="#">NVE21763 (English)</a> , <a href="#">NVE21771 (French)</a> , <a href="#">NVE21772 (German)</a> , <a href="#">NVE21773 (Spanish)</a> , <a href="#">NVE21774 (Italian)</a> , <a href="#">NVE21776 (Chinese)</a>
ATV320 Getting Started Annex (SCCR)	<a href="#">NVE21777 (English)</a>
ATV320 Installation manual	<a href="#">NVE41289 (English)</a> , <a href="#">NVE41290 (French)</a> , <a href="#">NVE41291 (German)</a> , <a href="#">NVE41292 (Spanish)</a> , <a href="#">NVE41293 (Italian)</a> , <a href="#">NVE41294 (Chinese)</a>
ATV320 Programming manual	<a href="#">NVE41295 (English)</a> , <a href="#">NVE41296 (French)</a> , <a href="#">NVE41297 (German)</a> , <a href="#">NVE41298 (Spanish)</a> , <a href="#">NVE41299 (Italian)</a> , <a href="#">NVE41300 (Chinese)</a>
ATV320 Modbus Serial Link manual	<a href="#">NVE41308 (English)</a>
ATV320 Ethernet IP/Modbus TCP manual	<a href="#">NVE41313 (English)</a>
ATV320 PROFIBUS DP manual (VW3A3607)	<a href="#">NVE41310 (English)</a>
ATV320 DeviceNet manual (VW3A3609)	<a href="#">NVE41314 (English)</a>
ATV320 CANopen manual (VW3A3608, 618, 628)	<a href="#">NVE41309 (English)</a>
ATV320 EtherCAT manual (VW3A3601)	<a href="#">NVE41315 (English)</a>
ATV320 Communication Parameters	<a href="#">NVE41316 (English)</a>
ATV320 Safety Functions manual	<a href="#">NVE50467 (English)</a> , <a href="#">NVE50468 (French)</a> , <a href="#">NVE50469 (German)</a> , <a href="#">NVE50470 (Spanish)</a> , <a href="#">NVE50472 (Italian)</a> , <a href="#">NVE50473 (Chinese)</a>

You can download these technical publications and other technical information from our website at <http://download.schneider-electric.com>

## Terminology

The technical terms, terminology, and the corresponding descriptions in this manual normally use the terms or definitions in the relevant standards.

In the area of drive systems this includes, but is not limited to, terms such as **error, error message, failure, fault, fault reset, protection, safe state, safety function, warning, warning message**, and so on.

Among others, these standards include:

- IEC 61800 series: Adjustable speed electrical power drive systems
- IEC 61508 Ed.2 series: Functional safety of electrical/electronic/programmable electronic safety-related
- EN 954-1 Safety of machinery - Safety related parts of control systems
- EN ISO 13849-1 & 2 Safety of machinery - Safety related parts of control systems.
- IEC 61158 series: Industrial communication networks - Fieldbus specifications
- IEC 61784 series: Industrial communication networks - Profiles
- IEC 60204-1: Safety of machinery - Electrical equipment of machines - Part 1: General requirements

In addition, the term **zone of operation** is used in conjunction with the description of specific hazards, and is defined as it is for a **hazard zone** or **danger zone** in the EC Machinery Directive (2006/42/EC) and in ISO 12100-1.

Also see the glossary at the end of this manual.



---

# General Overview



---

## What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	Overview	<a href="#">17</a>
2	Setup	<a href="#">37</a>



# Overview

# 1

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Factory configuration	<a href="#">18</a>
Application functions	<a href="#">19</a>
Basic functions	<a href="#">23</a>
Graphic display terminal option	<a href="#">24</a>
Graphic display terminal option	<a href="#">24</a>
Powering up the drive for the first time	<a href="#">27</a>
Remote display terminal option	<a href="#">30</a>
Structure of the parameter tables	<a href="#">31</a>
Finding a parameter in this document	<a href="#">32</a>
Description of the HMI	<a href="#">33</a>
Structure of the menus	<a href="#">35</a>



## Factory configuration

### Factory settings

The Altivar 320 is factory-set for common operating conditions:

- Display: drive ready **[Ready]** (*r d Y*) when motor is ready to run and the output frequency when motor is running.
- The LI3 to LI6 logic inputs, AI2 and AI3 analog inputs, LO1 logic output, AO1 analog output, and R2 relay are unassigned.
- Stop mode if error is detected: freewheel.

Code	Description	Factory settings values	Page
<i>b F r</i>	<b>[Standard mot. freq]</b>	<b>[50Hz IEC]</b>	<a href="#">86</a>
<i>l l l</i>	<b>[2/3 wire control]</b>	<b>[2 wire]</b> ( <i>l l l</i> ): 2-wire control	<a href="#">85</a>
<i>l l l</i>	<b>[Motor control type]</b>	<b>[Standard]</b> ( <i>S l d</i> ): standard motor law	<a href="#">105</a>
<i>A l l</i>	<b>[Acceleration]</b>	3.0 seconds	<a href="#">87</a>
<i>d e l</i>	<b>[Deceleration]</b>	3.0 seconds	<a href="#">87</a>
<i>L S P</i>	<b>[Low speed]</b>	0 Hz	<a href="#">87</a>
<i>H S P</i>	<b>[High speed]</b>	50 Hz	<a href="#">87</a>
<i>i t H</i>	<b>[Mot. therm. current]</b>	Nominal motor current (value depending on drive rating)	<a href="#">87</a>
<i>S d l</i>	<b>[Auto DC inj. level 1]</b>	0.7 x nominal drive current, for 0.5 seconds	<a href="#">93</a>
<i>S F r</i>	<b>[Switching freq.]</b>	4 kHz	<a href="#">94</a>
<i>F r d</i>	<b>[Forward]</b>	<b>[LI1]</b> ( <i>L i 1</i> ): Logic input LI1	<a href="#">126</a>
<i>r r S</i>	<b>[Reverse assign.]</b>	<b>[LI2]</b> ( <i>L i 2</i> ): Logic input LI2	<a href="#">126</a>
<i>F r l</i>	<b>[Ref.1 channel]</b>	<b>[AI1]</b> ( <i>A i 1</i> ): Analog input AI1	<a href="#">154</a>
<i>r l</i>	<b>[R1 Assignment]</b>	<b>[No drive fkt]</b> ( <i>F L t</i> ): The contact opens when a fault is detected or when the drive has been switched off	<a href="#">138</a>
<i>b r R</i>	<b>[Dec ramp adapt.]</b>	<b>[Yes]</b> ( <i>Y E S</i> ): Function active (automatic adaptation of deceleration ramp)	<a href="#">172</a>
<i>R l r</i>	<b>[Automatic restart]</b>	<b>[No]</b> ( <i>n o</i> ): Function inactive	<a href="#">252</a>
<i>S l l</i>	<b>[Type of stop]</b>	<b>[Ramp stop]</b> ( <i>r P P</i> ): On ramp	<a href="#">173</a>
<i>l F G</i>	<b>[Macro configuration]</b>	<b>[Start/Stop]</b> ( <i>S l S</i> )	<a href="#">82</a>

**Note:** If you want to keep the drive presettings to a minimum, select the macro configuration **[Macro configuration]** (*l F G*) = **[Start/stop]** (*S l S*) followed by **[Restore config.]** (*F l S*) = **[Config. CFG]** (*i n i*). For more information, see page [82](#).

Check whether the values above are compatible with the application.

## Application functions

The tables on the following pages show the combinations of functions and applications, in order to guide your selection.

The applications in these tables relate to the following machines, in particular:

- **Hoisting:** cranes, overhead cranes, gantries (vertical hoisting, translation, slewing), lifting platforms
- **Handling:** palletizers/depalletizers, conveyors, roller tables
- **Packing:** carton packers, labeling machines
- **Textiles:** weaving looms, carding frames, washing machines, spinners, drawing frames
- **Wood:** automatic lathes, saws, milling
- **Process**

Each machine has its own special features, and the combinations listed here are neither mandatory nor exhaustive.

Some functions are designed specifically for a particular application. In this case, the application is identified by a tab in the margin on the relevant programming pages.

## Motor control functions

Functions	Page	Applications					
		Hoisting	Handling	Packing	Textiles	Wood	Process
V/f ratio	<a href="#">105</a>		■			■	
Sensorless flux vector control	<a href="#">105</a>	■	■	■	■	■	■
2-point vector control	<a href="#">105</a>	■			■		
Open-loop synchronous motor	<a href="#">105</a>				■		
Output frequency up to 599 Hz	<a href="#">105</a>				■	■	
Motor overvoltage limiting	<a href="#">120</a>				■	■	
DC bus connection (see Installation manual)	-				■		■
Motor fluxing using a logic input	<a href="#">189</a>	■	■	■			
Switching frequency of up to 16 kHz	<a href="#">94</a>				■	■	
Auto-tuning	<a href="#">87</a>	■	■	■	■	■	■

## Functions on speed references

Functions	Page	Applications					
		Hoisting	Handling	Packing	Textiles	Wood	Process
Differential bipolar reference	<a href="#">129</a>	■	■	■			
Reference delinearization (magnifying glass effect)	<a href="#">131</a>	■	■				
Frequency control input	<a href="#">154</a>				■		■
Reference switching	<a href="#">167</a>			■			
Reference summing	<a href="#">168</a>			■			
Reference subtraction	<a href="#">168</a>			■			
Reference multiplication	<a href="#">168</a>			■			
Adjustable profile ramp	<a href="#">170</a>	■	■				
Jog operation	<a href="#">178</a>		■		■		■
Preset speeds	<a href="#">180</a>	■	■	■			
+ speed / - speed using single action pushbuttons (1 step)	<a href="#">184</a>						■
+ speed / - speed using double action pushbuttons (2 steps)	<a href="#">184</a>	■					
+/- speed around a reference	<a href="#">187</a>				■		■
Save reference	<a href="#">188</a>						■

## Application-Specific functions

Functions	Page	Applications					
		Hoisting	Handling	Packing	Textiles	Wood	Process
Fast stop	<a href="#">173</a>					■	
Brake control	<a href="#">191</a>	■	■				
Load measurement	<a href="#">199</a>	■					
High-speed hoisting	<a href="#">201</a>	■					
Rope slack	<a href="#">204</a>	■					
PID regulator	<a href="#">206</a>						■
Motor/generator torque limit	<a href="#">215</a>		■		■		■
Load sharing	<a href="#">122</a>	■	■				
Line contactor control	<a href="#">220</a>	■	■			■	
Output contactor control	<a href="#">223</a>	■					
Positioning by limit switches or sensors	<a href="#">224</a>	■	■	■			
Stop at distance calculated after deceleration limit switch	<a href="#">226</a>		■	■			
Parameter switching	<a href="#">229</a>	■	■	■	■	■	■
Motor or configuration switching	<a href="#">232</a>	■	■	■			
Traverse control	<a href="#">237</a>				■		
Stop configuration	<a href="#">173</a>		■		■	■	

## Safety functions/Fault management

Functions	Page	Applications					
		Hoisting	Handling	Packing	Textiles	Wood	Process
Safe Torque Off (STO) (Safety function, see dedicated document)	-	■	■	■	■	■	■
Deferred stop on thermal alarm	<a href="#">258</a>	■					■
Alarm handling	<a href="#">145</a>	■	■	■	■	■	■
Fault management	<a href="#">250</a>	■	■	■	■	■	■
IGBT tests	<a href="#">260</a>	■	■	■	■	■	■
Catch a spinning load	<a href="#">253</a>				■	■	
Motor protection with PTC probes	<a href="#">250</a>	■	■	■	■	■	■
Undervoltage management	<a href="#">259</a>				■	■	
4-20 mA loss	<a href="#">260</a>	■	■		■	■	■
Uncontrolled output cut (output phase loss)	<a href="#">256</a>		■				
Automatic restart	<a href="#">252</a>		■				
Use of the "Pulse input" input to measure the speed of rotation of the motor	<a href="#">265</a>	■	■				
Load variation detection	<a href="#">267</a>	■					
Underload detection	<a href="#">270</a>						■
Overload detection	<a href="#">272</a>						■
Safety Integrated functions (see related documents page <a href="#">12</a> )			■	■	■	■	■

## Basic functions


### Drive ventilation

The fan starts automatically when the drive thermal state reaches 70% of the maximum thermal state and if the **[Fan Mode]** (*F F n*) is set to **[Standard]** (*S t d*).

## Graphic display terminal option

### Description of the graphic display terminal

With the graphic display terminal, which works with FLASH V1.1IE26 or higher, it is possible to display more detailed information than can be shown on the integrated display terminal.



**Note:** Keys **3**, **4**, **5** and **6** can be used to control the drive directly, if control via the graphic display terminal is activated.

To activate the keys on the remote display terminal, you first have to configure [\[Ref.1 channel\] \(F r I\) = \[HMI\] \(L C C\)](#). For more information, see page [154](#).

**Example configuration windows:**

*Single selection*

LANGUAGE	
English	
Français	✓
Deutsch	
Italiano	
Español	
Chinese	
Русский	
Türkçe	

When powering up the graphic display terminal for the first time, the user has to select the required language.


When only one selection is possible, the selection made is indicated by ✓ .  
Example: Only one language can be chosen.

*Multiple selection*

PARAMETER SELECTION	
SETTINGS	
Ramp increment	<input checked="" type="checkbox"/>
Acceleration-----	<input checked="" type="checkbox"/>
Deceleration-----	<input type="checkbox"/>
Acceleration 2-----	<input type="checkbox"/>
Deceleration 2	
Edit	

When multiple selection is possible, the selections made are indicated by ✓ .  
Example: A number of parameters can be chosen to form the **[USER MENU]**.

**Example configuration window for one value:**



The << and >> arrows (keys F2 and F3) are used to select the digit to be modified, and the jog dial is rotated to increase or decrease this number.

**Example visualization of function blocks state:**

RDY	⊗	Term	+0.0 Hz	0.0 A
Acceleration				
9.51s				
Min = 0.00		Max = 99.99		
<<		>>		Quick

- ⊗ OFF light: A valid function blocks program is in the ATV320 in stop mode.
- ⊗ ON light: A valid function blocks program is in the ATV320 in run mode. The drive is considered as being in running state and configuration parameters cannot be modified.




**Powering up the drive with Graphic display terminal for the first time**

When powering up the graphic display terminal for the first time, the user has to select the required language.

LANGUAGE	
English	
Français	✓
Deutsch	
Italiano	
Español	
Chinese	
Русский	
Türkçe	

Display after the graphic display terminal has been powered up for the first time. Select the language and press ENT.

↓ ENT

<b>Schneider</b>	
 Electric	
<b>ATV320U15M2B</b>	
1.5kW/2HP 220V Single	
Config. n°0	

The drive's rating details will now appear.

↓ 3 seconds


RDY	Term	0.0 Hz	0.0 A
ACCESS LEVEL			
Basic			
Standard			✓
Advanced			
Expert			

↓ ENT

RDY	Term	0.0 Hz	0.0 A
1 DRIVE MENU			
1.1 SPEED REFERENCE			
1.2 MONITORING			
1.3 CONFIGURATION			
Code	<<	>>	Quick

## Powering up the drive for the first time

With the integrated display terminal, when powering up the drive for the first time, the user immediately accesses to **[Standard mot. freq]** (*b F r*) (see page 86) in the menu (CO nF > FULL > SIM).



Display after the drive has been powered up for the first time.

↓ 3 seconds

RDY	Term	0.0 Hz	0.0 A
ACCESS LEVEL			
Basic			
Standard			
Advanced			
Expert			

The **[ACCESS LEVEL]** screen follows automatically.

↓ ENT

RDY	Term	0.0 Hz	0.0 A
1 DRIVE MENU			
1.1 SPEED REFERENCE			
1.2 MONITORING			
1.3 CONFIGURATION			
Code	<<	>>	Quick

Automatically switches to the **[1 DRIVE MENU]** menu after 3 seconds. Select the menu and press ENT.


↓ ESC

MAIN MENU			
1 DRIVE MENU			
2 IDENTIFICATION			
3 INTERFACE			
4 OPEN / SAVE AS			
5 PASSWORD			

The MAIN MENU appears on the graphic display terminal if you press the ESC key.


**Subsequent power-ups**

With the integrated display terminal, at subsequent power-ups of the drive for the first time, the user immediately accesses to the drive state (Same list than [\[Drive state\] \(H 5 I\)](#) page [65](#)). Example : Ready (rdY).




Display after powering up.

↓ 3 seconds



Automatically switches to the [\[1 DRIVE MENU\]](#) menu after 3 seconds. Select the menu and press ENT.

↓ 10 seconds




Automatically switches to the monitoring screen after 10 seconds.

**Identification menu**

The **[IDENTIFICATION]** (**o d -**) menu can only be accessed on the graphic display terminal.

This is a read-only menu that cannot be configured. It enables the following information to be displayed:


- Drive reference, power rating and voltage
- Drive software version
- Drive serial number
- Safety function status and checksum
- Function blocks program and catalogue version
- Type of options present, with their software version
- Graphic display terminal type and version



## Remote display terminal option

### Description of the remote display terminal

This remote display terminal is a local control unit which can be mounted on the door of the wall-mounted or floor-standing enclosure. It has a cable with connectors, which is connected to the drive serial link (see the documentation supplied with the remote display terminal). With this remote display terminal, up and down arrows are used for navigation rather than a jog dial.



(1) If the drive is locked by a code ([PIN code 1] (Lcd) page 300), pressing the MODE key enables you to switch from the [1.2 MONITORING] (MON-) menu to the [1.1 SPEED REFERENCE] (REF-) menu and vice versa.

To activate the keys on the remote display terminal, you first have to configure [Ref.1 channel] (Frl) = [HMI] (LCL). For more information, see page 154.

### Structure of the parameter tables

The parameter tables contained in the descriptions of the various menus are organized as follows.

Example:

Parameters described in this page can be accessed by: DRI- > CONF > FULL > FUN-

Code	Name / Description	Adjustment range	Factory setting
P , d -	<b>[PID REGULATOR]</b> <small>Note: This function cannot be used with certain other functions. Follow the instructions on page 162.</small>		
P , f	<b>[PID feedback ass.]</b>		[No] (no)
no	[No] (no): Not assigned		
A I 1	[AI1] (A I 1): Analog input A1		
A I 2	[AI2] (A I 2): Analog input A2		
A I 3	[AI3] (A I 3): Analog input A3		
P ,	[RP] (P ,): Pulse input		
A I u 2	[AI virtual 2] (A I u 2): Virtual analog input 2		
o A O 1	[OA01] (o A O 1): Function blocks: Analog Output 01		
...			
o A I 0	[OA10] (o A I 0): Function blocks: Analog Output 10		

- |  |   |
|--|---|
| 1. Way to access the parameters described in this page | 5. Name of submenu on graphic display terminal    |
| 2. Submenu code on 4-digit 7-segment display           | 6. Name of parameter on graphic display terminal  |
| 3. Parameter code on 4-digit 7-segment display         | 7. Value of parameter on graphic display terminal |
| 4. Parameter value on 4-digit 7-segment display        |   |

**Note:** The text in square brackets [ ] indicates what you will see on the graphic display terminal.

A menu followed by the mention "(continued)" appears sometimes to locate you in the structure.

Example:

F u n -	<b>[APPLICATION FUNCT.] (continued)</b>
P , d -	<b>[PID REGULATOR]</b> <small>Note: This function cannot be used with certain other functions. Follow the instructions on page 162.</small>

In this case, the mention "(continued)" indicates that the [APPLICATION FUNCT.] submenu is above the [PID REGULATOR] submenu in the structure.

A parameter can contain some pictograms. Each pictogram has its legend at the end of the table.

Main mictograms:

- ★


These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.
- ↻

Parameter that can be modified during operation or when stopped.
- ⌚ 2 s

To change the assignment of this parameter, press the ENT key for 2 s.

## Finding a parameter in this document

The following assistance with finding explanations on a parameter is provided:

- With the integrated display terminal and the remote display terminal: Direct use of the parameter code index, page [321](#), to find the page giving details of the displayed parameter.
- With the graphic display terminal: Select the required parameter and press F1  : **[Code]**. The parameter code is displayed instead of its name while the key is held down.

Example: ACC

RDY	Term	+0.0 Hz	0.0 A
SETTINGS			
Ramp increment	:		0.1
Acceleration	:		9.51 s
Deceleration	:		9.67 s
Low speed	:		0.0 Hz
High speed	:		50.0 Hz
Code	<<	>>	Quick

Code  
→


RDY	Term	+0.0 Hz	0.0 A
SETTINGS			
Ramp increment	:		0.1
ACC	:		9.51 s
Deceleration	:		9.67 s
Low speed	:		0.0 Hz
High speed	:		50.0 Hz
Code	<<	>>	Quick

- Then use the parameter code index, page [321](#), to find the page giving details of the displayed parameter.

## Description of the HMI

### Functions of the Display and the Keys

- 1 The **ESC** key is used for menu navigation (backward) and parameters adjustment (cancel)
- 2 The **Jog dial** is used for menu navigation (up or down) and parameters adjustment (increase/decrease value or element choice). It can be used as Virtual analogic input 1 for drive frequency reference.
- 3 The **ENT** key (push on the Jog dial) is used for menu navigation (forward) and parameters adjustment (validate)



A	REF mode selected ( <i>r E F -</i> )	E	Dot used to display parameter value (1/10 unit)
B	MON mode selected ( <i>M o n -</i> )	F	Current display is parameter value
C	CONF mode selected ( <i>C o n F</i> )	G	Current display is parameter unit
D	Dot used to display parameter value (1/100 unit)		

#### Normal display, with no error code displayed and no startup:

Displays the parameter selected in the [1.2 MONITORING] (*M o n -*) menu (default: [Frequency ref.] (*F r H*)).


- *i n i t*: Initialization sequence (only on remote display terminal)
- *t u n*: AutoTuning
- *d C b*: Injection braking
- *r d y*: Drive ready
- *n S t*: Freewheel stop control
- *C L i*: Current limit
- *F S t*: Fast stop
- *F L u*: Fluxing function is activated
- *n L P*: Control is powered on but the DC bus is not loaded
- *C t L*: Controlled stop



- **abr**: Adapted deceleration
- **SOC**: Stand by output cut
- **USA**: Undervoltage alarm
- **SSI**: Safety function SS1
- **SLS**: Safety function SLS
- **Sto**: Safety function STO
- **SMS**: Safety function SMS
- **GDL**: Safety function GDL

In the event of a detected error, the display will flash to notify the user accordingly. If a graphic display terminal is connected, the name of the detected error will be displayed.

## Structure of the menus



On the 7-segment display, a dash after menu and submenu codes is used to differentiate them from parameter codes.

Example: [APPLICATION FUNCT.] (*F u n -*) menu, [Acceleration] (*A C C*) parameter

### Selection of multiple assignments for one parameter

Example: List of group 1 alarms in [INPUTS / OUTPUTS CFG] (*i \_ o -*) menu

A number of alarms can be selected by "checking" them as follows.

The digit on the right indicates:



The same principle is used for all multiple selections.



# Setup

# 2

## What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Steps for setting-up the drive	<a href="#">38</a>
Initial steps	<a href="#">39</a>

## Steps for setting-up the drive

# INSTALLATION

1. Please refer to the installation manual.



# PROGRAMMING

2. Apply input power to the drive, but do not give a run command.

### 3. Configure:

- The nominal frequency of the motor **[Standard mot. freq]** (*b F r*) page [86](#) if this is not 50 Hz.
- The motor parameters in the **[MOTOR CONTROL]** (*d r C -*) menu, page [105](#), only if the factory configuration of the drive is not suitable.
- The application functions in the **[INPUTS / OUTPUTS CFG]** (*i \_ o -*) menu, page [125](#), the **[COMMAND]** (*C E L -*) menu, page [154](#), and the **[APPLICATION FUNCT.]** (*F u n -*) menu, page [167](#), only if the factory configuration of the drive is not suitable.

### 4. In the **[SETTINGS]** (*S E t -*) menu, adjust the following parameters:

- **[Acceleration]** (*R C C*), page [87](#) and **[Deceleration]** (*d E C*), page [87](#).
- **[Low speed]** (*L S P*), page [87](#) and **[High speed]** (*H S P*), page [89](#).
- **[Mot. therm. current]** (*i t H*), page [87](#).

### 5. Start the drive.

### Tips:

- Before beginning programming, complete the customer setting tables, page [321](#).
- Use the **[Restore config.]** (*F C S*) parameter, page [81](#), to return to the factory settings at any time.
- To locate the description of a function quickly, use the index of functions page [319](#).
- Before configuring a function, read carefully the "Function compatibility" section page [165](#).

**Note:** The following operations must be performed for optimum drive performance in terms of accuracy and response time:

- Enter the values indicated on the motor rating plate in the **[MOTOR CONTROL]** (*d r C -*) menu, page [105](#).
- Perform auto-tuning with the motor cold and connected using the **[Auto-tuning]** (*t u n*) parameter, page [87](#).

## Initial steps

If the drive was not connected to mains for an extended period of time, the capacitors must be restored to their full performance before the motor is started.

### NOTICE

#### REDUCED CAPACITOR PERFORMANCE

- Apply mains voltage to the drive for one hour before starting the motor if the drive has not been connected to mains for the following periods of time:
  - 12 months at a maximum storage temperature of +50°C (+122°F).
  - 24 months at a maximum storage temperature of +45°C (+113°F)
  - 36 months at a maximum storage temperature of +40°C (+104°F).
- Verify that no Run command can be applied before the period of one hour has elapsed.
- Verify the date of manufacture if the drive is commissioned for the first time and run the specified procedure if the date of manufacture is more than 12 months in the past.

**Failure to follow these instructions can result in equipment damage.**

If the specified procedure cannot be performed without a Run command because of internal mains contactor control, perform this procedure with the power stage enabled, but the motor being at a standstill so that there is no appreciable mains current in the capacitors.

## Before powering up the drive

### ⚠ WARNING

#### UNANTICIPATED EQUIPMENT OPERATION

Before switching on the device, verify that no unintended signals can be applied to the digital inputs that could cause unintended movements.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

## Drive locked

If a Run command such as Run forward, Run reverse, DC injection is still active during:

- I A product reset to the factory settings,
- I A manual "Fault Reset" using **[Fault Reset] (r 5 F)**,
- I A manual "Fault reset" by applying a product switched off and on again,
- I A stop command given by a channel that is not the active channel command (such as Stop key of the display terminal in 2/3 wires control).

The drive is in a blocking state and displays **[Freewheel stop] (r 5 E)**. It will be necessary to deactivate all active Run commands prior to authorizing a new Run command.

## Mains contactor

### NOTICE

#### RISK OF DAMAGE TO THE DRIVE

Do not switch on the drive at intervals of less than 60 s.

**Failure to follow these instructions can result in equipment damage.**

### Using a motor with a lower rating or dispensing with a motor altogether

With the factory settings, motor output phase loss detection is active (**[Output Phase Loss]** (o P L) = **[Yes]** (Y E 5), page 256). To avoid having to use a motor with the same rating as the drive when testing the drive or during a maintenance phase, deactivate the motor output phase loss detection (**[Output Phase Loss]** (o P L) = **[No]** (n o)). This can prove particularly useful if very large drives are being tested with a small motor.

Set **[Motor control type]** (C t t), page 105, to **[Standard]** (5 t d) in **[Motor control menu]** (d r C -).

## NOTICE

### MOTOR OVERHEATING

Install external thermal monitoring equipment under the following conditions:

- If a motor with a nominal current of less than 20% of the nominal current of the drive is connected.
- If you use the function Motor Switching.

**Failure to follow these instructions can result in equipment damage.**

## DANGER

### HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

If output phase monitoring is disabled, phase loss and, by implication, accidental disconnection of cables, are not detected.

- Verify that the setting of this parameter does not result in unsafe conditions.

**Failure to follow these instructions will result in death or serious injury.**



## What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
4	Reference Mode (rEF)	<a href="#">43</a>
5	Monitoring Mode (MOn)	<a href="#">47</a>
6	Configuration Mode (ConF)	<a href="#">77</a>
7	Interface (ItF)	<a href="#">279</a>
8	Open / Save as (trA)	<a href="#">295</a>
9	Password (COd)	<a href="#">299</a>
10	Multipoint Screen	<a href="#">301</a>

Incorrect wiring, unsuitable settings or unsuitable data may trigger unanticipated movements, trigger signals or damage parts and disable monitoring functions.

### **WARNING**

#### **UNANTICIPATED EQUIPMENT OPERATION**

- Do not operate the drive system with unknown settings or data.
- Never modify a parameter unless you fully understand the parameter and all effects of the modification.
- When commissioning the product, carefully run tests for all operating states and potential error situations.
- Verify that a functioning emergency stop push-button is within reach of all persons involved in running tests.
- Verify the functions after replacing the product and also after making changes to the settings or data.
- Anticipate movements in unintended directions or oscillation of the motor.
- Only operate the system if there are no persons or obstructions in the zone of operation.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

If the power stage is disabled unintentionally, for example as a result of power outage, errors or functions, the motor is no longer decelerated in a controlled way.

### **WARNING**

#### **MOVEMENT WITHOUT BRAKING EFFECT**

Verify that movements without braking effect cannot cause injuries or equipment damage

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**





## Reference Mode (rEF)



# 3

---

### What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Introduction	<a href="#">44</a>
Organization tree	<a href="#">45</a>
Menu	<a href="#">46</a>

## Introduction

Use the reference mode to monitor and, if the reference channel is the analog input 1 (**[Ref.1 channel]** (FR I) page 154 set to **[AI virtual 1]** (R I I)), adjust the actual reference value by modifying the analog input voltage value.

If local control is enabled (**[Ref.1 channel]** (FR I) page 154 set to **[HMI]** (L C C)), the jog dial on the remote display terminal or the Up/Down Navigation keys on the remote display terminal acts as a potentiometer to change the reference value up and down within the limits preset by other parameters (**[Low speed]** (L S P) or **[High speed]** (H S P)).

There is no need to press the ENT key to confirm the change of the reference.

## Organization tree


(1) Depending on the active reference channel

Possible values:

- (R i u l)
- (L F r)
- (Π F r)
- (r P i)
- (F r H)
- (r P L)

(2) 2 s or ESC

Displayed parameter value and unit of the diagram are given as examples.



Parameters described in this page can be accessed by:

DRI- &gt; REF-


## Menu

Code	Name / Description	Adjustment range	Factory setting
<i>dr i -</i>	<b>[1 DRIVE MENU]</b>		
<i>rEF -</i>	<b>[1.1 SPEED REFERENCE]</b> Displayed parameters depend on drive settings.		
<i>R i u I</i> ★ ( ) (1)	<b>[Image input AIV1]</b> First virtual AI value. This parameter allows to modify the frequency reference with the embedded jog dial.	0 to 100% of HSP-LSP	0%
<i>LFr</i> ★ ( ) (1)	<b>[HMI Frequency ref.]</b> HMI frequency reference (signed value). This parameter allows to modify the frequency reference with the remote HMI.	-599 to +599 Hz	0 Hz
<i>MF r</i> ★ ( )	<b>[Multiplying coeff.]</b> Multiply frequency variable. Multiplying coefficient, can be accessed if <b>[Multiplier ref.-] (M R 2, M R 3)</b> page 169 has been assigned to the graphic terminal.	0 to 100%	100%
<i>r P i</i> ★ ( ) (1)	<b>[Internal PID ref.]</b> PID: Internal reference PI. This parameter allows to modify the PID internal reference with the jog dial. Internal PID reference is visible if <b>[PID feedback] (P i F)</b> is not set to <b>[No] (n o)</b> .	0 to 32,767	150
<i>F r H</i> ★	<b>[Frequency ref.]</b> Frequency reference before ramp (signed value). Actual frequency reference applied to the motor regardless of which reference channel has been selected. This parameter is in read-only mode. Frequency reference is visible if the command channel is not HMI or virtual AI.	-599 to +599 Hz	-
<i>r P C</i> ★	<b>[PID reference]</b> PID: Setpoint value. PID reference is visible if <b>[PID feedback] (P i F)</b> is not set to <b>[No] (n o)</b> .	0 to 65,535	-

(1) It is not necessary to press the ENT key to confirm the modification of the reference.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.

## Monitoring Mode (MOn)



# 4

---

### What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Introduction	<a href="#">48</a>
Organization tree	<a href="#">49</a>
Menu	<a href="#">50</a>

## Introduction

The parameters can be accessed when the drive is running or stopped.

Some functions have numerous parameters. In order to clarify programming and avoid having to scroll through endless parameters, these functions have been grouped in submenus. Like menus, submenus are identified by a dash after their code.

When the drive is running, the value displayed is one of the monitoring parameters. By default, the value displayed is the input frequency reference ([Frequency ref.] (F r H) parameter page 50).

While the value of the new monitoring parameter required is being displayed, press a second time on the jog dial key to display the units or press and hold down the jog dial (ENT) again (for 2 seconds) to confirm the change of monitoring parameter and store it. From then on, it is the value of this parameter that will be displayed during operation (even after powering down).


Unless the new choice is confirmed by pressing and holding down ENT again, the display will revert to the previous parameter after powering down.

**Note:** After the drive has been turned off or following a loss of supply mains, the parameter displayed is the drive status (example: [Ready] (r d Y)). The selected parameter is displayed following a run command.

## Organization tree

Displayed parameters of the diagram are given as examples.

(1) Visible only with graphic display terminal





Parameters described in this page can be accessed by:



DRI- &gt; MON-

## Menu

Code	Name / Description	Unit
<b>ПОН-</b>	<b>[1.2 MONITORING]</b>	
<b>АИВ1</b> (  )	<b>[Image input AIV1]</b> First virtual AI value. This parameter is read-only. It enables you to display the speed reference applied to the motor.	%
<b>FrH</b>	<b>[Frequency ref.]</b> Frequency reference before ramp (signed value). This parameter is read-only. It enables you to display the speed reference applied to the motor, regardless of which reference channel has been selected.	Hz
<b>StFr</b>	<b>[Stator Frequency]</b> Displays the estimated stator frequency in Hz (signed value)	Hz
<b>LFr</b>	<b>[HMI Frequency ref.]</b> HMI frequency reference (signed value). This parameter only appears if the function has been enabled. It is used to change the speed reference from the remote control. ENT does not have to be pressed to enable a change of reference.	Hz
<b>ПFr</b> ★ (  )	<b>[Multiplying coeff.]</b> Multiply frequency variable. Multiplying coefficient, can be accessed if <b>[Multiplier ref. -] (ПР2, ПР3)</b> page 169 has been assigned.	%
<b>ППФ</b>	<b>[Measured output fr.]</b> Measured motor frequency (signed value) The measured motor speed is displayed if the speed monitoring card has been inserted. (VW3A3620)	Hz
<b>rFr</b>	<b>[Output frequency]</b> Estimated motor frequency (signed value).	Hz
<b>F95</b> ★	<b>[Pulse in. work. freq.]</b> Measured frequency of the "Pulse input" input (see page 265).	Hz
<b>uLn</b>	<b>[Mains voltage]</b> Main voltage (from DC bus). Mains voltage based on DC bus measurement, motor running or stopped.	V
<b>tHr</b>	<b>[Motor thermal state]</b> Motor thermal state. 100% = Nominal thermal state, 118% = "OLF" threshold (motor overload).	%
<b>tHd</b>	<b>[Drv.thermal state]</b> Drive thermal state. 100% = Nominal thermal state, 118% = "OHF" threshold (drive overload).	%
<b>ППО-</b>	<b>[MONIT. MOTOR]</b>	
<b>SPd</b>	<b>[Motor speed]</b> Motor speed in rpm. (Estimated value)	rpm
<b>uоP</b>	<b>[Motor voltage]</b> Motor voltage. (Estimated value)	V
<b>оPr</b>	<b>[Motor power]</b> Output power monitoring (100% = nominal motor power, estimated value based on current measure).	%
<b>оtr</b>	<b>[Motor torque]</b> Output torque value (100% = nominal motor torque, estimated value based on current measure).	%
<b>LCr</b>	<b>[Motor current]</b> Estimated motor current. (Value measured)	A

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; IOM- &gt; LIA-

Code	Name / Description	Unit
<b>Π ο η -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>Π Π ο -</b>	<b>[MONIT. MOTOR]</b>	
<b>ι ρ ε η</b>	<b>[I<sup>2</sup>t overload level]</b> Monitoring of I <sup>2</sup> t overload level This parameter can be accessed if <b>[I<sup>2</sup>t model activation]</b> ( <b>ι ρ ε η</b> ) is set to <b>[Yes]</b> ( <b>υ ε 5</b> ) see page <a href="#">219</a>	%
<b>ι ο η -</b>	<b>[I/O MAP]</b>	
<b>L ι η -</b>	<b>[LOGIC INPUT CONF.]</b> Logic input functions.	
<b>L ι η</b>	<b>[LI1 assignment]</b> Read-only parameters, cannot be configured. It displays all the functions that are assigned to the logic input in order to check for multiple assignments. If no functions have been assigned, <b>[No]</b> ( <b>η ο</b> ) is displayed. Use the jog dial to scroll through the functions. The use of graphic display terminal allows to see the delay <b>[LI1 On Delay]</b> ( <b>L ι δ</b> ). Possible values are the same than in configuration menu page <a href="#">127</a> .	
<b>L ρ η</b> to <b>L β η</b> <b>L η ι η</b> <b>L η ρ η</b>	<b>[L-- assignment]</b> All the logic inputs available on the drive are processed as in the example for LI1 above.	
<b>L ι σ ι</b>	<b>[State of logic inputs LI1 to LI6]</b> Can be used to visualize the state of logic inputs LI1 to LI6 (display segment assignment: high = 1, low = 0).  Example above: LI1 and LI6 are at 1; LI2 to LI5 are at 0.	
<b>L ι σ ρ</b>	<b>[State of Safe Torque Off]</b> Can be used to visualize the state of LA1, LA2 and STO (Safe Torque Off) (display segment assignment: high = 1, low = 0).  Example above: LA1 and LA2 are at 0; STO (Safe Torque Off) is at 1.	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; IOM- &gt; AIA-

Code	Name / Description	Unit
<b>A , A -</b>	<b>[ANALOG INPUTS IMAGE]</b> Analog input functions.	
<b>A , I C</b>	<b>[AI1]</b> AI1 customer image: Value of analog input 1.	V
<b>A , I A</b>	<b>[AI1 assignment]</b> AI1 functions assignment. If no functions have been assigned, <b>[No] (n o)</b> is displayed. Following parameters are visible on the graphic display terminal by pressing the ENT key on the parameter.  <b>n o</b> <b>[No] (n o)</b> : Not assigned <b>F r 1</b> <b>[Ref.1 channel] (F r 1)</b> : Reference source 1 <b>F r 2</b> <b>[Ref.2 channel] (F r 2)</b> : Reference source 2 <b>S A 2</b> <b>[Summing ref. 2] (S A 2)</b> : Summing reference 2 <b>P , F</b> <b>[PID feedback] (P , F)</b> : PI feedback (PI control) <b>L A A</b> <b>[Torque limitation] (L A A)</b> : Torque limitation: Activation by an analog value <b>d A 2</b> <b>[Subtract. ref. 2] (d A 2)</b> : Subtracting reference 2 <b>P , n</b> <b>[Manual PID ref.] (P , n)</b> : Manual speed reference of the PI(D) regulator (auto-man) <b>F P , i</b> <b>[PID speed ref.] (F P , i)</b> : Speed reference of the PI(D) regulator (predictive reference) <b>S A 3</b> <b>[Summing ref. 3] (S A 3)</b> : Summing reference 3 <b>F r 1 b</b> <b>[Ref.1B channel] (F r 1 b)</b> : Reference source 1B <b>d A 3</b> <b>[Subtract. ref. 3] (d A 3)</b> : Subtracting reference 3 <b>F L o C</b> <b>[Forced local] (F L o C)</b> : Forced local reference source <b>n A 2</b> <b>[Ref. 2 multiplier] (n A 2)</b> : Multiplying reference 2 <b>n A 3</b> <b>[Ref. 3 multiplier] (n A 3)</b> : Multiplying reference 3 <b>P E S</b> <b>[Weight input] (P E S)</b> : External weight measurement function <b>, A 0 1</b> <b>[IA01] ( , A 0 1)</b> : Functions blocks: Analog Input 01 ... <b>, A 1 0</b> <b>[IA10] ( , A 1 0)</b> : Functions blocks: Analog Input 10	
<b>u , L 1</b>	<b>[AI1 min value]</b> Voltage scaling parameter of 0%.	V
<b>u , H 1</b>	<b>[AI1 max value]</b> Voltage scaling parameter of 100%.	V
<b>A , I F</b>	<b>[AI1 filter]</b> Interference filtering cut-off time of the low-filter.	s
<b>A L A -</b>	<b>[ANALOG INPUTS IMAGE] (continued)</b> Analog input functions.	
<b>A , I 2 C</b>	<b>[AI2]</b> AI2 customer image: Value of analog input 2.	V
<b>A , I 2 A</b>	<b>[AI2 assignment]</b> AI2 functions assignment. If no functions have been assigned, <b>[No] (n o)</b> is displayed. Following parameters are visible on the graphic display terminal by pressing the ENT key on the parameter.  Identical to <b>[AI1 assignment] (A , I A)</b> page 52.	
<b>u , L 2</b>	<b>[AI2 min value]</b> Voltage scaling parameter of 0%.	V
<b>u , H 2</b>	<b>[AI2 max value]</b> Voltage scaling parameter of 100%.	V
<b>A , I 2 F</b>	<b>[AI2 filter]</b> Interference filtering cutoff time of the low-filter.	s

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; IOM- &gt; AIA- &gt; AI3C

Code	Name / Description	Unit
<b>A , A -</b>	<b>[ANALOG INPUTS IMAGE] (continued)</b> Analog input functions.	
<b>A , 3 C</b>	<b>[AI3]</b> AI3 customer image: Value of analog input 3.	V
<b>A , 3 A</b>	<b>[AI3 assignment]</b> AI3 functions assignment. If no functions have been assigned, <b>[No] (n o)</b> is displayed. Following parameters are visible on the graphic display terminal by pressing the ENT key on the parameter.  Identical to <b>[AI1 assignment] (A , 1 A)</b> page <a href="#">52</a> .	
<b>C r L 3</b>	<b>[AI3 min value]</b> Current scaling parameter of 0%.	mA
<b>C r H 3</b>	<b>[AI3 max value]</b> Current scaling parameter of 100%.	mA
<b>A , 3 F</b>	<b>[AI3 filter]</b> Interference filtering cutoff time of the low-filter.	s
<b>I O Π -</b>	<b>[I/O MAP] (continued)</b>	
<b>A o A -</b>	<b>[ANALOG OUTPUTS IMAGE]</b> Analog output functions. Following parameters are visible on the graphic display terminal by pressing the ENT key on the parameter.	
<b>A o 1 C</b> <b>( )</b>	<b>[AO1C]</b> AO1 customer image: Value of analog output 1.	
<b>A o 1</b>	<b>[AO1 assignment]</b> AO1 functions assignment. If no functions have been assigned, <b>[No] (n o)</b> is displayed.  Identical to <b>[AO1 assignment] (A o 1)</b> page <a href="#">144</a> .	
<b>u o L 1</b> <b>★</b>	<b>[AO1 min Output]</b> Voltage scaling parameter of 0%. Can be accessed if <b>[AO1 Type] (A o 1 E)</b> is set to <b>[Voltage] ( I O u )</b> .	V
<b>u o H 1</b> <b>★</b>	<b>[AO1 max Output]</b> Voltage scaling parameter of 100%. Can be accessed if <b>[AO1 Type] (A o 1 E)</b> is set to <b>[Voltage] ( I O u )</b> .	V
<b>A o L 1</b> <b>★</b>	<b>[AO1 min output]</b> Current scaling parameter of 0%. Can be accessed if <b>[AO1 Type] (A o 1 E)</b> is set to <b>[Current] ( O A )</b> .	mA
<b>A o H 1</b> <b>★</b>	<b>[AO1 max output]</b> Current scaling parameter of 100%. Can be accessed if <b>[AO1 Type] (A o 1 E)</b> is set to <b>[Current] ( O A )</b> .	mA
<b>A 5 L 1</b>	<b>[Scaling AO1 max]</b> Minimum scaling value for AO1.	%
<b>A 5 H 1</b>	<b>[Scaling AO1 min]</b> Maximum scaling value for AO1.	%
<b>A o 1 F</b>	<b>[AO1 filter]</b> Cutoff time of the low-filter.	s

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; IOM- &gt; FSI-

Code	Name / Description	Unit
<b>I O M -</b>	<b>[I/O MAP] (continued)</b>	
<b>F S I -</b>	<b>[FREQ. SIGNAL IMAGE]</b> Frequency signal image. This menu is visible only on graphic display terminal.	
<b>P F r C</b>	<b>[RP input]</b> Filtered customer pulse input frequency reference. Following parameters are visible on the graphic display terminal by pressing the ENT key on the parameter.	Hz
<b>P , A</b>	<b>[RP assignment]</b> Pulse input assignment. If no functions have been assigned, <b>[No] (n o)</b> is displayed.  Identical to <b>[A1 assignment] (A , I A)</b> page 52.	
<b>P , L</b>	<b>[RP min value]</b> RP minimum value. Pulse input scaling parameter of 0%.	kHz
<b>P F r</b>	<b>[RP max value]</b> RP maximum value Pulse input scaling parameter of 100%.	kHz
<b>P F i</b>	<b>[RP filter]</b> Interference filtering pulse input cutoff time of the low-filter.	ms
<b>M o n -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>S A F -</b>	<b>[MONIT. SAFETY]</b> For more details on Integrated Safety Functions, please refer to dedicated Safety manual.	
<b>S t o S</b>	<b>[STO status]</b> Status of the Safe Torque Off safety function.	
<b>i d L E</b>	<b>[Idle] ( i d L E)</b> : STO not in progress	
<b>S t o</b>	<b>[Safe stop] ( S t o)</b> : STO in progress	
<b>F L t</b>	<b>[Fault] ( F L t)</b> : STO error detected	
<b>S L S S</b>	<b>[SLS status]</b> Status of the Safely-limited speed safety function.	
<b>n o</b>	<b>[Not config.] ( n o)</b> : SLS not configured	
<b>i d L E</b>	<b>[Idle] ( i d L E)</b> : SLS not in progress	
<b>W A i t</b>	<b>[SLS wait time] ( W A i t)</b> : SLS waiting for activation	
<b>S t r t</b>	<b>[SLS start] ( S t r t)</b> : SLS in transient state	
<b>S S I</b>	<b>[Safe ramp] ( S S I)</b> : SLS ramp in progress	
<b>S L S</b>	<b>[Spd limited] ( S L S)</b> : SLS speed limitation in progress	
<b>S t o</b>	<b>[Safe stop] ( S t o)</b> : SLS safe torque off request in progress	
<b>F L t</b>	<b>[Fault] ( F L t)</b> : SLS error detected	
<b>S S I S</b>	<b>[SS1 status]</b> Status of the Safe Stop 1 safety function.	
<b>n o</b>	<b>[Not config.] ( n o)</b> : SS1 not configured	
<b>i d L E</b>	<b>[Idle] ( i d L E)</b> : SS1 not in progress	
<b>S S I</b>	<b>[Safe ramp] ( S S I)</b> : SS1 ramp in progress	
<b>S t o</b>	<b>[Safe stop] ( S t o)</b> : SS1 safe torque off request in progress	
<b>F L t</b>	<b>[Fault] ( F L t)</b> : SS1 error detected	
<b>S M S S</b>	<b>[SMS status]</b> Status of the Safe Maximum Speed safety function.	
<b>n o</b>	<b>[Not Set] ( n o)</b> : SMS not set	
<b>o F F</b>	<b>[Active] ( o F F)</b> : SMS active	
<b>F t i</b>	<b>[Internal Err.] ( F t i)</b> : SMS internal error	
<b>F t o</b>	<b>[Max Speed] ( F t o)</b> : Maximum Speed reached	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; SAF-

Code	Name / Description	Unit
<b>G d L S</b>	<b>[GDL status]</b> Status of the Guard Door Locking safety function.  <b>no</b> <b>[Not Set]</b> ( <b>no</b> ): GDL not set <b>oFF</b> <b>[Inactive]</b> ( <b>oFF</b> ): GDL inactive <b>S t d</b> <b>[Short Delay]</b> ( <b>S t d</b> ): Short Delay In Progress <b>L G d</b> <b>[Long Delay]</b> ( <b>L G d</b> ): Long Delay In Progress <b>o n</b> <b>[Active]</b> ( <b>L G d</b> ): GDL active <b>L F t</b> <b>[Internal Err.]</b> ( <b>L G d</b> ): GDL internal error	
<b>S F F E</b>	<b>[Safety fault reg.]</b> Safety function error register.  Bit0 = 1: Logic inputs debounce time-out (verify value of debounce time LIDT according to the application) Bit1 Reserved Bit2 = 1: Motor speed sign has changed during SS1 ramp Bit3 = 1: Motor speed has reached the frequency limit threshold during SS1 ramp. Bit4: Reserved Bit5: Reserved Bit6 = 1: Motor speed sign has changed during SLS limitation Bit7 = 1: Motor speed has reached the frequency limit threshold during SS1 ramp. Bit8: Reserved Bit9: Reserved Bit10: Reserved Bit11: Reserved Bit12: Reserved Bit13 = 1: Not possible to measure the motor speed (verify the motor wiring connection) Bit14 = 1: Motor ground short-circuit detected (verify the motor wiring connection) Bit15 = 1: Motor phase to phase short-circuit detected (verify the motor wiring connection)	
<b>no n -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>no f b -</b>	<b>[MONIT. FUN. BLOCKS]</b> For more details on Function Blocks, please refer to dedicated Function Blocks manual.	
<b>F b S t</b>	<b>[FB status]</b> Function Block Status.  <b>i d L E</b> <b>[Idle]</b> ( <b>i d L E</b> ): Idle state <b>C H E C</b> <b>[Check prog.]</b> ( <b>C H E C</b> ): Check program state <b>S t o P</b> <b>[Stop]</b> ( <b>S t o P</b> ): STOP state <b>i n i t</b> <b>[Init]</b> ( <b>i n i t</b> ): Initialization state <b>r u n</b> <b>[Run]</b> ( <b>r u n</b> ): RUN state <b>E r r</b> <b>[Error]</b> ( <b>E r r</b> ): Error state	
<b>F b F t</b>	<b>[FB fault]</b> Status of the function blocks execution.  <b>no</b> <b>[No]</b> ( <b>no</b> ): No error detected <b>i n t</b> <b>[Internal]</b> ( <b>i n t</b> ): Internal error detected <b>b i n</b> <b>[Binary file]</b> ( <b>b i n</b> ): Binary error detected <b>i n P</b> <b>[Intern para.]</b> ( <b>i n P</b> ): Internal parameter error detected <b>P A r</b> <b>[Para. RW]</b> ( <b>P A r</b> ): Parameter access error detected <b>C A L</b> <b>[Calculation]</b> ( <b>C A L</b> ): Calculation error detected <b>t o A u</b> <b>[TO AUX]</b> ( <b>t o A u</b> ): TimeOut AUX task <b>t o P P</b> <b>[TO synch]</b> ( <b>t o P P</b> ): TimeOut in PRE/POST task <b>A d L</b> <b>[Bad ADLC]</b> ( <b>A d L</b> ): ADLC with bad parameter <b>i n</b> <b>[Input assign.]</b> ( <b>i n</b> ): Input not configured	
<b>F b i -</b>	<b>[FB IDENTIFICATION]</b>	
<b>b u E r</b> ★	<b>[Program version]</b> Program user version. Can be accessed if <b>[FB status]</b> ( <b>F b S t</b> ) is not set to <b>[Idle]</b> ( <b>i d L E</b> ).	
<b>b n S</b> ★	<b>[Program size]</b> Program file size. Can be accessed if <b>[FB status]</b> ( <b>F b S t</b> ) is not set to <b>[Idle]</b> ( <b>i d L E</b> ).	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; CMM-

Code	Name / Description	Unit
<i>b n u</i>	<b>[Prg. format version]</b> Binary format version of the drive. Can be accessed if <b>[FB status]</b> ( <i>F b 5 k</i> ) is not set to <b>[Idle]</b> ( <i>i d L E</i> ).	
<i>C k u</i>	<b>[Catalogue version]</b> Catalog version of the drive.	
<i>Π α η -</i>	<b>[1.2 MONITORING] (continued)</b>	
<i>C Π Π -</i>	<b>[COMMUNICATION MAP]</b> This menu is visible only on graphic display terminal, except for <b>[COM. SCANNER INPUT MAP]</b> ( <i>, 5 R -</i> ) and <b>[COM SCAN MAP]</b> ( <i>, 5 R -</i> ) menus.	
<i>C Π d C</i>	<b>[Command channel]</b> Active command channel.	
<i>k E r Π</i>	<b>[Terminals]</b> ( <i>k E r Π</i> ): Terminals	
<i>H Π i</i>	<b>[HMI]</b> ( <i>H Π i</i> ): Graphic display terminal or remote display terminal	
<i>Π d b</i>	<b>[Modbus]</b> ( <i>Π d b</i> ): Integrated Modbus	
<i>C R n</i>	<b>[CANopen]</b> ( <i>C R n</i> ): Integrated CANopen®	
<i>k u d</i>	<b>[+/- speed]</b> ( <i>k u d</i> ): +/- speed command	
<i>n E k</i>	<b>[Com. card]</b> ( <i>n E k</i> ): Communication card (if inserted)	
<i>P 5</i>	<b>[PC tool]</b> ( <i>P 5</i> ): PC software	
<i>C Π d</i>	<b>[Cmd value]</b> DRIVECOM command register value. <b>[Profile]</b> ( <i>C H C F</i> ) is not set to <b>[I/O profile]</b> ( <i>i o</i> ), see page 154.  Possible values in CiA402 profile, separate or not separate mode. Bit 0: "Switch on"/Contactor command Bit 1: "Disable voltage"/Authorization to supply AC power Bit 2: "Quick stop"/Emergency stop Bit 3: "Enable operation"/Run command Bit 4 to Bit 6: Reserved (set to 0) Bit 7: "Fault reset"/error acknowledgment active on 0 to 1 rising edge Bit 8: Halt Stop according to the <b>[Type of stop]</b> ( <i>5 k k</i> ) parameter without leaving the Operation enabled state Bit 9: Reserved (set to 0) Bit 10: Reserved (set to 0) Bit 11 to Bit 15: Can be assigned to a command  Possible values in the I/O profile. On state command <b>[2 wire]</b> ( <i>k C</i> ). Bit 0: Forward (on state) command = 0: No forward command = 1: Forward command The assignment of bit 0 cannot be modified. It corresponds to the assignment of the terminals. It can be switched. Bit 0 ( <i>C d d d</i> ) is only active if the channel of this control word is active. Bit 1 to Bit 15: Can be assigned to commands.  On edge command <b>[3 wire]</b> ( <i>k C</i> ). Bit 0: Stop (run authorization). = 0: Stop = 1: Run is authorized on a forward or reverse command Bit 1: Forward (on 0 to 1 rising edge) command The assignment of bits 0 and 1 cannot be modified. It corresponds to the assignment of the terminals. It can be switched. Bits 0 ( <i>C d d d</i> ) and 1 ( <i>C d d l</i> ) are only active if the channel of this control word is active. Bit 2 to Bit 15: Can be assigned to commands	
<i>r F C C</i>	<b>[Active ref. channel]</b> HMI reference channel.	
<i>k E r Π</i>	<b>[Terminals]</b> ( <i>k E r Π</i> ): Terminals	
<i>L o C</i>	<b>[Local]</b> ( <i>L o C</i> ): Jog dial	
<i>H Π i</i>	<b>[HMI]</b> ( <i>H Π i</i> ): Graphic display terminal or remote display terminal	
<i>Π d b</i>	<b>[Modbus]</b> ( <i>Π d b</i> ): Integrated Modbus	
<i>C R n</i>	<b>[CANopen]</b> ( <i>C R n</i> ): Integrated CANopen®	
<i>k u d</i>	<b>[tUd]</b> ( <i>k u d</i> ): +/- speed command	
<i>n E k</i>	<b>[Com. card]</b> ( <i>n E k</i> ): Communication card (if inserted)	
<i>P 5</i>	<b>[PC tool]</b> ( <i>P 5</i> ): PC software	
<i>F r H</i>	<b>[Frequency ref.]</b>	Hz

Code	Name / Description	Unit
	Frequency reference before ramp.	
E L F	<p><b>[ETA state word]</b> DRIVECOM status word.</p> <p>Possible values in CiA402 profile, separate or not separate mode.            Bit 0: "Ready to switch on", awaiting power section supply mains            Bit 1: "Switched on", ready            Bit 2: "Operation enabled", running            Bit 3: "Fault"                = 0: No fault                = 1: Fault            Bit 4: "Voltage enabled", power section supply mains present                = 0: Power section supply mains absent                = 1: Power section supply mains present            When the drive is powered by the power section only, this bit is always at 1.            Bit 5: Quick stop/Emergency stop            Bit 6: "Switched on disabled", power section supply mains locked            Bit 7: Alarm                = 0: No alarm                = 1: Alarm            Bit 8: Reserved (= 0)            Bit 9: Remote: command or reference via the network                = 0: Command or reference via the graphic display terminal or the remote display terminal                = 1: Command or reference via the network            Bit 10: Target reference reached                = 0: The reference is not reached                = 1: The reference has been reached            When the drive is in speed mode, this is the speed reference.            Bit 11: "Internal limit active", reference outside limits                = 0: The reference is within the limits                = 1: The reference is not within the limits            When the drive is in speed mode, the limits are defined by the <b>[Low speed] (L 5 P)</b> and <b>[High speed] (H 5 P)</b> parameters.            Bit 12 and Bit 13: Reserved (= 0)            Bit 14: "Stop key", STOP via stop key                = 0: STOP key not pressed                = 1: Stop triggered by the STOP key on the graphic display terminal or the remote display terminal            Bit 15: "Direction", direction of rotation                = 0: Forward rotation at output                = 1: Reverse rotation at output</p> <p>The combination of bits 0, 1, 2, 4, 5 and 6 defines the state in the DSP 402 state chart (see the Communication manuals).</p> <p>Possible values in the I/O profile.  <b>Note:</b> The value is identical in the CiA402 profile and the I/O profile. In the I/O profile, the description of the values is simplified and does not refer to the CiA402 (Drivecom) state chart.            Bit 0: Reserved (= 0 or 1)            Bit 1: Ready                = 0: Not ready                = 1: Ready            Bit 2: Running                = 0: The drive will not start if a reference other than zero is applied.                = 1: Running, if a reference other than zero is applied, the drive can start.            Bit 3: Fault                = 0: No fault                = 1: Fault            Bit 4: Power section supply mains present                = 0: Power section supply mains absent                = 1: Power section supply mains present            Bit 5: Reserved (= 1)            Bit 6: Reserved (= 0 or 1)            Bit 7: Alarm                = 0: No alarm                = 1: Alarm            Bit 8: Reserved (= 0)            Bit 9: Command via a network                = 0: Command via the terminals or the graphic display terminal                = 1: Command via a network</p>	



Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; CMM-

Code	Name / Description	Unit
	Bit 10: Reference reached = 0: The reference is not reached = 1: The reference has been reached Bit 11: Reference outside limits = 0: The reference is within the limits = 1: The reference is not within the limits When the drive is in speed mode, the limits are defined by LSP and HSP parameters. Bit 12 and Bit 13: Reserved (= 0) Bit 14: Stop via STOP key = 0: STOP key not pressed = 1: Stop triggered by the STOP key on the graphic display terminal or the remote display terminal Bit 15: Direction of rotation = 0: Forward rotation at output = 1: Reverse rotation at output	
<b>Пнд -</b>	<b>[MODBUS NETWORK DIAG]</b> Modbus network diagnostic.	
<b>Пдб1</b>	<b>[COM LED]</b> View of the Modbus Communication.	
<b>П1Сб</b>	<b>[Mb NET frames nb.]</b> Modbus network frame counter: Number of processed frames.	
<b>П1ЕС</b>	<b>[Mb NET CRC errors]</b> Modbus network CRC error counter: Number of CRC errors.	
<b>СПП -</b>	<b>[COMMUNICATION MAP] (continued)</b>	
<b>15А -</b>	<b>[COM. SCANNER INPUT MAP]</b> Used for CANopen® and Modbus Network.	
<b>пп1</b>	<b>[Com Scan In1 val.]</b> Value of the 1st input word.	
<b>пп2</b>	<b>[Com Scan In2 val.]</b> Value of the 2nd input word.	
<b>пп3</b>	<b>[Com Scan In3 val.]</b> Value of the 3rd input word.	
<b>пп4</b>	<b>[Com Scan In4 val.]</b> Value of the 4th input word.	
<b>пп5</b>	<b>[Com Scan In5 val.]</b> Value of the 5th input word.	
<b>пп6</b>	<b>[Com Scan In6 val.]</b> Value of the 6th input word.	
<b>пп7</b>	<b>[Com Scan In7 val.]</b> Value of the 7th input word.	
<b>пп8</b>	<b>[Com Scan In8 val.]</b> Value of the 8th input word.	
<b>СПП -</b>	<b>[COMMUNICATION MAP] (continued)</b>	
<b>о5А -</b>	<b>[COM SCAN MAP]</b>	
<b>пс1</b>	<b>[Com Scan Out1 val.]</b> Value of the 1st output word.	
<b>пс2</b>	<b>[Com Scan Out2 val.]</b> Value of the 2nd output word.	
<b>пс3</b>	<b>[Com Scan Out3 val.]</b> Value of the 3rd output word.	
<b>пс4</b>	<b>[Com Scan Out4 val.]</b> Value of the 4th output word.	
<b>пс5</b>	<b>[Com Scan Out5 val.]</b> Value of the 5th output word.	

Code	Name / Description	Unit
<i>n C 6</i>	<b>[Com Scan Out6 val.]</b> Value of the 6th output word.	
<i>n C 7</i>	<b>[Com Scan Out7 val.]</b> Value of the 7th output word.	
<i>n C 8</i>	<b>[Com Scan Out8 val.]</b> Value of the 8th output word.	
<i>C P P -</i>	<b>[COMMUNICATION MAP] (continued)</b>	
<i>C I -</i>	<b>[CMD. WORD IMAGE]</b> Command word image: Only accessible via graphic display terminal.	
<i>C P d 1</i>	<b>[Modbus cmd.]</b> Modbus command word image.	
<i>C P d 2</i>	<b>[CANopen cmd.]</b> CANopen® command word image.	
<i>C P d 3</i>	<b>[COM. card cmd.]</b> Communication card command word image.	
<i>C P P -</i>	<b>[COMMUNICATION MAP] (continued)</b>	
<i>r I -</i>	<b>[FREQ. REF. WORD MAP]</b> Frequency reference image: Only accessible via graphic display terminal.	
<i>L F r 1</i>	<b>[Modbus ref.]</b> Modbus frequency reference image.	Hz
<i>L F r 2</i>	<b>[CANopen ref.]</b> CANopen® frequency reference image.	Hz
<i>L F r 3</i>	<b>[Com. card ref.]</b> Communication card frequency reference image.	Hz
<i>C P P -</i>	<b>[COMMUNICATION MAP] (continued)</b>	
<i>C n P -</i>	<b>[CANopen MAP]</b> CANopen® image: Only accessible via graphic display terminal.	
<i>C o n</i>	<b>[RUN LED]</b> View of the CANopen® RUN Led Status.	
<i>C A n E</i>	<b>[ERR LED]</b> View of the CANopen® Error Led Status.	
<i>P o 1 -</i>	<b>[PDO1 IMAGE]</b> View of the RPDO1 and TPDO1.	
<i>r P 1 1</i> ★	<b>[Received PDO1-1]</b> First frame of the received PDO1.	
<i>r P 1 2</i> ★	<b>[Received PDO1-2]</b> Second frame of the received PDO1.	
<i>r P 1 3</i> ★	<b>[Received PDO1-3]</b> Third frame of the received PDO1.	
<i>r P 1 4</i> ★	<b>[Received PDO1-4]</b> Fourth frame of the received PDO1.	
<i>t P 1 1</i> ★	<b>[Transmit PDO1-1]</b> First frame of the transmit PDO1.	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; CMM- &gt; CNM- &gt; P01-

Code	Name / Description	Unit
<i>EP12</i> ★	<b>[Transmit PDO1-2]</b> Second frame of the transmit PDO1.	
<i>EP13</i> ★	<b>[Transmit PDO1-3]</b> Third frame of the transmit PDO1.	
<i>EP14</i> ★	<b>[Transmit PDO1-4]</b> Fourth frame of the transmit PDO1.	
<i>ENP-</i>	<b>[CANopen MAP] (continued)</b> CANopen® image: Only accessible via graphic display terminal.	
<i>P02-</i>	<b>[PDO2 IMAGE]</b> View of the RPDO2 and TPDO2: Same structure as <b>[PDO1 IMAGE]</b> ( <i>P01-</i> ).	
<i>rP21</i> ★	<b>[Received PDO2-1]</b> First frame of the received PDO2.	
<i>rP22</i> ★	<b>[Received PDO2-2]</b> Second frame of the received PDO2.	
<i>rP23</i> ★	<b>[Received PDO2-3]</b> Third frame of the received PDO2.	
<i>rP24</i> ★	<b>[Received PDO2-4]</b> Fourth frame of the received PDO2.	
<i>EP21</i> ★	<b>[Transmit PDO2-1]</b> First frame of the transmit PDO2.	
<i>EP22</i> ★	<b>[Transmit PDO2-2]</b> Second frame of the transmit PDO2.	
<i>EP23</i> ★	<b>[Transmit PDO2-3]</b> Third frame of the transmit PDO2.	
<i>EP24</i> ★	<b>[Transmit PDO2-4]</b> Fourth frame of the transmit PDO2.	
<i>ENP-</i>	<b>[CANopen MAP] (continued)</b> CANopen® image: Only accessible via graphic display terminal.	
<i>P03-</i>	<b>[PDO3 IMAGE]</b> View of the RPDO3 and TPDO3: Same structure as <b>[PDO1 IMAGE]</b> ( <i>P01-</i> ).	
<i>rP31</i> ★	<b>[Received PDO3-1]</b> First frame of the received PDO3.	
<i>rP32</i> ★	<b>[Received PDO3-2]</b> Second frame of the received PDO3.	
<i>rP33</i> ★	<b>[Received PDO3-3]</b> Third frame of the received PDO3.	
<i>rP34</i> ★	<b>[Received PDO3-4]</b> Fourth frame of the received PDO3.	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; CMM- &gt; CNM- &gt; P03-

Code	Name / Description	Unit
<i>EP31</i> ★	<b>[Transmit PDO3-1]</b> First frame of the transmit PDO3.	
<i>EP32</i> ★	<b>[Transmit PDO3-2]</b> Second frame of the transmit PDO3.	
<i>EP33</i> ★	<b>[Transmit PDO3-3]</b> Third frame of the transmit PDO3.	
<i>EP34</i> ★	<b>[Transmit PDO3-4]</b> Fourth frame of the transmit PDO3.	
<i>CnN-</i>	<b>[CANopen MAP] (continued)</b> CANopen® image: Only accessible via graphic display terminal.	
<i>nNtS</i>  <i>boot</i> <i>StoP</i> <i>oPE</i> <i>PoPE</i>	<b>[Canopen NMT state]</b> Drive NMT State of the CANopen® slave.  <b>[Boot]</b> ( <i>boot</i> ): Bootup <b>[Stopped]</b> ( <i>StoP</i> ): Stopped <b>[Operation]</b> ( <i>oPE</i> ): Operational <b>[Pre-op]</b> ( <i>PoPE</i> ): Pre-Operational	
<i>nbtP</i>	<b>[Number of TX PDO]</b> Number of transmit PDO.	
<i>nbrP</i>	<b>[Number of RX PDO]</b> Number of receive PDO.	
<i>ErCo</i>	<b>[Error code]</b> CANopen® error register (from 1 to 5).	
<i>rECI</i>	<b>[RX Error Counter]</b> Controller Rx error counter (not stored at power off).	
<i>tECI</i>	<b>[TX error counter]</b> Controller Tx error counter (not stored at power off).	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; MPI-

Code	Name / Description	Unit
<b>Π ο η -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>Π Ρ ι -</b> ★	<b>[MONIT. PI]</b> PID management. Visible if <b>[PID feedback ass.]</b> ( <b>Ρ ι F</b> ) is not set to <b>[No]</b> ( <b>η ο</b> ).	
<b>ι Ρ ι</b> (↻) ★	<b>[Internal PID ref.]</b> Internal PID reference: As a process value.	
<b>ι Ρ Ε</b> ★	<b>[PID error]</b> PID error value.	
<b>ι Ρ F</b> ★	<b>[PID feedback]</b> PID feedback value.	
<b>ι Ρ C</b> ★	<b>[PID reference]</b> PID setpoint value via graphic display terminal.	
<b>ι Ρ ο</b>	<b>[PID Output]</b> PID output value with limitation.	Hz
<b>Π ο η -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>Ρ Ε t -</b>	<b>[MONIT. POWER TIME]</b>	
<b>Ρ Ρ Η</b>	<b>[Consumption]</b> Energy consumption in Wh, kWh or MWh (accumulated consumption).	Wh, kWh, MWh
<b>ι t Η</b>	<b>[Run time]</b> Run elapsed time display (resetable) in seconds, minutes or hours (length of time the motor has been switched on).	s, min, h
<b>Ρ t Η</b>	<b>[Power on time]</b> Power elapsed time display in seconds, minutes or hours (length of time the drive has been switched on).	s, min, h
<b>ι Ρ r</b> (↻)	<b>[Operating t. reset]</b> Reset of run elapsed time.	
<b>η ο</b>	<b>[No]</b> ( <b>η ο</b> ): Reset operation not in progress	
<b>Ρ Ρ Η</b>	<b>[Reset kWh]</b> ( <b>Ρ Ρ Η</b> ): Clear <b>[Reset kWh]</b> ( <b>Ρ Ρ Η</b> )	
<b>ι t Η</b>	<b>[rst. runtime]</b> ( <b>ι t Η</b> ): Clear <b>[rst. runtime]</b> ( <b>ι t Η</b> )	
<b>Ρ t Η</b>	<b>[rst. P On t.]</b> ( <b>Ρ t Η</b> ): Clear <b>[rst. P On t.]</b> ( <b>Ρ t Η</b> )	
<b>Π ο η -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>C η F 5</b>	<b>[Config. active]</b> View of the active configuration.	
<b>η ο</b>	<b>[In progress]</b> ( <b>η ο</b> ): Transitory state (configuration changing)	
<b>C η F 0</b>	<b>[Config. n°0]</b> ( <b>C η F 0</b> ): Configuration 0 active	
<b>C η F 1</b>	<b>[Config. n°1]</b> ( <b>C η F 1</b> ): Configuration 1 active	
<b>C η F 2</b>	<b>[Config. n°2]</b> ( <b>C η F 2</b> ): Configuration 2 active	
<b>C F P 5</b> ★	<b>[Utilised param. set]</b> Configuration parameter status (can be accessed if parameter switching has been enabled, see page <a href="#">229</a> ).	
<b>η ο</b>	<b>[None]</b> ( <b>η ο</b> ): Not assigned	
<b>C F P 1</b>	<b>[Set N°1]</b> ( <b>C F P 1</b> ): Parameter set 1 active	
<b>C F P 2</b>	<b>[Set N°2]</b> ( <b>C F P 2</b> ): Parameter set 2 active	
<b>C F P 3</b>	<b>[Set N°3]</b> ( <b>C F P 3</b> ): Parameter set 3 active	

Code	Name / Description	Unit
<b>ALGr</b>	<b>[Alarm groups]</b> Current impacted alarm group numbers. Group of alarms could be user defined in <b>[INPUTS / OUTPUTS CFG] ( i - o - )</b> page <a href="#">125</a> .	
---	[--] ( -- ): No alarm group impacted	
1--	[1--] ( 1 - - ): Alarm group 1	
-2-	[-2-] ( - 2 - ): Alarm group 2	
12-	[12-] ( 1 2 - ): Alarm group 1 and 2	
--3	[--3] ( - - 3 ): Alarm group 3	
1-3	[1-3] ( 1 - 3 ): Alarm group 1 and 3	
-23	[-23] ( - 2 3 ): Alarm group 2 and 3	
123	[123] ( 1 2 3 ): Alarm group 1, 2 and 3	
<b>SPd1</b> or <b>SPd2</b> or <b>qSPd3</b>	<b>[Cust. output value]</b> [Cust. output value] ( <b>SPd1</b> ), [Cust. output value] ( <b>SPd2</b> ) or [Cust. output value] ( <b>SPd3</b> ) depending on the [Scale factor display] ( <b>SD5</b> ) parameter, page <a href="#">104</a> ([Cust. output value] ( <b>SPd3</b> ) in the factory setting)	
<b>ALr-</b>	<b>[ALARMS]</b> List of current alarms. If an alarm is present, a ✓ appears on the graphic display terminal.	
<b>noAL</b>	[No alarm] ( <b>noAL</b> )	
<b>PECL</b>	[PTC alarm] ( <b>PECL</b> )	
<b>EEF</b>	[External fault] ( <b>EEF</b> )	
<b>uSA</b>	[UnderV. al.] ( <b>uSA</b> )	
<b>CEA</b>	[I attained] ( <b>CEA</b> )	
<b>FEA</b>	[Freq. Th. attain.] ( <b>FEA</b> )	
<b>F2A</b>	[Freq. Th. 2 attained] ( <b>F2A</b> )	
<b>SrA</b>	[Freq.ref.att] ( <b>SrA</b> )	
<b>tSA</b>	[Th.mot. att.] ( <b>tSA</b> )	
<b>tS2</b>	[Th.mot2 att.] ( <b>tS2</b> )	
<b>tS3</b>	[Th.mot3 att.] ( <b>tS3</b> )	
<b>uPA</b>	[Underv. prev.] ( <b>uPA</b> )	
<b>FLA</b>	[HSP attain.] ( <b>FLA</b> )	
<b>tHA</b>	[Al. °C drv] ( <b>tHA</b> )	
<b>AG1</b>	[Alarm group 1] ( <b>AG1</b> )	
<b>AG2</b>	[Alarm group 2] ( <b>AG2</b> )	
<b>AG3</b>	[Alarm group 3] ( <b>AG3</b> )	
<b>PEE</b>	[PID error al] ( <b>PEE</b> )	
<b>PFA</b>	[PID fdbk al.] ( <b>PFA</b> )	
<b>AP3</b>	[AI3 Al. 4-20mA] ( <b>AP3</b> )	
<b>SSA</b>	[Lim T/I att.] ( <b>SSA</b> )	
<b>tAd</b>	[Th.driv.att.] ( <b>tAd</b> )	
<b>tJA</b>	[IGBT alarm] ( <b>tJA</b> )	
<b>boA</b>	[Brake R. al.] ( <b>boA</b> )	
<b>uLA</b>	[Underload. Proc. Al.] ( <b>uLA</b> )	
<b>oLA</b>	[Overload. Proc. Al.] ( <b>oLA</b> )	
<b>rSdA</b>	[Rope slack alarm] ( <b>rSdA</b> )	
<b>tEHA</b>	[High torque alarm] ( <b>tEHA</b> )	
<b>tELA</b>	[Low torque alarm] ( <b>tELA</b> )	
<b>dLdA</b>	[Dynamic load alarm] ( <b>dLdA</b> )	
<b>FqLA</b>	[Freq. meter Alarm] ( <b>FqLA</b> )	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; SST-

Code	Name / Description	Unit
<b>55t -</b>	<b>[OTHER STATE]</b> List of secondary states. This menu is visible only on graphic display terminal.	
<i>FL</i>	<b>[In motor fluxing] (FL)</b>	
<i>PtCLL</i>	<b>[PTC Alarm] (PtCLL)</b>	
<i>FSt</i>	<b>[Fast stop in prog.] (FSt)</b>	
<i>CtA</i>	<b>[Current Th. attained] (CtA)</b>	
<i>FtA</i>	<b>[Freq. Th. attained] (FtA)</b>	
<i>F2A</i>	<b>[Freq. Th. 2 attained] (F2A)</b>	
<i>SrA</i>	<b>[Frequency ref. att.] (SrA)</b>	
<i>tSA</i>	<b>[Motor th. state att.] (tSA)</b>	
<i>EtF</i>	<b>[External fault alarm] (EtF)</b>	
<i>Aut</i>	<b>[Auto restart] (Aut)</b>	
<i>FtL</i>	<b>[Remote] (FtL)</b>	
<i>tun</i>	<b>[Auto-tuning] (tun)</b>	
<i>uSA</i>	<b>[Undervoltage] (uSA)</b>	
<i>CnF1</i>	<b>[Config. 1 act.] (CnF1)</b>	
<i>CnF2</i>	<b>[Config. 2 act.] (CnF2)</b>	
<i>FLA</i>	<b>[HSP attained] (FLA)</b>	
<i>CFP1</i>	<b>[Set 1 active] (CFP1)</b>	
<i>CFP2</i>	<b>[Set 2 active] (CFP2)</b>	
<i>CFP3</i>	<b>[Set 3 active] (CFP3)</b>	
<i>brS</i>	<b>[In braking] (brS)</b>	
<i>dbl</i>	<b>[DC bus loading] (dbl)</b>	
<i>tHA</i>	<b>[High torque alarm] (tHA)</b>	
<i>tLA</i>	<b>[Low torque alarm] (tLA)</b>	
<i>FFrd</i>	<b>[Forward] (FFrd)</b>	
<i>FFrs</i>	<b>[Reverse] (FFrs)</b>	
<i>F9LA</i>	<b>[Freq. metre Alarm] (F9LA)</b>	
<b>dGt -</b>	<b>[DIAGNOSTICS]</b> This menu is visible only on graphic display terminal.	
<b>PFH -</b>	<b>[FAULT HISTORY]</b> Shows the 8 last detected faults.	
<b>dP1</b>	<b>[Past fault 1]</b> Fault record 1 (1 is last).	
<i>noF</i>	<b>[No fault] (noF):</b> No detected fault stored	
<i>ASF</i>	<b>[Angle error] (ASF):</b> Angle setting detected fault	
<i>BLF</i>	<b>[Brake control] (BLF):</b> Brake's motor 3-phases loss	
<i>brF</i>	<b>[Brake feedback] (brF):</b> Brake contactor detected error	
<i>CFE</i>	<b>[Incorrect config.] (CFE):</b> Invalid configuration at power on	
<i>CFi2</i>	<b>[Bad conf] (CFi2):</b> Configuration transfer detected error	
<i>CnF</i>	<b>[Com. network] (CnF):</b> NET option communication interruption	
<i>CoF</i>	<b>[CAN com.] (CoF):</b> CANopen® communication interruption	
<i>CrF</i>	<b>[Capa.charg] (CrF):</b> Load relay detected fault	
<i>CSF</i>	<b>[Ch.sw. fault] (CSF):</b> Channel switching detected error	
<i>dLF</i>	<b>[Load fault] (dLF):</b> Dynamic load detected error	
<i>EEF1</i>	<b>[Control EEPROM] (EEF1):</b> Control EEPROM detected error	
<i>EEF2</i>	<b>[Power EEPROM] (EEF2):</b> Power EEPROM detected error	
<i>EPF1</i>	<b>[External fault LI/Bit] (EPF1):</b> External detected fault from LI or local link	
<i>EPF2</i>	<b>[External fault com.] (EPF2):</b> External interruption from communication board	
<i>FbE</i>	<b>[FB fault] (FbE):</b> Function block detected error	
<i>FbES</i>	<b>[FB stop fly.] (FbES):</b> Function block stop detected error	
<i>FCF1</i>	<b>[Out. contact. stuck] (FCF1):</b> Output contactor: closed contactor	
<i>FCF2</i>	<b>[Out. contact. open.] (FCF2):</b> Output contactor: opened contactor	
<i>HCF</i>	<b>[Cards pairing] (HCF):</b> Hardware configuration detected error	
<i>HdF</i>	<b>[IGBT desaturation] (HdF):</b> Hardware detected error	
<i>iLF</i>	<b>[Option int link] (iLF):</b> Option internal link interruption	
<i>inF1</i>	<b>[Rating error] (inF1):</b> Unknown drive rating	
<i>inF2</i>	<b>[PWR Calib.] (inF2):</b> Unknown or incompatible power board	
<i>inF3</i>	<b>[Int.serial link] (inF3):</b> Internal serial link communication interruption	
<i>inF4</i>	<b>[Int.Mfg area] (inF4):</b> Invalid industrialization zone	
<i>inF5</i>	<b>[Internal-option] (inF5):</b> Unknown or incompatible option board	
<i>inF9</i>	<b>[Internal- I measure] (inF9):</b> Current measurement circuit detected error	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; DGT- &gt; PFH-

Code	Name / Description	Unit
<i>inFA</i>	<b>[Internal-mains circuit]</b> ( <i>inFA</i> ): Input phase loss circuit detected error	
<i>inFb</i>	<b>[Internal- th. sensor]</b> ( <i>inFb</i> ): Thermal sensor detected error (OC or SC)	
<i>inFE</i>	<b>[Internal-CPU]</b> ( <i>inFE</i> ): CPU detected fault (ram, flash, task ...)	
<i>LCF</i>	<b>[Input contactor]</b> ( <i>LCF</i> ): Line contactor detected error	
<i>LI3</i>	<b>[AI3 4-20mA loss]</b> ( <i>LI3</i> ): AI3 4-20 mA loss	
<i>obF</i>	<b>[Overbraking]</b> ( <i>obF</i> ): Overbraking	
<i>ocF</i>	<b>[Overcurrent]</b> ( <i>ocF</i> ): Overcurrent	
<i>oHF</i>	<b>[Drive overheat]</b> ( <i>oHF</i> ): Drive overheating	
<i>oLC</i>	<b>[Proc.Overload Flt]</b> ( <i>oLC</i> ): Torque overload	
<i>oLF</i>	<b>[Motor overload]</b> ( <i>oLF</i> ): Motor overload	
<i>oPF1</i>	<b>[1 output phase loss]</b> ( <i>oPF1</i> ): Motor 1-phase loss	
<i>oPF2</i>	<b>[3out ph loss]</b> ( <i>oPF2</i> ): Motor 3-phases loss	
<i>oS F</i>	<b>[Mains overvoltage]</b> ( <i>oS F</i> ): Oversupply detected fault	
<i>oEFL</i>	<b>[PTC fault]</b> ( <i>oEFL</i> ): Motor overheating detected error from PTCL: standard product	
<i>PHF</i>	<b>[Input phase loss]</b> ( <i>PHF</i> ): Main input 1-phase loss	
<i>PEFL</i>	<b>[L16=PTC probe]</b> ( <i>PEFL</i> ): PTCL detected error (OC or SC)	
<i>SFFF</i>	<b>[Safety]</b> ( <i>SFFF</i> ): Safety function	
<i>SCF1</i>	<b>[Motor short circuit]</b> ( <i>SCF1</i> ): Motor short circuit (hard detection)	
<i>SCF3</i>	<b>[Ground short circuit]</b> ( <i>SCF3</i> ): Direct ground short-circuit (hard detection)	
<i>SCF4</i>	<b>[IGBT short circuit]</b> ( <i>SCF4</i> ): IGBT short-circuit (hard detection)	
<i>SCF5</i>	<b>[Motor short circuit]</b> ( <i>SCF5</i> ): Load short-circuit during Igon load sequence (hard detection)	
<i>SLF1</i>	<b>[Modbus com.]</b> ( <i>SLF1</i> ): Modbus local serial communication interruption	
<i>SLF2</i>	<b>[PC com.]</b> ( <i>SLF2</i> ): PC Software communication interruption	
<i>SLF3</i>	<b>[HMI com.]</b> ( <i>SLF3</i> ): Remote terminal communication interruption	
<i>soF</i>	<b>[Overspeed]</b> ( <i>soF</i> ): Overspeed	
<i>SPF</i>	<b>[Speed fdback loss]</b> ( <i>SPF</i> ): Speed feedback loss	
<i>SSF</i>	<b>[Torque/current lim]</b> ( <i>SSF</i> ): Torque current limitation detected fault	
<i>tJF</i>	<b>[IGBT overheat]</b> ( <i>tJF</i> ): IGBT overheating	
<i>tNF</i>	<b>[Auto-tuning]</b> ( <i>tNF</i> ): Tune detected fault	
<i>uLF</i>	<b>[Pr.Underload Flt]</b> ( <i>uLF</i> ): Torque underload	
<i>uSF</i>	<b>[Undervoltage]</b> ( <i>uSF</i> ): Undervoltage	
<b>H51</b>	<b>[Drive state]</b> HMI Status of the detected fault record 1.	
<i>tun</i>	<b>[Auto-tuning]</b> ( <i>tun</i> ): Auto-tuning	
<i>dCb</i>	<b>[In DC inject.]</b> ( <i>dCb</i> ): Injection braking	
<i>rdY</i>	<b>[Ready]</b> ( <i>rdY</i> ): Drive ready	
<i>nSt</i>	<b>[Freewheel]</b> ( <i>nSt</i> ): Freewheel stop control	
<i>run</i>	<b>[Drv running]</b> ( <i>run</i> ): Motor in steady state or run command present and zero reference	
<i>ACC</i>	<b>[In accel.]</b> ( <i>ACC</i> ): Acceleration	
<i>dEC</i>	<b>[In decel.]</b> ( <i>dEC</i> ): Deceleration	
<i>CLi</i>	<b>[Current lim.]</b> ( <i>CLi</i> ): Current limit (in case of using a synchronous motor, if the motor does not start, follow the procedure page <a href="#">112</a> )	
<i>FSt</i>	<b>[Fast stop]</b> ( <i>FSt</i> ): Fast stop	
<i>FLu</i>	<b>[Mot. fluxing]</b> ( <i>FLu</i> ): Fluxing function is activated	
<i>nLP</i>	<b>[no mains V.]</b> ( <i>nLP</i> ): Control is powered on but the DC bus is not loaded	
<i>CLL</i>	<b>[control.stop]</b> ( <i>CLL</i> ): Controlled stop	
<i>abr</i>	<b>[Dec. adapt.]</b> ( <i>abr</i> ): Adapted deceleration	
<i>SoC</i>	<b>[Output cut]</b> ( <i>SoC</i> ): Stand by output cut	
<i>uSA</i>	<b>[UnderV. al.]</b> ( <i>uSA</i> ): Undervoltage alarm	
<i>tC</i>	<b>[In mfg. test]</b> ( <i>tC</i> ): TC indus mode activated	
<i>St</i>	<b>[in autotest]</b> ( <i>St</i> ): Self test in progress	
<i>FR</i>	<b>[autotest err]</b> ( <i>FR</i> ): Self test detected error	
<i>YES</i>	<b>[Autotest OK]</b> ( <i>YES</i> ): Self test OK	
<i>EP</i>	<b>[eeprom test]</b> ( <i>EP</i> ): Self test Eeprom detected error	
<i>FLt</i>	<b>[In fault]</b> ( <i>FLt</i> ): Product has detected a fault	
<i>SS1</i>	<b>[SS1 active]</b> ( <i>SS1</i> ): Safety function SS1	
<i>SLS</i>	<b>[SLS active]</b> ( <i>SLS</i> ): Safety function SLS	
<i>Sto</i>	<b>[STO active]</b> ( <i>Sto</i> ): Safety function STO	
<i>SMS</i>	<b>[SMS active]</b> ( <i>SMS</i> ): Safety function SMS	
<i>GdL</i>	<b>[GdL active]</b> ( <i>GdL</i> ): Safety function GdL	
<b>EP1</b>	<b>[ETA state word]</b> DRIVECOM status register of detected fault record 1 (same as <b>[ETA state word]</b> ( <i>ETR</i> ) page <a href="#">57</a> ).	
<b>IP1</b>	<b>[ETI state word]</b> Extended status register of detected fault record 1 (see the communication parameters file).	



Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; DGT- &gt; PFH-

Code	Name / Description	Unit
<i>C P I</i>	<b>[Cmd word]</b> Command register of detected fault record 1 (same as <b>[Cmd word]</b> ( <i>C P d</i> ) page 56).	
<i>L C P I</i>	<b>[Motor current]</b> Estimated motor current of detected fault record 1 (same as <b>[Motor current]</b> ( <i>L C r</i> ) page 50).	A
<i>r F P I</i>	<b>[Output frequency]</b> Estimated motor frequency of detected fault record 1 (same as <b>[Output frequency]</b> ( <i>r F r</i> ) page 50).	Hz
<i>r t P I</i>	<b>[Elapsed time]</b> Elapsed run time of detected fault record 1 (same as <b>[Elapsed time]</b> ( <i>r t H</i> ) page 62).	h
<i>u L P I</i>	<b>[Mains voltage]</b> Main voltage of detected fault record 1 (same as <b>[Mains voltage]</b> ( <i>u L n</i> ) page 50).	V
<i>t H P I</i>	<b>[Motor thermal state]</b> Motor thermal state of detected fault record 1 (same as <b>[Motor thermal state]</b> ( <i>t H r</i> ) page 50).	%
<i>d C C I</i>	<b>[Command Channel]</b> Command channel of detected fault record 1 (same as <b>[Command channel]</b> ( <i>C P d C</i> ) page 56).	
<i>d r C I</i>	<b>[Channel ref. active]</b> Reference channel of detected fault record 1 (same as <b>[Channel ref. active]</b> ( <i>r F C C</i> ) page 56).	
<i>S r 1 I</i>	<b>[Saf01 Reg n-1]</b> SAF1 Register x (1 is last)	
<i>S r 2 I</i>	<b>[Saf02 Reg n-1]</b> SAF2 Register x (1 is last)	
<i>S r A I</i>	<b>[SF00 Reg n-1]</b> SF00 Register x (1 is last)	
<i>S r b I</i>	<b>[SF01 Reg n-1]</b> SF01 Register x (1 is last)	
<i>S r C I</i>	<b>[SF02 Reg n-1]</b> SF02 Register x (1 is last)	
<i>S r d I</i>	<b>[SF03 Reg n-1]</b> SF03 Register x (1 is last)	
<i>S r E I</i>	<b>[SF04 Reg n-1]</b> SF04 Register x (1 is last)	
<i>S r F I</i>	<b>[SF05 Reg n-1]</b> SF05 Register x (1 is last)	
<i>S r G I</i>	<b>[SF06 Reg n-1]</b> SF06 Register x (1 is last)	
<i>S r H I</i>	<b>[SF07 Reg n-1]</b> SF07 Register x (1 is last)	
<i>S r I I</i>	<b>[SF08 Reg n-1]</b> SF08 Register x (1 is last)	
<i>S r J I</i>	<b>[SF09 Reg n-1]</b> SF09 Register x (1 is last)	
<i>S r K I</i>	<b>[SF10 Reg n-1]</b> SF10 Register x (1 is last)	
<i>S r L I</i>	<b>[SF11 Reg n-1]</b> SF11 Register x (1 is last)	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; DGT- &gt; PFH-

Code	Name / Description	Unit
<b>PFH -</b>	<b>[FAULT HISTORY] (continued)</b> Shows the 8 last detected faults.	
<b>dP2</b>	<b>[Past fault 2]</b> [Saf1 Reg n-2] ( <i>Sr I2</i> ), [Saf2 Reg n-2] ( <i>Sr 22</i> ), [SF00 Reg n-2] ( <i>Sr A2</i> ), [SF01 Reg n-2] ( <i>Sr b2</i> ), and [SF02 Reg n-2] ( <i>Sr C2</i> ) to [SF11 Reg n-2] ( <i>Sr L2</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP3</b>	<b>[Past fault 3]</b> [Saf1 Reg n-3] ( <i>Sr I3</i> ), [Saf2 Reg n-3] ( <i>Sr 23</i> ), [SF00 Reg n-3] ( <i>Sr A3</i> ), [SF01 Reg n-3] ( <i>Sr b3</i> ), and [SF02 Reg n-3] ( <i>Sr C3</i> ) to [SF11 Reg n-3] ( <i>Sr L3</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP4</b>	<b>[Past fault 4]</b> [Saf1 Reg n-4] ( <i>Sr I4</i> ), [Saf2 Reg n-4] ( <i>Sr 24</i> ), [SF00 Reg n-4] ( <i>Sr A4</i> ), [SF01 Reg n-4] ( <i>Sr b4</i> ), and [SF02 Reg n-4] ( <i>Sr C4</i> ) to [SF11 Reg n-4] ( <i>Sr L4</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP5</b>	<b>[Past fault 5]</b> [Saf1 Reg n-5] ( <i>Sr I5</i> ), [Saf2 Reg n-5] ( <i>Sr 25</i> ), [SF00 Reg n-5] ( <i>Sr A5</i> ), [SF01 Reg n-5] ( <i>Sr b5</i> ), and [SF02 Reg n-5] ( <i>Sr C5</i> ) to [SF11 Reg n-5] ( <i>Sr L5</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP6</b>	<b>[Past fault 6]</b> [Saf1 Reg n-6] ( <i>Sr I6</i> ), [Saf2 Reg n-6] ( <i>Sr 26</i> ), [SF00 Reg n-6] ( <i>Sr A6</i> ), [SF01 Reg n-6] ( <i>Sr b6</i> ), and [SF02 Reg n-6] ( <i>Sr C6</i> ) to [SF11 Reg n-6] ( <i>Sr L6</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP7</b>	<b>[Past fault 7]</b> [Saf1 Reg n-7] ( <i>Sr I7</i> ), [Saf2 Reg n-7] ( <i>Sr 27</i> ), [SF00 Reg n-7] ( <i>Sr A7</i> ), [SF01 Reg n-7] ( <i>Sr b7</i> ), and [SF02 Reg n-7] ( <i>Sr C7</i> ) to [SF11 Reg n-7] ( <i>Sr L7</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	
<b>dP8</b>	<b>[Past fault 8]</b> [Saf1 Reg n-8] ( <i>Sr I8</i> ), [Saf2 Reg n-8] ( <i>Sr 28</i> ), [SF00 Reg n-8] ( <i>Sr A8</i> ), [SF01 Reg n-8] ( <i>Sr b8</i> ), and [SF02 Reg n-8] ( <i>Sr C8</i> ) to [SF11 Reg n-8] ( <i>Sr L8</i> ) may be visible with this parameter. Identical to <b>[Past fault 1] (dP 1)</b> page 64.	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; PFL-

Code	Name / Description	Unit
<b>d G E -</b>	<b>[DIAGNOSTICS] (continued)</b>	
<b>P F L -</b>	<b>[CURRENT FAULT LIST]</b>	
<i>n o F</i>	[No fault] ( <i>n o F</i> ): No detected fault stored	
<i>A S F</i>	[Angle error] ( <i>A S F</i> ): Angle setting detected fault	
<i>b L F</i>	[Brake control] ( <i>b L F</i> ): Brake's motor 3-phases loss	
<i>b r F</i>	[Brake feedback] ( <i>b r F</i> ): Brake contactor detected error	
<i>C F F</i>	[Incorrect config.] ( <i>C F F</i> ): Invalid configuration at power on	
<i>C F i 2</i>	[Bad conf] ( <i>C F i 2</i> ): Configuration transfer detected error	
<i>C n F</i>	[Com. network] ( <i>C n F</i> ): NET option communication interruption	
<i>C o F</i>	[CAN com.] ( <i>C o F</i> ): CANopen® communication interruption	
<i>C r F</i>	[Capa.charg] ( <i>C r F</i> ): Load relay detected fault	
<i>C S F</i>	[Ch.sw. fault] ( <i>C S F</i> ): Channel switching detected error	
<i>d L F</i>	[Load fault] ( <i>d L F</i> ): Dynamic load detected error	
<i>E E F 1</i>	[Control EEprom] ( <i>E E F 1</i> ): Control EEprom detected error	
<i>E E F 2</i>	[Power Eeprom] ( <i>E E F 2</i> ): Power EEprom detected error	
<i>E P F 1</i>	[External fault LI/Bit] ( <i>E P F 1</i> ): External detected fault from LI or local link	
<i>E P F 2</i>	[External fault com.] ( <i>E P F 2</i> ): External interruption from communication board	
<i>F b E</i>	[FB fault] ( <i>F b E</i> ): Function block detected error	
<i>F b E S</i>	[FB stop fly.] ( <i>F b E S</i> ): Function block stop detected error	
<i>F C F 1</i>	[Out. contact. stuck] ( <i>F C F 1</i> ): Output contactor: closed contactor	
<i>F C F 2</i>	[Out. contact. open.] ( <i>F C F 2</i> ): Output contactor: opened contactor	
<i>H C F</i>	[Cards pairing] ( <i>H C F</i> ): Hardware configuration detected error	
<i>H d F</i>	[IGBT desaturation] ( <i>H d F</i> ): Hardware detected error	
<i>i L F</i>	[Option int link] ( <i>i L F</i> ): Option internal link interruption	
<i>i n F 1</i>	[Rating error] ( <i>i n F 1</i> ): Unknown drive rating	
<i>i n F 2</i>	[PWR Calib.] ( <i>i n F 2</i> ): Unknown or incompatible power board	
<i>i n F 3</i>	[Int.serial link] ( <i>i n F 3</i> ): Internal serial link communication interruption	
<i>i n F 4</i>	[Int.Mfg area] ( <i>i n F 4</i> ): Invalid industrialization zone	
<i>i n F 5</i>	[Internal-option] ( <i>i n F 5</i> ): Unknown or incompatible option board	
<i>i n F 9</i>	[Internal- I measure] ( <i>i n F 9</i> ): Current measurement circuit detected error	
<i>i n F A</i>	[Internal-mains circuit] ( <i>i n F A</i> ): Input phase loss circuit detected error	
<i>i n F b</i>	[Internal- th. sensor] ( <i>i n F b</i> ): Thermal sensor detected error (OC or SC)	
<i>i n F E</i>	[Internal-CPU] ( <i>i n F E</i> ): CPU detected fault (ram, flash, task ...)	
<i>L C F</i>	[Input contactor] ( <i>L C F</i> ): Line contactor detected error	
<i>L F F 3</i>	[AI3 4-20mA loss] ( <i>L F F 3</i> ): AI3 4-20 mA loss	
<i>o b F</i>	[Overbraking] ( <i>o b F</i> ): Overbraking	
<i>o C F</i>	[Overcurrent] ( <i>o C F</i> ): Overcurrent	
<i>o H F</i>	[Drive overheat] ( <i>o H F</i> ): Drive overheating	
<i>o L C</i>	[Proc.Overload Flt] ( <i>o L C</i> ): Torque overload	
<i>o L F</i>	[Motor overload] ( <i>o L F</i> ): Motor overload	
<i>o P F 1</i>	[1 output phase loss] ( <i>o P F 1</i> ): Motor 1-phase loss	
<i>o P F 2</i>	[3out ph loss] ( <i>o P F 2</i> ): Motor 3-phases loss	
<i>o S F</i>	[Mains overvoltage] ( <i>o S F</i> ): Oversupply detected fault	
<i>o t F L</i>	[PTC fault] ( <i>o t F L</i> ): Motor overheating detected error from PTCL: standard product	
<i>P H F</i>	[Input phase loss] ( <i>P H F</i> ): Main input 1-phase loss	
<i>P t F L</i>	[LI6=PTC probe] ( <i>P t F L</i> ): PTCL detected error (OC or SC)	
<i>S A F F</i>	[Safety] ( <i>S A F F</i> ): Safety function	
<i>S C F 1</i>	[Motor short circuit] ( <i>S C F 1</i> ): Motor short circuit (hard detection)	
<i>S C F 3</i>	[Ground short circuit] ( <i>S C F 3</i> ): Direct ground short-circuit (hard detection)	
<i>S C F 4</i>	[IGBT short circuit] ( <i>S C F 4</i> ): IGBT short-circuit (hard detection)	
<i>S C F 5</i>	[Motor short circuit] ( <i>S C F 5</i> ): Load short-circuit during Igon load sequence (hard detection)	
<i>S L F 1</i>	[Modbus com.] ( <i>S L F 1</i> ): Modbus local serial communication interruption	
<i>S L F 2</i>	[PC com.] ( <i>S L F 2</i> ): PC Software communication interruption	
<i>S L F 3</i>	[HMI com.] ( <i>S L F 3</i> ): Remote terminal communication interruption	
<i>S o F</i>	[Overspeed] ( <i>S o F</i> ): Overspeed	
<i>S P F</i>	[Speed fdback loss] ( <i>S P F</i> ): Speed feedback loss	
<i>S S F</i>	[Torque/current lim] ( <i>S S F</i> ): Torque current limitation detected fault	
<i>t J F</i>	[IGBT overheat] ( <i>t J F</i> ): IGBT overheating	
<i>t n F</i>	[Auto-tuning] ( <i>t n F</i> ): Tune detected fault	
<i>u L F</i>	[Pr.Underload Flt] ( <i>u L F</i> ): Torque underload	
<i>u S F</i>	[Undervoltage] ( <i>u S F</i> ): Undervoltage	

Parameters described in this page can be accessed by:

DRI- &gt; MON- &gt; AFI-

Code	Name / Description	Unit
<b>AF I -</b>	<b>[MORE FAULT INFO]</b> Additional detected fault information.	
<b>LnF</b>	<b>[Network fault]</b> Communication option card fault code. This parameter is read-only. The fault code remains saved in the parameter, even if the cause disappears. The parameter is reset after the drive is disconnected and then reconnected. The values of this parameter depend on the network card. Consult the manual for the corresponding card.	
<b>ILFI</b>	<b>[Internal link fault 1]</b> Communication interruption between option card 1 and drive. This parameter is read-only. The fault code remains saved in the parameter, even if the cause disappears. The parameter is reset after the drive is disconnected and then reconnected.	
<b>SFFE</b>	<b>[Safety fault reg.] (1)</b> Safety function fault error register.  Bit0 = 1: Logic inputs debounce time-out (verify value of debounce time LIDT according to the application) Bit1 Reserved Bit2 = 1: Motor speed sign has changed during SS1 ramp Bit3 = 1: Motor speed has reached the frequency limit threshold during SS1 ramp. Bit4: Reserved Bit5: Reserved Bit6 = 1: Motor speed sign has changed during SLS limitation Bit7 = 1: Motor speed has reached the frequency limit threshold during SS1 ramp. Bit8: Reserved Bit9: Reserved Bit10: Reserved Bit11: Reserved Bit12: Reserved Bit13 = 1: Not possible to measure the motor speed (verify the motor wiring connection) Bit14 = 1: Motor ground short-circuit detected (verify the motor wiring connection) Bit15 = 1: Motor phase to phase short-circuit detected (verify the motor wiring connection)	
<b>SFFI</b>	<b>[Safety fault Reg1] (1)</b> Safety fault register 1. Application control error register.  Bit0 = 1: PWRM consistency detected error Bit1 = 1: Safety functions parameters detected error Bit2 = 1: Application auto test has detected an error Bit3 = 1: Diagnostic verification of safety function has detected an error Bit4 = 1: Logical input diagnostic has detected an error Bit5 = 1: SMS or GDL safety functions detected error (Details in <a href="#">[SAFF Subcode 4] SFD4</a> register page <a href="#">71</a> ) Bit6 = 1: Application watchdog management active Bit7 = 1: Motor control detected error Bit8 = 1: Internal serial link core detected error Bit9 = 1: Logical input activation detected error Bit10 = 1: Safe Torque Off function has triggered an error Bit11 = 1: Application interface has detected an error of the safety functions Bit12 = 1: Safe Stop 1 function has detected an error of the safety functions Bit13 = 1: Safely Limited Speed function has triggered an error Bit14 = 1: Motor data is corrupted Bit15 = 1: Internal serial link data flow detected error	

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:

SFFE = **0x0008** in HexadecimalSFFE = Bit **3**

Code	Name / Description	Unit
<b>SFF2</b>	<b>[Safety fault Reg2] (1)</b> Safety fault register 2 Motor Control error register Bit0 = 1 : Consistency stator frequency verification has detected an error Bit1 = 1 : Stator frequency estimation detected error Bit2 = 1 : Motor control watchdog management is active Bit3 = 1 : Motor control hardware watchdog is active Bit4 = 1 : Motor control auto test has detected an error Bit5 = 1 : Chain testing detected error Bit6 = 1 : Internal serial link core detected error Bit7 = 1 : Direct short-circuit detected error Bit8 = 1 : PWM driver detected error Bit9 = 1 : GDL internal detected error Bit10 : Reserved Bit11 = 1 : Application interface has detected an error of the safety functions Bit12 = 1 : Reserved Bit13: Reserved Bit14 = 1 : Motor data is corrupted Bit15 = 1 : Internal serial link data flow detected error	
<b>SF00</b>	<b>[SAFF Subcode 0] (1)</b> Safety fault subregister 00 Application auto test error register Bit0 : Reserved Bit1 = 1 : Ram stack overflow Bit2 = 1 : Ram address integrity error Bit3 = 1 : Ram data access error Bit4 = 1 : Flash Checksum Error Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 : Reserved Bit9 = 1 : Fast task overflow Bit10 = 1 : Slow task overflow Bit11 = 1 : Application task overflow Bit12 : Reserved Bit13 : Reserved Bit14 = 1 : PWRM line is not activated during initialization phase Bit15 = 1 : Application hardware Watch Dog is not running after initialization	
<b>SF01</b>	<b>[SAFF Subcode 1] (1)</b> Safety fault subregister 01 Logical input diagnostics error register Bit0 = 1 : Management - state machine error Bit1 = 1 : Data required for test management are corrupted Bit2 = 1 : Channel selection detected error Bit3 = 1 : Testing - state machine detected error Bit4 = 1 : Test request is corrupted Bit5 = 1 : Pointer to test method is corrupted Bit6 = 1 : Incorrect test action provided Bit7 = 1 : Detected Error in results collecting Bit8 = 1 : LI3 detected error. Cannot activate safe function Bit9 = 1 : LI4 detected error. Cannot activate safe function Bit10 = 1 : LI5 detected error. Cannot activate safe function Bit11 = 1 : LI6 detected error. Cannot activate safe function Bit12 = 1 : Test sequence updated while a diagnostic is in progress Bit13 = 1 : Detected error in test pattern management Bit14 : Reserved Bit15 : Reserved	

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:

SFFE = **0x0008** in Hexadecimal

SFFE = Bit **3**

Code	Name / Description	Unit
<b>S F 0 2</b>	<p><b>[SAFF Subcode 2] (1)</b></p> <p>Safety fault subregister 02 Application Watchdog Management detected error register</p> <p>Bit0 = 1 : Fast task detected error Bit1 = 1 : Slow task detected error Bit2 = 1 : Application task detected error Bit3 = 1 : Background task detected error Bit4 = 1 : Safety fast task/input detected error Bit5 = 1 : Safety slow task/input detected error Bit6 = 1 : Safety app task/input detected error Bit7 = 1 : Safety app task/treatment detected error Bit8 = 1 : Safety background task detected error Bit9 : Reserved Bit10 : Reserved Bit11 : Reserved Bit12 : Reserved Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved</p>	
<b>S F 0 3</b>	<p><b>[SAFF Subcode 3] (1)</b></p> <p>Safety fault subregister 03</p> <p>Bit0 = 1 : Debounce time out Bit1 = 1 : Input not consistent Bit2 = 1 : Consistency check - state machine detected error Bit3 = 1 : Consistency check - debounce timeout corrupted Bit4 = 1 : Response time data detected error Bit5 = 1 : Response time corrupted Bit6 = 1 : Undefined consumer queried Bit7 = 1 : Configuration detected error Bit8 = 1 : Inputs are not in nominal mode Bit9 : Reserved Bit10 : Reserved Bit11 : Reserved Bit12 : Reserved Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved</p>	
<b>S F 0 4</b>	<p><b>[SAFF Subcode 4] (1)</b></p> <p>Safety fault subregister 04 <b>[Safe Torque Off] S t o</b> detected error register</p> <p>Bit0 = 1 : No signal configured Bit1 = 1 : State machine detected error Bit2 = 1 : Internal data detected error Bit3 : Reserved Bit4 : Reserved Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 = 1 : SMS overspeed detected error Bit9 = 1 : SMS internal detected error Bit10 : Reserved Bit11 = 1 : GDL internal detected error 1 Bit12 = 1 : GDL internal detected error 2 Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved</p>	

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:

SFFE = **0x0008** in Hexadecimal

SFFE = Bit **3**

Code	Name / Description	Unit
<b>S F 0 5</b>	<p><b>[SAFF Subcode 5] (1)</b>            Safety fault subregister 05  <b>[Safe Stop 1] 5 5 /</b> detected error register            Bit0 = 1 : State machine detected error            Bit1 = 1 : Motor speed sign changed during stop            Bit2 = 1 : Motor speed reached trigger area            Bit3 = 1 : Theoretical motor speed corrupted            Bit4 = 1 : Unauthorized configuration            Bit5 = 1 : Theoretical motor speed computation detected error            Bit6 : Reserved            Bit7 = 1 : Speed sign check: consistency detected error            Bit8 = 1 : Internal SS1 request corrupted            Bit9 : Reserved            Bit10 : Reserved            Bit11 : Reserved            Bit12 : Reserved            Bit13 : Reserved            Bit14 : Reserved            Bit15 : Reserved</p>	
<b>S F 0 6</b>	<p><b>[SAFF Subcode 6] (1)</b>            Safety fault subregister 06  <b>[Safely Limited Speed] 5 L 5</b> detected error register            Bit0 = 1 : State machine error register            Bit1 = 1 : Motor speed sign changed during limitation            Bit2 = 1 : Motor speed has reached the frequency limit threshold            Bit3 = 1 : Data corruption            Bit4 : Reserved            Bit5 : Reserved            Bit6 : Reserved            Bit7 : Reserved            Bit8 : Reserved            Bit9 : Reserved            Bit10 : Reserved            Bit11 : Reserved            Bit12 : Reserved            Bit13 : Reserved            Bit14 : Reserved            Bit15 : Reserved</p>	
<b>S F 0 7</b>	<p><b>[SAFF Subcode 7] (1)</b>            Safety fault subregister 07            Application Watchdog Management detected error register            Bit0 : Reserved            Bit1 : Reserved            Bit2 : Reserved            Bit3 : Reserved            Bit4 : Reserved            Bit5 : Reserved            Bit6 : Reserved            Bit7 : Reserved            Bit8 : Reserved            Bit9 : Reserved            Bit10 : Reserved            Bit11 : Reserved            Bit12 : Reserved            Bit13 : Reserved            Bit14 : Reserved            Bit15 : Reserved</p>	

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:

SFFE = **0x0008** in Hexadecimal

SFFE = Bit **3**

Code	Name / Description	Unit
<b>S F 0 8</b>	<p><b>[SAFF Subcode 8] (1)</b></p> <p>Safety fault subregister 08 Application Watchdog Management detected error register</p> <p>Bit0 = 1 : PWM task detected error Bit1 = 1 : Fixed task detected error Bit2 = 1 : ATMC watchdog detected error Bit3 = 1 : DYNFCT watchdog detected error Bit4 : Reserved Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 : Reserved Bit9 : Reserved Bit10 : Reserved Bit11 : Reserved Bit12 : Reserved Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved</p>	
<b>S F 0 9</b>	<p><b>[SAFF Subcode 9] (1)</b></p> <p>Safety fault subregister 09 Motor control Auto Test detected error register</p> <p>Bit0 : Reserved Bit1 = 1 : Ram stack overflow Bit2 = 1 : Ram address integrity detected error Bit3 = 1 : Ram data access detected error Bit4 = 1 : Flash Checksum detected error Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 : Reserved Bit9 = 1 : 1ms task overflow Bit10 = 1 : PWM task overflow Bit11 = 1 : Fixed task overflow Bit12 : Reserved Bit13 : Reserved Bit14 = 1 : Unwanted interruption Bit15 = 1 : Hardware WD is not running after initialization</p>	
<b>S F 1 0</b>	<p><b>[SAFF Subcode 10] (1)</b></p> <p>Safety fault subregister 10 Motor control direct short-circuit detected error register</p> <p>Bit0 = 1 : Ground short circuit - Configuration detected error Bit1 = 1 : Phase to phase short circuit - Configuration detected error Bit2 = 1 : Ground short circuit Bit3 = 1 : Phase to phase short circuit Bit4 : Reserved Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 : Reserved Bit9 : Reserved Bit10 : Reserved Bit11 : Reserved Bit12 : Reserved Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved</p>	

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:

SFFE = **0x0008** in Hexadecimal

SFFE = Bit **3**



Code	Name / Description	Unit
<b>S F I I</b>	<b>[SAFF Subcode 11] (1)</b> Safety fault subregister 11 Motor Control dynamic check of activity detected error register Bit0 = 1 : Application requested a diagnostic of direct short circuit Bit1 = 1 : Application requested consistency verification of stator frequency estimation (voltage and current) Bit2 = 1 : Application requested diagnostic of SpdStat provided by Motor Control Bit3 : Reserved Bit4 : Reserved Bit5 : Reserved Bit6 : Reserved Bit7 : Reserved Bit8 = 1 : Motor Control safe diagnostic of direct short circuit is enabled Bit9 = 1 : Motor Control consistency check of stator frequency estimation is enabled Bit10 = 1 : Motor Control diagnostic of SpdStat provided by Motor Control is enabled Bit11 : Reserved Bit12 : Reserved Bit13 : Reserved Bit14 : Reserved Bit15 : Reserved	
<b>d G t -</b>	<b>[DIAGNOSTICS] (continued)</b>	
<b>t A C</b>	<b>[IGBT alarm counter]</b> Transistor alarm time counter (length of time the "IGBT temperature" alarm has been active).	
<b>t A C 2</b>	<b>[Min. freq time]</b> Transistor alarm time counter at minimum switching frequency (length of time the "IGBT temperature" alarm has been active after the drive has automatically reduced the switching frequency to the minimum value).	
<b>n t J</b>  ★	<b>[IGBT alarm Nb]</b> Transistor alarm counter: number detected during lifecycle.  Visible if [3.1 ACCESS LEVEL] ( <b>L A C</b> ) is set to [Expert] ( <b>E P r</b> ).	
<b>S E r -</b>	<b>[SERVICE MESSAGE]</b> See page 289.	
<b>r F L t</b>  <b>n o</b> <b>y E S</b>	<b>[Reset past faults]</b> Reset all resettable previous detected faults.  [No] ( <b>n o</b> ): Reset not active [YES] ( <b>y E S</b> ): Reset in progress	



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

(1) Hexadecimal values are displayed on the Graphic display terminal

Example:


SFFE = **0x0008** in Hexadecimal

SFFE = Bit **3**

Code	Name / Description	Unit
<b>Π α η -</b>	<b>[1.2 MONITORING] (continued)</b>	
<b>ϭ ο δ -</b>	<b>[PASSWORD]</b> HMI Password. If you have lost your code, please contact Schneider Electric.	
<b>ϭ 5 t</b>	<b>[State]</b> Status of the drive (lock/unlock). Information parameter, cannot be modified.	
<b>ℓ ℓ</b> <b>υ ℓ ℓ</b>	<b>[Locked] (ℓ ℓ)</b> : The drive is locked by a password <b>[Unlocked] (υ ℓ ℓ)</b> : The drive is not locked by a password	
<b>ϭ ο δ</b>	<b>[PIN code 1]</b> Confidential code.  Enables the drive configuration to be protected using an access code. When access is locked by means of a code, only the parameters in the <b>[1.2 MONITORING] (Π α η -)</b> and <b>[1.1 SPEED REFERENCE] (r E F -)</b> menus can be accessed. The MODE key can be used to switch between menus. <b>Note:</b> Before entering a code, do not forget to make a careful note of it.	
<b>ο F F</b> <b>ο η</b>	<b>[OFF] (ο F F)</b> : No access locking codes. - To lock access, enter a code (2 to 9,999). The display can be incremented using the jog dial. Then press ENT. <b>[ON] (ο η)</b> appears on the screen to indicate that access has been locked. <b>[ON] (ο η)</b> : A code is locking access (2 to 9,999). - To unlock access, enter the code (incrementing the display using the jog dial) and press ENT. The code remains on the display and access is unlocked until the next time the drive is turned off. Access will be locked again the next time the drive is turned on. - If an incorrect code is entered, the display changes to <b>[ON] (ο η)</b> , and access remains locked. Access is unlocked (the code remains on the screen). - To reactivate locking with the same code when access has been unlocked, return to <b>[ON] (ο η)</b> using the jog dial and then press ENT. <b>[ON] (ο η)</b> remains on the screen to indicate that access has been locked. - To lock access with a new code when access has been unlocked, enter the new code (increment the display using the jog dial) and then press ENT. <b>[ON] (ο η)</b> appears on the screen to indicate that access has been locked. - To clear locking when access has been unlocked, return to <b>[OFF] (ο F F)</b> using the jog dial and then press ENT. <b>[OFF] (ο F F)</b> remains on the display. Access is unlocked and will remain so until the next restart.	
<b>ϭ ο δ 2</b> ★	<b>[PIN code 2]</b> Confidential code 2. Visible if <b>[3.1 ACCESS LEVEL] (ℓ η ℓ)</b> is set to <b>[Expert] (E P r)</b> .	
<b>ο F F</b> <b>ο η</b>	The value <b>[OFF] (ο F F)</b> indicates that no password has been set <b>[Unlocked] (υ ℓ ℓ)</b> . The value <b>[ON] (ο η)</b> indicates that the drive configuration is protected and an access code must be entered in order to unlock it. Once the correct code has been entered, it remains on the display and the drive is unlocked until the next time the power supply is disconnected.	
<b>Β Β Β Β</b>	PIN code 2 is an unlock code known only to Schneider Electric Product Support.	
<b>υ ℓ r</b>	<b>[Upload rights]</b>	
<b>υ ℓ r 0</b> <b>υ ℓ r 1</b>	<b>[Permitted] (υ ℓ r 0)</b> : Means that SoMove or the graphic display terminal can save the whole configuration (password, protections, configuration). When the configuration is edited, only the non protected parameters will be accessible. <b>[Not allowed] (υ ℓ r 1)</b> : Means that SoMove or the graphic display terminal cannot save the configuration	
<b>d ℓ r</b>	<b>[Download rights]</b>	
<b>d ℓ r 0</b> <b>d ℓ r 1</b> <b>d ℓ r 2</b> <b>d ℓ r 3</b>	<b>[Locked drv] (d ℓ r 0)</b> : Locked drive: means that the configuration can be downloaded only in a locked drive which configuration has the same password. If the passwords are different, download is not permitted. <b>[Unlocked drv] (d ℓ r 1)</b> : Unlocked drive: means that the configuration can be downloaded only in a drive without active password <b>[Not allowed] (d ℓ r 2)</b> : Not allowed: the configuration cannot be downloaded <b>[Lock/unlock] (d ℓ r 3)</b> : Lock. + Not: download is permitted following case 0 or case 1	



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.



## Configuration Mode (ConF)



# 5

---

### What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Introduction	<a href="#">78</a>
Organization tree	<a href="#">79</a>
My Menu	<a href="#">80</a>
Factory Settings	<a href="#">81</a>
Macro Configuration	<a href="#">82</a>
Full	<a href="#">85</a>


## Introduction

Configuration mode includes 4 parts:

1. "My Menu" menu includes up to 25 parameters available for user customization using the graphic display terminal or SoMove software.
2. Store/recall parameter set: These 2 functions are used to store and recall customer settings.
3. **[Macro configuration]** (C F G) parameter which allows to load predefined values for applications (see page [82](#)).
4. FULL: This menu provides access to all other parameters. It includes 10 sub-menus:
  - **[SIMPLY START]** (S , Π -) page [85](#)
  - **[SETTINGS]** (S E t -) page [89](#)
  - **[MOTOR CONTROL]** (d r C -) page [105](#)
  - **[INPUTS / OUTPUTS CFG]** ( i - o -) page [125](#)
  - **[COMMAND]** (C t L -) page [154](#)
  - **[FUNCTION BLOCK]** (F b Π -) page [158](#)
  - **[APPLICATION FUNCT.]** (F u n -) page [167](#)
  - **[FAULT MANAGEMENT]** (F L t -) page [250](#)
  - **[COMMUNICATION]** (C o Π -) page [275](#)
  - **[ACCESS LEVEL]** (L # C) page [280](#)

### Organization tree

Displayed parameter values are given as examples.



Parameters described in this page can be accessed by:

DRI- > CONF > MYMN-

## My Menu

Code	Name / Description
<a href="#">C o n F</a>	<a href="#">[1.3 CONFIGURATION]</a>
<a href="#">M Y M N</a>	<a href="#">[MY MENU]</a>
	This menu contains the parameters selected in the <a href="#">[3.4 DISPLAY CONFIG.]</a> ( <a href="#">d C F -</a> ) menu on page <a href="#">287</a> .

### Factory Settings

Code	Name / Description	Factory setting
<b>C o n F</b>	<b>[1.3 CONFIGURATION]</b>	
<b>F C S -</b>	<b>[FACTORY SETTINGS]</b>	
<b>F C S ,</b>	<p><b>[Config. Source]</b></p> <p>Choice of source configuration. If the configuration switching function is configured, it will not be possible to access <b>[Config 1] (C F G 1)</b> and <b>[Config 2] (C F G 2)</b>.</p> <p><b>Note:</b> To load the drive's presets previously stored (<b>[Config 1] (5 t r 1)</b> or <b>[Config 2] (5 t r 2)</b>), select the source configuration <b>[Config. Source] (F C S ,)</b> = <b>[Config 1] (C F G 1)</b> or <b>[Config 2] (C F G 2)</b> followed by a factory setting <b>[Goto FACTORY SETTINGS] (G F 5)</b> = <b>[YES] (Y E 5)</b>.</p> <p><b>[Macro-Conf] ( , n i ):</b> Factory configuration, return to selected macro configuration  <b>[Config 1] (C F G 1):</b> Configuration 1  <b>[Config 2] (C F G 2):</b> Configuration 2</p>	<b>[Macro-Conf] ( , n i )</b>
<b>F r y -</b>	<p><b>[PARAMETER GROUP LIST]</b></p> <p>Selection of menus to be loaded. See the multiple selection procedure on page 33 for the integrated display terminal and page 24 for the graphic display terminal. <b>Note:</b> In factory configuration and after a return to "factory settings", <b>[PARAMETER GROUP LIST]</b> will be empty.</p> <p><b>[All] (A L L):</b> All parameters (the function blocks program will also be erased)  <b>[Drive configuration] (d r n):</b> The <b>[1 DRIVE MENU] (d r , -)</b> menu without <b>[COMMUNICATION] (C o n -)</b>. In the <b>[2.4 DISPLAY CONFIG.]</b> menu, <b>[Return std name] (G 5 P)</b> page 289 returns to <b>[No] (n o)</b>.  <b>[Motor param] (n o t):</b> Motor parameters, see page 297.                      The following selections can only be accessed if <b>[Config. Source] (F C S ,)</b> is set to <b>[Macro-Conf.] ( , n i )</b>.  <b>[Comm. menu] (C o n):</b> The <b>[COMMUNICATION] (C o n -)</b> menu without either <b>[Scan. In1 address] (n n A 1)</b> to <b>[Scan. In8 address] (n n A 8)</b> or <b>[Scan.Out1 address] (n C A 1)</b> to <b>[Scan.Out8 address] (n C A 8)</b>.  <b>[Display config.] (d , 5):</b> The <b>[3.3 MONITORING CONFIG.] (n C F -)</b> menu</p>	
<b>G F 5</b>	<p><b>[Goto FACTORY SETTINGS]</b></p> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>⚠ WARNING</b></p> <p><b>UNANTICIPATED EQUIPMENT OPERATION</b></p> <p>Verify that restoring the factory settings is compatible with the type of wiring used.  <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>It is only possible to revert to the factory settings if at least one group of parameters has previously been selected.</p> <p><b>[No] (n o):</b> No  <b>[Yes] (Y E 5):</b> The parameter changes back to <b>[No] (n o)</b> automatically as soon as the operation is complete</p>	
<b>G C S ,</b>	<p><b>[Save config]</b></p> <p>The active configuration to be saved does not appear for selection. For example, if it is <b>[Config 0] (5 t r 0)</b>, only <b>[Config 1] (5 t r 1)</b> and <b>[Config 2] (5 t r 2)</b> appear. The parameter changes back to <b>[No] (n o)</b> as soon as the operation is complete.</p> <p><b>[No] (n o):</b> No  <b>[Config 0] (5 t r 0):</b> Press and hold down the ENT key for 2 s  <b>[Config 1] (5 t r 1):</b> Press and hold down the ENT key for 2 s  <b>[Config 2] (5 t r 2):</b> Press and hold down the ENT key for 2 s</p>	<b>[No] (n o)</b>

These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



2 s To change the assignment of this parameter, press the ENT key for 2 s.



Parameters described in this page can be accessed by:

DRI- &gt; CONF

## Macro Configuration

Code	Name / Description	Factory setting
<b>C o n F</b>	<b>[1.3 CONFIGURATION] (continued)</b>	
<b>C F G</b>	<b>[Macro configuration]</b>	<b>[Start/Stop] (S t S)</b>
	<b>⚠ WARNING</b>	
 2 s	<b>UNANTICIPATED EQUIPMENT OPERATION</b> Verify that the selected macro configuration is compatible with the type of wiring used. <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>	
<b>S t S</b>	<b>[Start/Stop] (S t S):</b> Start/stop	
<b>H d G</b>	<b>[M. handling] (H d G):</b> Handling	
<b>H S t</b>	<b>[Hoisting] (H S t):</b> Hoisting	
<b>G E n</b>	<b>[Gen. Use] (G E n):</b> General use	
<b>P i d</b>	<b>[PID regul.] (P i d):</b> PID regulation	
<b>n E t</b>	<b>[Network C.] (n E t):</b> Communication bus	



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



To change the assignment of this parameter, press the ENT key for 2 s.

## Example of total return to factory settings

- **[Config. Source] (F C S i)** is set to **[Macro-Conf] ( i n i)**
- **[PARAMETER GROUP LIST] (F r Y -)** is set to **[All] (R L L)**
- **[Goto FACTORY SETTINGS] (G F S)** is set to **[Yes] (Y E S)**

## Assignment of the inputs/outputs

Input/output	[Start/Stop]	[M. handling]	[Gen. Use]	[Hoisting]	[PID regul.]	[Network C.]
[AI1]	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel]	[Ref.1 channel] (PID reference)	[Ref.2 channel] ([Ref.1 channel] = integrated Modbus) (1)
[AI2]	[No]	[Summing ref. 2]	[Summing ref. 2]	[No]	[PID feedback]	[No]
[AI3]	[No]	[No]	[No]	[No]	[No]	[No]
[AO1]	[No]	[No]	[No]	[No]	[No]	[No]
[R1]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]	[No drive flt]
[R2]	[No]	[No]	[No]	[Brk control]	[No]	[No]
[LI1] (2-wire)	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]
[LI2] (2-wire)	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]
[LI3] (2-wire)	[No]	[2 preset speeds]	[Jog]	[Fault reset]	[PID integral reset]	[Ref. 2 switching]
[LI4] (2-wire)	[No]	[4 preset speeds]	[Fault reset]	[External fault]	[2 preset PID ref.]	[Fault reset]
[LI5] (2-wire)	[No]	[8 preset speeds]	[Torque limitation]	[No]	[4 preset PID ref.]	[No]
[LI6] (2-wire)	[No]	[Fault reset]	[No]	[No]	[No]	[No]
[LI1] (3-wire)	[Drive running]	[Drive running]	[Drive running]	[Drive running]	[Drive running]	[Drive running]
[LI2] (3-wire)	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]	[Forward]
[LI3] (3-wire)	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]	[Reverse]
[LI4] (3-wire)	[No]	[2 preset speeds]	[Jog]	[Fault reset]	[PID integral reset]	[Ref. 2 switching]
[LI5] (3-wire)	[No]	[4 preset speeds]	[Fault reset]	[External fault]	[2 preset PID ref.]	[Fault reset]
[LI6] (3-wire)	[No]	[8 preset speeds]	[Torque limitation]	[No]	[4 preset PID ref.]	[No]
[LO1]	[No]	[No]	[No]	[No]	[No]	[No]
Graphic display terminal keys						
F1 key	[No]	[No]	[No]	[No]	[No]	Control via graphic display terminal
F2, F3, F4 keys	[No]	[No]	[No]	[No]	[No]	[No]

In 3-wire control, the assignment of inputs LI1 to LI6 shifts.

(1) To start with, integrated Modbus **[Modbus Address] (F d d)** must first be configured, page [276](#).

**Note:** These assignments are reinitialized every time the macro configuration changes.

## Other configurations and settings

In addition to the assignment of inputs/outputs, other parameters are assigned **only in the Hoisting macro configuration**.

### Hoisting:

- [Movement type] (*b 5 t*) is set to [Hoisting] (*u E r*) page 194
- [Brake contact] (*b C i*) is set to [No] (*n o*) page 194
- [Brake impulse] (*b i P*) is set to [Yes] (*y E 5*) page 194
- [Brake release I FW] (*i b r*) is set to 0 A page 194
- [Brake Release time] (*b r t*) is set to 0 s page 194
- [Brake release freq] (*b i r*) is set to [Auto] (*R u t o*) page 195
- [Brake engage freq] (*b E n*) is set to [Auto] (*R u t o*) page 195
- [Brake engage time] (*b E t*) is set to 0 s page 195
- [Engage at reversal] (*b E d*) is set to [No] (*n o*) page 195
- [Jump at reversal] (*J d C*) is set to [Auto] (*R u t o*) page 195
- [Time to restart] (*t t r*) is set to 0 s page 196
- [Current ramp time] (*b r r*) is set to 0 s page 198
- [Low speed] (*L 5 P*) is set to Rated motor slip calculated by the drive, page 87
- [Output Phase Loss] (*o P L*) is set to [Yes] (*y E 5*) page 256  
No further modifications can be made to this parameter.
- [Catch on the fly] (*F L r*) is set to [No] (*n o*) page 253  
No further modifications can be made to this parameter.


### Return to factory settings:

Returning to factory settings with [Config. Source] (*F C 5 i*) is set to [Macro-Conf] (*i n i*) page 81 will return the drive to the selected macro configuration. The [Macro configuration] (*C F G*) parameter does not change, although [Customized macro] (*C C F G*) disappears.

**Note:** The factory settings that appear in the parameter tables correspond to

[Macro configuration] (*C F G*) = [Start/Stop] (*5 t 5*). This is the macro configuration set at the factory.

## Example diagrams for use with the macro configurations



- (1) Without integrated safety function, a contact on the Preventa module must be inserted in the brake control circuit to engage it when the "Safe Torque Off" safety function is activated (see connection diagrams in the Installation manual).

**Full**







Code	Name / Description	Adjustment range	Factory setting
<b>ConF</b>	<b>[1.3 CONFIGURATION]</b>		
<b>FULL</b>	<b>[FULL]</b>		
<b>5, 11 -</b>	<b>[SIMPLY START]</b>		
<b>EEE</b>	<b>[2/3 wire control]</b>		<b>[2 wire] (EE)</b>
<div style="display: flex; align-items: center;">  2 s                 </div>	<div style="border: 1px solid black; padding: 10px; margin-bottom: 10px;"> <h3 style="margin: 0;">⚠ WARNING</h3> <p><b>UNANTICIPATED EQUIPMENT OPERATION</b>                      If this parameter is changed, the parameters <b>[Reverse assign.] (rr5)</b> and <b>[2 wire type] (EEE)</b> and the assignments of the digital inputs are reset to the factory setting.                      Verify that this change is compatible with the type of wiring used.  <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>See <b>[2/3 wire control] (EEE)</b> page <a href="#">125</a>.</p> <p><b>EE [2 wire] (EE)</b>  <b>2-wire control (level commands):</b> This is the input state (0 or 1) or edge (0 to 1 or 1 to 0), which controls running or stopping.</p> <p>Example of "source" wiring:</p> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p>L1: forward Lx: reverse</p> </div> </div> <p><b>EE [3 wire] (EE)</b>  <b>3-wire control (pulse commands):</b> A "forward" or "reverse" pulse is sufficient to command starting, a "stop" pulse is sufficient to command stopping.</p> <p>Example of "source" wiring:</p> <div style="display: flex; align-items: center;"> <div> <p>L1: stop L2: forward Lx: reverse</p> </div> </div>		
<b>CFG</b>	<b>[Macro configuration]</b>		<b>[Start/Stop] (SES)</b>
<div style="display: flex; align-items: center;"> <div style="margin-left: 10px;"> <div style="display: flex; align-items: center;">  2 s                     </div> </div> </div>	<div style="border: 1px solid black; padding: 10px; margin-bottom: 10px;"> <h3 style="margin: 0;">⚠ WARNING</h3> <p><b>UNANTICIPATED EQUIPMENT OPERATION</b>                      Verify that the selected macro configuration is compatible with the type of wiring used.  <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>See <b>[Macro configuration] (CFG)</b> page <a href="#">82</a>.</p> <p><b>SES [Start/Stop] (SES):</b> Start/stop  <b>HdG [M. handling] (HdG):</b> Handling  <b>HSE [Hoisting] (HSE):</b> Hoisting  <b>Gen [Gen. Use] (Gen):</b> General use  <b>Pid [PID regul.] (Pid):</b> PID regulation  <b>NEE [Network C.] (NEE):</b> Communication bus</p>		

Parameters described in this page can be accessed by:

DRI -&gt; CONF &gt; FULL &gt; SIM-

Code	Name / Description	Adjustment range	Factory setting
<b>CCFG</b> ★	<b>[Customized macro]</b> Read-only parameter, only visible if at least one macro configuration parameter has been modified.  no [No] (no): No YES [Yes] (YES): Yes		
<b>bFr</b>  50 60	<b>[Standard mot. freq]</b> This parameter modifies the presets of the following parameters: <b>[Rated motor volt.]</b> (u n S) below, <b>[High speed]</b> (H S P) page 87, <b>[Freq. threshold]</b> (F E d) page 102, <b>[Rated motor freq.]</b> (F r S) and <b>[Max frequency]</b> (E F r) .  50 <b>[50Hz IEC]</b> (50): Drive 50 Hz 60 <b>[60Hz NEMA]</b> (60): Drive 60 Hz		<b>[50Hz IEC]</b> (50)
<b>iPL</b> ★	<b>[Input phase loss]</b> This parameter is only accessible in this menu on 3-phase drives. If one phase disappears, the drive switches to fault mode <b>[Input phase loss]</b> (P H F), but if 2 or 3 phases disappear, the drive continues to operate until it trips on an undervoltage detected fault (the drive trips in <b>[Input phase loss]</b> (P H F) if there is an input phase loss and if this leads to performance decrease). See <b>[Input phase loss]</b> (i P L) page 256.  no <b>[Ignore]</b> (no): Detected fault ignored, to be used when the drive is supplied via a single-phase supply or by the DC bus YES <b>[Freewheel]</b> (YES): With freewheel stop		Yes or No, according to drive rating
<b>nPr</b> ★	<b>[Rated motor power]</b> Rated motor power given on the nameplate, in kW if <b>[Standard mot. freq]</b> (b F r) is set to <b>[50Hz IEC]</b> (50), in HP if <b>[Standard mot. freq]</b> (b F r) is set to <b>[60Hz NEMA]</b> (60). See <b>[Rated motor power]</b> (n P r) page 107.		According to drive rating
<b>u n S</b> ★	<b>[Rated motor volt.]</b> Rated motor voltage given on the nameplate. ATV320●●●M2●: 100 to 240 V – ATV320●●●N4●: 200 to 480 V. See <b>[Rated motor volt.]</b> (u n S) page 107.	100 to 480 V	According to drive rating
<b>nCr</b> ★	<b>[Rated mot. current]</b> Rated motor current given on the nameplate. See <b>[Rated mot. current]</b> (n C r) page 107.	0.25 to 1.5 In (1)	According to drive rating and <b>[Standard mot. freq]</b> (b F r)
<b>F r S</b> ★	<b>[Rated motor freq.]</b> Rated motor frequency given on the nameplate. The factory setting is 50 Hz, or preset to 60 Hz if <b>[Standard mot. freq]</b> (b F r) is set to 60 Hz. This parameter is not visible if <b>[Motor control type]</b> (E E E) page 105 is set to <b>[Sync. mot.]</b> (S Y n). See <b>[Rated motor freq.]</b> (F r S) page 107.	10 to 800 Hz	50 Hz
<b>n S P</b> ★	<b>[Rated motor speed]</b> Rated motor speed given on the nameplate. This parameter is not visible if <b>[Motor control type]</b> (E E E) page 105 is set to <b>[Sync. mot.]</b> (S Y n). See <b>[Rated motor speed]</b> (n S P) page 107. 0 to 9,999 rpm then 10.00 to 60.00 krpm on the integrated display terminal. If, rather than the rated speed, the nameplate indicates the synchronous speed and the slip in Hz or as a %, calculate the rated speed as follows:  ★ Nominal speed = Synchronous speed x $\frac{100 - \text{slip as a \%}}{100}$ or Nominal speed = Synchronous speed x $\frac{50 - \text{slip in Hz}}{50}$ (50 Hz motors) or Nominal speed = Synchronous speed x $\frac{60 - \text{slip in Hz}}{60}$ (60 Hz motors)	0 to 65,535 rpm	According to drive rating


**Parameters described in this page can be accessed by:** DRI- > CONF > FULL > SIM-

Code	Name / Description	Adjustment range	Factory setting
<i>EFr</i>	<b>[Max frequency]</b> The factory setting is 60 Hz, or preset to 72 Hz if <b>[Standard mot. freq]</b> ( <i>bFr</i> ) is set to 60 Hz. The maximum value is limited by the following conditions: It must not exceed 10 times the value of <b>[Rated motor freq.]</b> ( <i>Fr5</i> ).  See <b>[Max frequency]</b> ( <i>EFr</i> ) page 105.	10 to 599 Hz	60 Hz
<i>Aut</i> 	<b>[Auto tuning]</b> For asynchronous motors, see page 108. For synchronous motors, see page 113.		<b>[No action]</b> ( <i>no</i> )
<i>AutS</i>	<b>[Auto tuning state]</b> This parameter is not saved at drive power off. It shows the Autotuning status since last power on. See <b>[Auto tuning state]</b> ( <i>AutS</i> ) page 108.		<b>[Not done]</b> ( <i>AB</i> )
<i>AB</i> <i>PENd</i> <i>PrOG</i> <i>FAiL</i> <i>donE</i>	<b>[Not done]</b> ( <i>AB</i> ): Autotune is not done <b>[Pending]</b> ( <i>PENd</i> ): Autotune has been requested but not yet performed <b>[In Progress]</b> ( <i>PrOG</i> ): Autotune is in progress <b>[Failed]</b> ( <i>FAiL</i> ): Autotune has detected a fault <b>[Done]</b> ( <i>donE</i> ): The stator resistance measured by the auto-tuning function is used to control the motor		
<i>Stun</i>	<b>[Tune selection]</b> See <b>[Tune selection]</b> ( <i>Stun</i> ) page 108.		<b>[Default]</b> ( <i>AB</i> )
<i>AB</i> <i>MEAS</i> <i>CU5</i>	<b>[Default]</b> ( <i>AB</i> ): The default stator resistance value is used to control the motor <b>[Measure]</b> ( <i>MEAS</i> ): The stator resistance measured by the auto-tuning function is used to control the motor <b>[Custom]</b> ( <i>CU5</i> ): The stator resistance set manually is used to control the motor		
<i>iEH</i> 	<b>[Mot. therm. current]</b> Motor thermal protection current, to be set to the rated current indicated on the motor nameplate. See <b>[Mot. therm. current]</b> ( <i>iEH</i> ) page 90.	0.2 to 1.5 In (1)	According to drive rating
<i>ACC</i> 	<b>[Acceleration]</b> Time to accelerate from 0 to the <b>[Rated motor freq.]</b> ( <i>Fr5</i> ) (page 86). To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Acceleration]</b> ( <i>ACC</i> ) page 89.	0.00 to 6,000 s (2)	3.0 s
<i>DEC</i> 	<b>[Deceleration]</b> Time to decelerate from the <b>[Rated motor freq.]</b> ( <i>Fr5</i> ) (page 86) to 0. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Deceleration]</b> ( <i>DEC</i> ) page 89.	0.00 to 6,000 s (2)	3.0 s
<i>LSP</i> 	<b>[Low speed]</b> Motor frequency at minimum reference, can be set between 0 and <b>[High speed]</b> ( <i>HSP</i> ). See <b>[Low speed]</b> ( <i>LSP</i> ) page 89.	0 to 599 Hz	0
<i>HSP</i> 	<b>[High speed]</b> Motor frequency at maximum reference, can be set between <b>[Low speed]</b> ( <i>LSP</i> ) and <b>[Max frequency]</b> ( <i>EFr</i> ). The factory setting changes to 60 Hz if <b>[Standard mot. freq]</b> ( <i>bFr</i> ) is set to <b>[60Hz NEMA]</b> ( <i>BD</i> ). See <b>[High speed]</b> ( <i>HSP</i> ) page 89.	0 to 599 Hz	50 Hz

(1) In corresponds to the rated drive current indicated in the Installation manual and on the drive nameplate.  
(2) Range 0.01 to 99.99 s or 0.1 to 999.9 s or 1 to 6,000 s according to **[Ramp increment]** (*inc*) page 170.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.




To change the assignment of this parameter, press the ENT key for 2 s.

## Settings

### With integrated display terminal

It is recommended to stop the motor before modifying any of the settings.

From **ConF** menu



The adjustment parameters can be modified with the drive running or stopped.

Code	Name / Description	Adjustment range	Factory setting
<b>FULL</b>	<b>[FULL] (continued)</b>		
<b>SEt -</b>	<b>[SETTINGS]</b>		
<b>inr</b> ( )	<b>[Ramp increment]</b>  This parameter is valid for <b>[Acceleration] (ACC)</b> , <b>[Deceleration] (DEC)</b> , <b>[Acceleration 2] (AC2)</b> and <b>[Deceleration 2] (DE2)</b> . See <b>[Ramp increment] (inr)</b> page 170.  D.D I [0,01]: Ramp up to 99.99 seconds D. I [0,1]: Ramp up to 999.9 seconds I [1]: Ramp up to 6,000 seconds		0.1
<b>ACC</b> ( )	<b>[Acceleration]</b>  Time to accelerate from 0 to the <b>[Rated motor freq.] (Fr5)</b> page 86. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Acceleration] (ACC)</b> page 170.	0.00 to 6,000 s (1)	3.0 s
<b>DEC</b> ( )	<b>[Deceleration]</b>  Time to decelerate from the <b>[Rated motor freq.] (Fr5)</b> page 86 to 0. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Deceleration] (DEC)</b> page 170.	0.00 to 6,000 s (1)	3.0 s
<b>AC2</b> ★ ( )	<b>[Acceleration 2]</b>  Time to accelerate from 0 to the <b>[Rated motor freq.] (Fr5)</b> page 86. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Acceleration 2] (AC2)</b> page 171.	0.00 to 6,000 s (1)	5 s
<b>DE2</b> ★ ( )	<b>[Deceleration 2]</b>  Time to decelerate from the <b>[Rated motor freq.] (Fr5)</b> page 86 to 0. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. See <b>[Deceleration 2] (DE2)</b> page 171.	0.00 to 6,000 s (1)	5 s
<b>EA1</b> ★ ( )	<b>[Begin Acc round]</b>  Rounding of start of acceleration ramp as a % of the <b>[Acceleration] (ACC)</b> or <b>[Acceleration 2] (AC2)</b> ramp time. Visible if <b>[Ramp type] (rPE)</b> is set to <b>[Customized] (CU5)</b> . See <b>[Begin Acc round] (EA1)</b> page 170.	0 to 100%	10%
<b>EA2</b> ★ ( )	<b>[End Acc round]</b>  Rounding of end of acceleration ramp as a % of the <b>[Acceleration] (ACC)</b> or <b>[Acceleration 2] (AC2)</b> ramp time. Can be set between 0 and 100% - <b>[Begin Acc round] (EA1)</b> . Visible if <b>[Ramp type] (rPE)</b> is set to <b>[Customized] (CU5)</b> . See <b>[End Acc round] (EA2)</b> page 171.	0 to 100%	10%
<b>EA3</b> ★ ( )	<b>[Begin Dec round]</b>  Rounding of start of deceleration ramp as a % of the <b>[Deceleration] (DEC)</b> or <b>[Deceleration 2] (DE2)</b> ramp time. Visible if <b>[Ramp type] (rPE)</b> is set to <b>[Customized] (CU5)</b> . See <b>[Begin Dec round] (EA3)</b> page 171.	0 to 100%	10%
<b>EA4</b> ★ ( )	<b>[End Dec round]</b>  Rounding of end of deceleration ramp as a % of the <b>[Deceleration] (DEC)</b> or <b>[Deceleration 2] (DE2)</b> ramp time. Can be set between 0 and 100% - <b>[Begin Dec round] (EA3)</b> . Visible if <b>[Ramp type] (rPE)</b> is set to <b>[Customized] (CU5)</b> . See <b>[End Dec round] (EA4)</b> page 171.	0 to 100%	10%
<b>L5P</b> ( )	<b>[Low speed]</b>  Motor frequency at minimum reference, can be set between 0 and <b>[High speed] (H5P)</b> page 87. See <b>[Low speed] (L5P)</b> page 87.	0 to 599 Hz	0 Hz
<b>H5P</b> ( )	<b>[High speed]</b>  Motor frequency at maximum reference, can be set between <b>[Low speed] (L5P)</b> and <b>[Max frequency] (EFR)</b> . The factory setting changes to 60 Hz if <b>[Standard mot. freq] (BFR)</b> is set to <b>[60Hz NEMA] (BD)</b> . See <b>[High speed] (H5P)</b> page 87.	0 to 599 Hz	50 Hz



Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-


Code	Name / Description	Adjustment range	Factory setting
<b>HSP2</b> ★ ( )	<b>[High speed 2]</b> Visible if <b>[2 High speed]</b> (SH2) is not set to <b>[No]</b> (n0). See <b>[High speed 2]</b> (HSP2) page 244.	0 to 599 Hz	50 Hz
<b>HSP3</b> ★ ( )	<b>[High speed 3]</b> Visible if <b>[4 High speed]</b> (SH4) is not set to <b>[No]</b> (n0). See <b>[High speed 3]</b> (HSP3) page 244.	0 to 599 Hz	50 Hz
<b>HSP4</b> ★ ( )	<b>[High speed 4]</b> Visible if <b>[4 High speed]</b> (SH4) is not set to <b>[No]</b> (n0). See <b>[High speed 4]</b> (HSP4) page 244.	0 to 599 Hz	50 Hz
<b>IEH</b> ( )	<b>[Mot. therm. current]</b> Motor thermal protection current, to be set to the rated current indicated on the motor nameplate. See <b>[Mot. therm. current]</b> (IEH) page 87.	0.2 to 1.5 In (2)	According to drive rating
<b>IFr</b> ( )	<b>[IR compensation]</b> IR compensation. See <b>[IR compensation]</b> (IFr) page 118.	0 to 200%	100%
<b>SLP</b> ★ ( )	<b>[Slip compensation]</b> Slip compensation. See <b>[Slip compensation]</b> (SLP) page 118.	0 to 300%	100%
<b>SFC</b> ★ ( )	<b>[K speed loop filter]</b> Speed filter coefficient. See <b>[K speed loop filter]</b> (SFC) page 118.	0 to 100	65
<b>SIE</b> ★ ( )	<b>[Speed time integral]</b> Speed loop integral time constant. See <b>[Speed time integral]</b> (SIE) page 118.	1 to 65,535 ms	63 ms
<b>SPG</b> ★ ( )	<b>[Speed prop. gain]</b> Speed loop proportional gain. See <b>[Speed prop. gain]</b> (SPG) page 118.	0 to 1,000%	40%
<b>SPGμ</b> ★ ( )	<b>[UF inertia comp.]</b> Inertia factor. See <b>[UF inertia comp.]</b> (SPGμ) page 118.	0 to 1,000%	40%

(1) Range 0.01 to 99.99 s or 0.1 to 999.9 s or 1 to 6,000 s according to **[Ramp increment]** (Inr) page 170.

(2) In corresponds to the rated drive current indicated in the Installation manual or on the drive nameplate.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.


**Parameter settings for [K speed loop filter] (SFL), [Speed prop. gain] (SPG) and [Speed time integral] (SIT)**

The following parameters can be accessed if [Motor control type] (LTL) page 105 is set to [SVC V] (LVL), [Sync. mot.] (SYN) or [Energy Sav.] (ELD).

**General Case: Setting for [K speed loop filter] (SFL) = 0**

The regulator is an "IP" type with filtering of the speed reference, for applications requiring flexibility and stability (hoisting or high inertia, for example).

- [Speed prop. gain] (SPG) affects excessive speed.
- [Speed time integral] (SIT) affects the passband and response time.




**Special case: Parameter [K speed loop filter] (5FC) is not 0**

This parameter must be reserved for specific applications that require a short response time (trajectory positioning or servo control).

- When set to 100 as described above, the regulator is a "PI" type, without filtering of the speed reference.
- Settings between 0 and 100 will obtain an intermediate function between the settings below and those on the previous page.

Example: Setting for [K speed loop filter] (5FC) = 100

- [Speed prop. gain] (5PG) affects the passband and response time.
- [Speed time integral] (5LE) affects excessive speed.



Code	Name / Description	Adjustment range	Factory setting
<b>d C F</b> ★ ( )	<b>[Ramp divider]</b> Deceleration ramp time reduction. See <b>[Ramp divider]</b> (d C F) page <a href="#">173</a> .	0 to 10	4
<b>i d C</b> ★ ( )	<b>[DC inject. level 1]</b> Level of DC injection braking current activated via logic input or selected as stop mode. See <b>[DC inject. level 1]</b> (i d C) page <a href="#">174</a> .	0.1 to 1.41 In (1)	0.64 In (1)
<b>t d i</b> ★ ( )	<b>[DC injection time 1]</b> Maximum current injection time <b>[DC inject. level 1]</b> (i d C). After this time, the injection current becomes <b>[DC inject. level 2]</b> (i d C 2). See <b>[DC injection time 1]</b> (t d i) page <a href="#">174</a> .	0.1 to 30 s	0.5 s
<b>i d C 2</b> ★ ( )	<b>[DC inject. level 2]</b> Injection current activated by logic input or selected as stop mode, once period of time <b>[DC injection time 1]</b> (t d i) has elapsed. See <b>[DC inject. level 2]</b> (i d C 2) page <a href="#">175</a> .	0.1 In to 1.41 In (1)	0.5 In (1)
<b>t d C</b> ★ ( )	<b>[DC injection time 2]</b> Maximum injection time <b>[DC inject. level 2]</b> (i d C 2) for injection selected as stop mode only. See <b>[DC injection time 2]</b> (t d C) page <a href="#">175</a> .	0.1 to 30 s	0.5 s
<b>S d C I</b> ★ ( )	<b>[Auto DC inj. level 1]</b> <div style="border: 1px solid black; padding: 5px; text-align: center;"><b>NOTICE</b></div> <b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b>	0 to 1.2 In (1)	0.7 In (1)
	Level of standstill DC injection current <b>[Auto DC injection]</b> (A d C) is not <b>[No]</b> (n o). See page <a href="#">176</a> .		
<b>t d C I</b> ★ ( )	<b>[Auto DC inj. time 1]</b> <div style="border: 1px solid black; padding: 5px; text-align: center;"><b>NOTICE</b></div> <b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b>	0.1 to 30 s	0.5 s
	Standstill injection time. This parameter can be accessed if <b>[Auto DC injection]</b> (A d C) is not set to <b>[No]</b> (n o). If <b>[Motor control type]</b> (C t t) page <a href="#">105</a> is set to <b>[Sync. mot.]</b> (S Y n), this time corresponds to the zero speed maintenance time. See page <a href="#">176</a> .		

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
<b>5 d C 2</b>	<b>[Auto DC inj. level 2]</b>	0 to 1.2 In (1)	0.5 In (1)
★ ⌚	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b></p>		
	<p>2nd level of standstill DC injection current. This parameter can be accessed if <b>[Auto DC injection] (A d C)</b> is not <b>[No] (n o)</b>. See page <a href="#">177</a>.</p>		
<b>6 d C 2</b>	<b>[Auto DC inj. time 2]</b>	0 to 30 s	0 s
★ ⌚	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b></p>		
	<p>2nd standstill injection time. This parameter can be accessed if <b>[Auto DC injection] (A d C)</b> is set to <b>[Yes] (Y E 5)</b>. See page <a href="#">177</a>.</p>		
<b>5 F r</b>	<b>[Switching freq.]</b>	2 to 16 kHz	4.0 kHz
⌚	<b>NOTICE</b>		
	<p><b>DAMAGE TO THE MOTOR</b> Verify that the switching frequency of the drive does not exceed 4 kHz if the EMC filter is disconnected for operation of the drive in an IT mains. <b>Failure to follow these instructions can result in equipment damage.</b></p>		
	<p>This applies to the following drive versions: ATV320●●●M2● Switching frequency setting. See page <a href="#">119</a>. <b>Adjustment range:</b> The maximum value is limited to 4 kHz if <b>[Motor surge limit] (5 u L)</b> parameter, page <a href="#">120</a> is configured. <b>Note:</b> In the event of excessive temperature rise, the drive will automatically reduce the switching frequency and reset it once the temperature returns to normal.</p>		
<b>C L i</b>	<b>[Current Limitation]</b>	0 to 1.5 In (1)	1.5 In (1)
★ ⌚	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <ul style="list-style-type: none"> <li>• Verify that the motor is properly rated for the maximum current to be applied to the motor.</li> <li>• Consider the duty cycle of the motor and all factors of your application including derating requirements in determining the current limit.</li> </ul> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>		
	<p>Used to limit the motor current. See page <a href="#">218</a>. <b>Note:</b> If the setting is less than 0.25 In, the drive may lock in <b>[Output Phase Loss] (o P L)</b> fault mode if this has been enabled (see page <a href="#">256</a>). If it is less than the no-load motor current, the motor cannot run.</p>		

Code	Name / Description	Adjustment range	Factory setting
<b>CL2</b>	<b>[I Limit. 2 value]</b>	0 to 1.5 In (1)	1.5 In (1)
★ ⌚	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <ul style="list-style-type: none"> <li>Verify that the motor is properly rated for the maximum current to be applied to the motor.</li> <li>Consider the duty cycle of the motor and all factors of your application including derating requirements in determining the current limit.</li> </ul> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>		
<p>See page <a href="#">218</a>.  <b>Note:</b> If the setting is less than 0.25 In, the drive may lock in <b>[Output Phase Loss] (oPL)</b> fault mode if this has been enabled (see page <a href="#">256</a>). If it is less than the no-load motor current, the motor cannot run.</p>			
<b>FLU</b>	<b>[Motor fluxing]</b>		<b>[No] (Fn0)</b>
★ ⌚	<b>⚠ ⚠ DANGER</b>		
	<p><b>HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH</b></p> <p>If the parameter <b>[Motor fluxing] (FLU)</b> is set to <b>[Continuous] (FCE)</b>, fluxing is always active, even if the motor does not run.</p> <ul style="list-style-type: none"> <li>Verify that using this setting does not result in unsafe conditions.</li> </ul> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p>		
⌚ 2 s	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <p>Verify that the connected motor is properly rated for the flux current to be applied in order to avoid overheating and damage to the motor.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>		
<p>The parameter is visible if <b>[Motor control type] (CCE)</b> page <a href="#">105</a> is not set to <b>[Sync. mot.] (SYN)</b>.          In order to obtain rapid high torque on startup, magnetic flux needs to already have been established in the motor.          In <b>[Continuous] (FCE)</b> mode, the drive automatically builds up flux when it is powered up.          In <b>[Not cont.] (FNC)</b> mode, fluxing occurs when the motor starts up.          The flux current is greater than <b>[Rated mot. current] (nCr)</b> when the flux is established and is then adjusted to the motor magnetizing current. See page <a href="#">189</a>.</p>			
<b>FNC</b>	<b>[Not cont.] (FNC):</b> Non-continuous mode		
<b>FCE</b>	<b>[Continuous] (FCE):</b> Continuous mode. This option is not possible if <b>[Auto DC injection] (AdC)</b> page <a href="#">176</a> is <b>[Yes] (YES)</b> or if <b>[Type of stop] (SEt)</b> page <a href="#">173</a> is <b>[Freewheel] (nSE)</b> .		
<b>Fn0</b>	<b>[No] (Fn0):</b> Function inactive. This option is not possible if <b>[Brake assignment] (bLC)</b> page <a href="#">194</a> is not <b>[No] (n0)</b> .		
<b>ELS</b>	<b>[Low speed time out]</b>	0 to 999.9 s	0 s
⌚	<p>Maximum operating time at <b>[Low speed] (LSP)</b> (see page <a href="#">87</a>).</p> <p>Following operation at LSP for a defined period, a motor stop is requested automatically. The motor will restart if the reference is greater than LSP and if a run command is still present. See page <a href="#">213</a>.</p> <p><b>Note:</b> A value of 0 indicates an unlimited period of time.</p> <p><b>Note:</b> If <b>[Low speed time out] (ELS)</b> is not 0, <b>[Type of stop] (SEt)</b> page <a href="#">173</a> is forced to <b>[Ramp stop] (rPP)</b> (only if a ramp stop can be configured).</p>		
<b>JGF</b>	<b>[Jog frequency]</b>	0 to 10 Hz	10 Hz
★ ⌚	Reference in jog operation. See page <a href="#">178</a> .		

**Parameters described in this page can be accessed by:**

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
JGt	<b>[Jog delay]</b>	0 to 2.0 s	0.5 s
★ ↻	Anti-repeat delay between 2 consecutive jog operations. See page <a href="#">179</a> .		

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
<b>5 P 2</b> ★ ( )	<b>[Preset speed 2]</b> Preset speed 2. See <a href="#">[Preset speed 2] (5 P 2)</a> page <a href="#">181</a> .	0 to 599 Hz	10 Hz
<b>5 P 3</b> ★ ( )	<b>[Preset speed 3]</b> Preset speed 3. See <a href="#">[Preset speed 3] (5 P 3)</a> page <a href="#">181</a> .	0 to 599 Hz	15 Hz
<b>5 P 4</b> ★ ( )	<b>[Preset speed 4]</b> Preset speed 4. See <a href="#">[Preset speed 4] (5 P 4)</a> page <a href="#">181</a> .	0 to 599 Hz	20 Hz
<b>5 P 5</b> ★ ( )	<b>[Preset speed 5]</b> Preset speed 5. See <a href="#">[Preset speed 5] (5 P 5)</a> page <a href="#">181</a> .	0 to 599 Hz	25 Hz
<b>5 P 6</b> ★ ( )	<b>[Preset speed 6]</b> Preset speed 6. See <a href="#">[Preset speed 6] (5 P 6)</a> page <a href="#">181</a> .	0 to 599 Hz	30 Hz
<b>5 P 7</b> ★ ( )	<b>[Preset speed 7]</b> Preset speed 7. See <a href="#">[Preset speed 7] (5 P 7)</a> page <a href="#">181</a> .	0 to 599 Hz	35 Hz
<b>5 P 8</b> ★ ( )	<b>[Preset speed 8]</b> Preset speed 8. See <a href="#">[Preset speed 8] (5 P 8)</a> page <a href="#">182</a> .	0 to 599 Hz	40 Hz
<b>5 P 9</b> ★ ( )	<b>[Preset speed 9]</b> Preset speed 9. See <a href="#">[Preset speed 9] (5 P 9)</a> page <a href="#">182</a> .	0 to 599 Hz	45 Hz
<b>5 P 10</b> ★ ( )	<b>[Preset speed 10]</b> Preset speed 10. See <a href="#">[Preset speed 10] (5 P 10)</a> page <a href="#">182</a> .	0 to 599 Hz	50 Hz
<b>5 P 11</b> ★ ( )	<b>[Preset speed 11]</b> Preset speed 11. See <a href="#">[Preset speed 11] (5 P 11)</a> page <a href="#">182</a> .	0 to 599 Hz	55 Hz
<b>5 P 12</b> ★ ( )	<b>[Preset speed 12]</b> Preset speed 12. See <a href="#">[Preset speed 12] (5 P 12)</a> page <a href="#">182</a> .	0 to 599 Hz	60 Hz



Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
5 P 13 ★ ( )	<b>[Preset speed 13]</b> Preset speed 13. See <a href="#">[Preset speed 13] (5 P 13)</a> page <a href="#">182</a> .	0 to 599 Hz	70 Hz
5 P 14 ★ ( )	<b>[Preset speed 14]</b> Preset speed 14. See <a href="#">[Preset speed 14] (5 P 14)</a> page <a href="#">182</a> .	0 to 599 Hz	80 Hz
5 P 15 ★ ( )	<b>[Preset speed 15]</b> Preset speed 15. See <a href="#">[Preset speed 15] (5 P 15)</a> page <a href="#">182</a> .	0 to 599 Hz	90 Hz
5 P 16 ★ ( )	<b>[Preset speed 16]</b> Preset speed 16. See <a href="#">[Preset speed 16] (5 P 16)</a> page <a href="#">182</a> .	0 to 599 Hz	100 Hz
П F r ★ ( )	<b>[Multiplying coeff.]</b> Multiplying coefficient, can be accessed if <a href="#">[Multiplier ref.] (П R 2, П R 3)</a> page <a href="#">169</a> has been assigned to the graphic display terminal. See page <a href="#">46</a> .	0 to 100%	100%
5 r P ★ ( )	<b>[+/-Speed limitation]</b> Limitation of +/- speed variation. See page <a href="#">187</a> .	0 to 50%	10%

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
<b>r P G</b> ★ ( )	<b>[PID prop. gain]</b> Proportional gain. See page <a href="#">211</a> .	0.01 to 100	1
<b>r I G</b> ★ ( )	<b>[PID integral gain]</b> Integral gain. See page <a href="#">211</a> .	0.01 to 100	1
<b>r d G</b> ★ ( )	<b>[PID derivative gain]</b> Derivative gain. See page <a href="#">211</a> .	0.00 to 100	0
<b>P r P</b> ★ ( )	<b>[PID ramp]</b> PID acceleration/deceleration ramp, defined to go from <b>[Min PID reference]</b> ( <b>P , P I</b> ) to <b>[Max PID reference]</b> ( <b>P , P 2</b> ) and vice versa. See page <a href="#">211</a> .	0 to 99.9 s	0 s
<b>P o L</b> ★ ( )	<b>[Min PID output]</b> Minimum value of regulator output in Hz. See page <a href="#">211</a> .	-599 to 599 Hz	0 Hz
<b>P o H</b> ★ ( )	<b>[Max PID output]</b> Maximum value of regulator output in Hz. See page <a href="#">211</a> .	0 to 599 Hz	60 Hz
<b>P R L</b> ★ ( )	<b>[Min fbk alarm]</b> Minimum monitoring threshold for regulator feedback. See page <a href="#">211</a> .	See page <a href="#">211</a> (2)	100
<b>P R H</b> ★ ( )	<b>[Max fbk alarm]</b> Maximum monitoring threshold for regulator feedback. See page <a href="#">212</a> .	See page <a href="#">212</a> (2)	1,000
<b>P E r</b> ★ ( )	<b>[PID error Alarm]</b> Regulator error monitoring threshold. See page <a href="#">212</a> .	0 to 65,535 (2)	100
<b>P S r</b> ★ ( )	<b>[Speed input %]</b> Multiplying coefficient for predictive speed input. See page <a href="#">212</a> .	1 to 100%	100%
<b>r P 2</b> ★ ( )	<b>[Preset ref. PID 2]</b> Preset PID reference. See page <a href="#">214</a> .	See page <a href="#">214</a> (2)	300

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
<i>r P 3</i> ★ ()	<b>[Preset ref. PID 3]</b> Preset PID reference. See page <a href="#">214</a> .	See page <a href="#">214</a> (2)	600
<i>r P 4</i> ★ ()	<b>[Preset ref. PID 4]</b> Preset PID reference. See page <a href="#">214</a> .	See page <a href="#">214</a> (2)	900

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
<i>i b r</i> ★ ( )	<b>[Brake release I FW]</b> Brake release current threshold for lifting or forward movement. See page <a href="#">194</a> .	0 to 1.36 In (1)	0.0 A
<i>i r d</i> ★ ( )	<b>[Brake release I Rev]</b> Brake release current threshold for lowering or reverse movement. See page <a href="#">194</a> .	0 to 1.36 In (1)	0.0 A
<i>b r t</i> ★ ( )	<b>[Brake Release time]</b> Brake release time delay. See page <a href="#">194</a> .	0 to 5.00 s	0 s
<i>b i r</i> ★ ( ) <i>A u t o</i>	<b>[Brake release freq]</b> See page <a href="#">195</a> . <b>[Auto] (Auto):</b> Nominal value	<b>[Auto] (Auto)</b> 0 to 10 Hz	<b>[Auto] (Auto)</b>
<i>b E n</i> ★ ( )	<b>[Brake engage freq]</b> Brake engage frequency threshold. See page <a href="#">195</a> .	<b>[Auto] (Auto)</b> 0 to 10 Hz	<b>[Auto] (Auto)</b>
<i>t b E</i> ★ ( )	<b>[Brake engage delay]</b> Time delay before request to engage brake. See page <a href="#">195</a> .	0 to 5.00 s	0 s
<i>b E t</i> ★ ( )	<b>[Brake engage time]</b> Brake engage time (brake response time). See page <a href="#">195</a> .	0 to 5.00 s	0 s
<i>J d C</i> ★ ( ) <i>A u t o</i>	<b>[Jump at reversal]</b> See page <a href="#">195</a> . <b>[Auto] (Auto):</b> Nominal value	<b>[Auto] (Auto)</b> 0 to 10 Hz	<b>[Auto] (Auto)</b>
<i>t E r</i> ★ ( )	<b>[Time to restart]</b> Time between the end of a brake engage sequence and the start of a brake release sequence. See page <a href="#">196</a> .	0.00 to 15.00 s	0.00 s
<i>t L i n</i> ★ ( )	<b>[Motoring torque lim]</b> Torque limitation in motor mode, as a % or in 0.1% increments of the rated torque in accordance with the <b>[Torque increment] (i n t P)</b> parameter, page <a href="#">216</a> . See page <a href="#">216</a> .	0 to 300%	100%
<i>t L i G</i>	<b>[Gen. torque lim]</b>	0 to 300%	100%

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
★ ( )	Torque limitation in generator mode, as a % or in 0.1% increments of the rated torque in accordance with the <b>[Torque increment] ( i n t P )</b> parameter, page <a href="#">216</a> . See page <a href="#">216</a> .		
★ ( ) t r H	<b>[Traverse freq. high]</b> Traverse high. See page <a href="#">242</a> .	0 to 10 Hz	4 Hz
★ ( ) t r L	<b>[Traverse freq. low]</b> Traverse low. See page <a href="#">242</a> .	0 to 10 Hz	4 Hz
★ ( ) q s H	<b>[Quick step High]</b> Quick step high. See page <a href="#">242</a> .	0 to <b>[Traverse freq. high] ( t r H )</b>	0 Hz
★ ( ) q s L	<b>[Quick step Low]</b> Quick step low. See page <a href="#">242</a> .	0 to <b>[Traverse freq. low] ( t r L )</b>	0 Hz
( ) c t d	<b>[Current threshold]</b> Current threshold for <b>[I attained] ( c t r )</b> function assigned to a relay or a logic output (see page <a href="#">138</a> ). See page <a href="#">252</a> .	0 to 1.5 In (1)	In (1)
( ) t t H	<b>[High torque thd.]</b> High torque threshold for <b>[High tq. att.] ( t t H r )</b> function assigned to a relay or a logic output (see page <a href="#">138</a> ), as a % of the rated motor torque. See page <a href="#">253</a> .	-300% to +300%	100%
( ) t t L	<b>[Low torque thd.]</b> Low torque threshold for <b>[Low tq. att.] ( t t L r )</b> function assigned to a relay or a logic output (see page <a href="#">138</a> ), as a % of the rated motor torque. See page <a href="#">253</a> .	-300% to +300%	50%
★ ( ) f q L	<b>[Pulse warning thd.]</b> Speed threshold measured by the <b>[FREQUENCY METER] ( F q F - )</b> function, page <a href="#">266</a> , assigned to a relay or a logic output (see page <a href="#">138</a> ). See page <a href="#">253</a> .	0 Hz to 20,000 kHz	0 Hz
( ) f t d	<b>[Freq. threshold]</b> Motor frequency threshold for <b>[Freq.Th.att.] ( F t r )</b> function assigned to a relay or a logic output (see page <a href="#">138</a> ), or used by the <b>[PARAM. SET SWITCHING] ( n L P - )</b> function, page <a href="#">230</a> . See page <a href="#">253</a> .	0.0 to 599 Hz	HSP
( ) f 2 d	<b>[Freq. threshold 2]</b> Motor frequency threshold for <b>[Freq.th.2 attained] ( F 2 r )</b> function assigned to a relay or a logic output (see page <a href="#">138</a> ), or used by the <b>[PARAM. SET SWITCHING] ( n L P - )</b> function, page <a href="#">230</a> . See page <a href="#">253</a> .	0.0 to 599 Hz	HSP
★ ( ) f f t	<b>[Freewheel stop Thd]</b> Speed threshold below which the motor will switch to freewheel stop. This parameter supports switching from a ramp stop or a fast stop to a freewheel stop below a low speed threshold. It can be accessed if <b>[Type of stop] ( S t t )</b> is set to <b>[Fast stop] ( F S t )</b> or <b>[Ramp stop] ( r n P )</b> and if <b>[Brake assignment] ( b L C )</b> and <b>[Auto DC injection] ( A d C )</b> are not configured. See page <a href="#">173</a> .	0.2 to 599 Hz	0.2 Hz
( ) t t d	<b>[Motor therm. level]</b> Threshold for motor thermal alarm (logic output or relay). See page <a href="#">255</a> .	0 to 118%	100%
( ) j p f	<b>[Skip Frequency]</b> Skip frequency. This parameter helps to prevent prolonged operation within an adjustable range around the regulated frequency. This function can be used to help to prevent a speed, which would cause resonance, being reached. Setting the function to 0 renders it inactive. See page <a href="#">183</a> .	0 to 599 Hz	0 Hz
( ) j f 2	<b>[Skip Frequency 2]</b>	0 to 599 Hz	0 Hz

Parameters described in this page can be accessed by:

DRI -&gt; CONF &gt; FULL &gt; SET-

Code	Name / Description	Adjustment range	Factory setting
( )	2nd skip frequency. This parameter helps to prevent prolonged operation within an adjustable range around the regulated frequency. This function can be used to help to prevent a speed, which would cause resonance, being reached. Setting the function to 0 renders it inactive. See page <a href="#">183</a> .		
JF3	<b>[3rd Skip Frequency]</b>	0 to 599 Hz	0 Hz
( )	3rd skip frequency. This parameter helps to prevent prolonged operation within an adjustable range around the regulated frequency. This function can be used to help to prevent a speed, which would cause resonance, being reached. Setting the function to 0 renders it inactive. See page <a href="#">183</a> .		
JFH	<b>[Skip.Freq.Hysteresis]</b>	0.1 to 10 Hz	1 Hz
★	Parameter visible if at least one skip frequency <b>[Skip Frequency]</b> (JPF), <b>[Skip Frequency 2]</b> (JF2) or <b>[3rd Skip Frequency]</b> (JF3) is different from 0.		
( )	Skip frequency range: between (JPF - JFH) and (JPF + JFH) for example. This adjustment is common to the 3 frequencies (JPF, JF2, JF3). See page <a href="#">183</a> .		
LuN	<b>[Unld.Thr.Nom.Speed]</b>	20 to 100% of <b>[Rated mot. current]</b> (nCr)	60%
★	Underload threshold at rated motor frequency ( <b>[Rated motor freq.]</b> (Fr5) page <a href="#">86</a> ), as a % of the rated motor torque.		
( )	Visible only if <b>[Unld T. Del. Detect]</b> (uLt) page <a href="#">270</a> is not set to 0. See page <a href="#">270</a> .		
LuL	<b>[Unld.Thr.0.Speed]</b>	0 to <b>[Unld.Thr.Nom.Speed]</b> (LuN)	0%
★	Underload threshold at zero frequency, as a % of the rated motor torque.		
( )	Visible only if <b>[Unld T. Del. Detect]</b> (uLt) page <a href="#">270</a> is not set to 0. See page <a href="#">270</a> .		
rNd	<b>[Unld. Freq.Thr. Det.]</b>	0 to 599 Hz	0 Hz
★	Underload detection minimum frequency threshold. See page <a href="#">270</a> .		
( )			
Srb	<b>[Hysteresis Freq.Att.]</b>	0.3 to 599 Hz	0.3 Hz
★	Maximum deviation between the frequency reference and the motor frequency, which defines steady state operation.		
( )	See page <a href="#">270</a> .		
Ftu	<b>[Underload T.B.Rest.]</b>	0 to 6 min	0 min
★	Minimum time permitted between an underload being detected and any automatic restart.		
( )	In order for an automatic restart to be possible, the value of <b>[Max. restart time]</b> (tRr) page <a href="#">252</a> must exceed that of this parameter by at least one minute. See page <a href="#">271</a> .		
LoC	<b>[Ovld Detection Thr.]</b>	70% to 150% of <b>[Rated mot. current]</b> (nCr)	110%
★	Overload detection threshold, as a % of the rated motor current <b>[Rated mot. current]</b> (nCr). This value must be less than the limit current in order for the function to work. See page <a href="#">272</a> .		
( )	Visible only if <b>[Ovld Time Detect.]</b> (tOL) is not set to 0. This parameter is used to detect an "application overload". This is not a motor or drive thermal overload.		
Fto	<b>[Overload T.B.Rest.]</b>	0 to 6 min	0 min
★	Minimum time permitted between an overload being detected and any automatic restart.		
( )	In order for an automatic restart to be possible, the value of <b>[Max. restart time]</b> (tRr) page <a href="#">252</a> must exceed that of this parameter by at least one minute. See page <a href="#">272</a> .		
LbC	<b>[Load correction]</b>	0 to 599 Hz	0 Hz
★	Rated correction in Hz. See <b>[Load correction]</b> (LbC) page <a href="#">122</a> .		
( )			

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > DRC-


Code	Name / Description	Adjustment range	Factory setting
<p><i>FFΠ</i></p> <p><b>[Fan Mode]</b></p> <p>If <b>[Fan Mode]</b> (<i>FFΠ</i>) is set to <b>[Never]</b> (<i>SE P</i>), the fan of the drive is disabled. Service life of electronic component is reduced.</p> <p><b>NOTICE</b></p> <p><b>DAMAGE TO THE DRIVE</b> The ambient temperature must be limited to 40°C (104°F) <b>Failure to follow these instructions can result in equipment damage.</b></p> <p><i>SE d</i> <b>[Standard]</b> (<i>SE d</i>): The fan starts and stops automatically according to the drive thermal state <i>run</i> <b>[Always]</b> (<i>run</i>): The fan is started <i>SE P</i> <b>[Never]</b> (<i>SE P</i>): The fan is stopped</p>			<b>[Standard]</b> ( <i>SE d</i> )
<p><i>SDS</i></p> <p><b>[Scale factor display]</b></p> <p>Used to display a value in proportion to the output frequency <b>[Output frequency]</b> (<i>r F r</i>): the machine speed, the motor speed, etc.</p> <p>The display will show</p> <p><b>[Cust. output value]</b> (<i>SP d 3</i>) = <math>\frac{\text{[Scale factor display] (SDS)} \times \text{[Output frequency] (r F r)}}{1000}</math> to 2 decimal places</p> <ul style="list-style-type: none"> <li>• If <b>[Scale factor display]</b> (<i>SDS</i>) ≤ 1, <b>[Cust. output value]</b> (<i>SP d 1</i>) is displayed (possible definition = 0.01)</li> <li>• If 1 &lt; <b>[Scale factor display]</b> (<i>SDS</i>) ≤ 10, <b>[Cust. output value]</b> (<i>SP d 2</i>) is displayed (possible definition = 0.1)</li> <li>• If <b>[Scale factor display]</b> (<i>SDS</i>) &gt; 10, <b>[Cust. output value]</b> (<i>SP d 3</i>) is displayed (possible definition = 1)</li> <li>• If <b>[Scale factor display]</b> (<i>SDS</i>) &gt; 10 and <b>[Scale factor display]</b> (<i>SDS</i>) × <b>[Output frequency]</b> (<i>r F r</i>) &gt; 9,999:</li> </ul> <p>example: for 24,223, display will show 24.22</p> <p>- If <b>[Scale factor display]</b> (<i>SDS</i>) &gt; 10 and <b>[Scale factor display]</b> (<i>SDS</i>) × <b>[Output frequency]</b> (<i>r F r</i>) &gt; 65,535, display locked at 65.54</p> <p>Example: Display motor speed for 4-pole motor, 1,500 rpm at 50 Hz (synchronous speed): <b>[Scale factor display]</b> (<i>SDS</i>) = 30 <b>[Cust. output value]</b> (<i>SP d 3</i>) = 1,500 at <b>[Output frequency]</b> (<i>r F r</i>) = 50 Hz</p>	0.1 to 200	30	

(1) In corresponds to the rated drive current indicated in the Installation manual or on the drive nameplate.

(2) If a graphic display terminal is not in use, values greater than 9,999 will be displayed on the 4-digit display with a period mark after the thousand digit, example: 15.65 for 15,650.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.



To change the assignment of this parameter, press the ENT key for 2 s.

**Motor control**

The parameters in the **[MOTOR CONTROL]** (*d r C -*) menu can only be modified when the drive is stopped and no run command is present, with the following exceptions:

- **[Auto tuning]** (*t u n*) page 113, which may cause the motor to start up.
- Parameters containing the sign **( )** in the code column, which can be modified with the drive running or stopped.


Note : We recommend to perform auto-tuning if one of the following parameters are modified from their factory setting.

Code	Name / Description	Adjustment range	Factory setting
<i>F u L L</i>	<b>[FULL] (continued)</b>		
<i>d r C -</i>	<b>[MOTOR CONTROL]</b>		
<i>b F r</i>	<b>[Standard mot. freq]</b> This parameter modifies the presets of the following parameters: <b>[High speed]</b> ( <i>H S P</i> ) page 87, <b>[Freq. threshold]</b> ( <i>F t d</i> ) page 102, <b>[Rated motor volt.]</b> ( <i>u n S</i> ), <b>[Rated motor freq.]</b> ( <i>F r S</i> ) and <b>[Max frequency]</b> ( <i>t F r</i> ). <i>5 0</i> <b>[50 Hz IEC] (5 0)</b> : IEC <i>6 0</i> <b>[60 Hz NEMA] (6 0)</b> : NEMA		<b>[50 Hz IEC] (5 0)</b>
<i>t F r</i>	<b>[Max frequency]</b> The factory setting is 60 Hz, or preset to 72 Hz if <b>[Standard mot. freq]</b> ( <i>b F r</i> ) is set to 60 Hz. The maximum value is limited by the following conditions: It must not exceed 10 times the value of <b>[Rated motor freq.]</b> ( <i>F r S</i> ).	10 to 599 Hz	60 Hz
<i>C t t</i>	<b>[Motor control type]</b> <b>Note:</b> Select law before entering parameter values. <i>u u C</i> <b>[SVC V] (u u C)</b> : Sensorless vector control with internal speed loop based on voltage feedback calculation. For applications needing high performance during starting or operation. <i>S t d</i> <b>[Standard] (S t d)</b> : Standard motor law. For simple applications that do not require high performance. Simple motor control law keeping a constant Voltage Frequency ratio, with a possible adjustment of the curve bottom. This law is generally used for motors connected in parallel. Some specific applications with motors in parallel and high performance levels may require <b>[SVC V] (u u C)</b> .		<b>[Standard] (S t d)</b>
	<p><b>Note:</b> U0 is the result of an internal calculation based on motor parameters and multiplied by UFr (%). U0 can be adjusted by modifying UFr value.</p>		



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > DRC- > ASY-



Code	Name / Description	Adjustment range	Factory setting
<p><b>u F 5</b></p> <p><b>5 4 n</b></p> <p><b>u F 9</b></p> <p><b>n L d</b></p>	<p><b>[V/F 5pts] (u F 5):</b> 5-segment V/F profile: As <b>[Standard] (5 L d)</b> profile but also supports the avoidance of resonance (saturation).</p>  <p>The profile is defined by the values of parameters UnS, FrS, U0 to U5 and F1 to F5.</p> <p><math>FrS &gt; F5 &gt; F4 &gt; F3 &gt; F2 &gt; F1</math></p> <p><b>Note:</b> U0 is the result of an internal calculation based on motor parameters and multiplied by UFr (%). U0 can be adjusted by modifying UFr value.</p> <p><b>[Sync. mot.] (5 4 n):</b> For synchronous permanent magnet motors with sinusoidal electromotive force (EMF) only. This selection makes the asynchronous motor parameters inaccessible, and the synchronous motor parameters accessible.</p> <p><b>[V/F Quad.] (u F 9):</b> Variable torque. For pump and fan applications.</p> <p><b>[Energy Sav.] (n L d):</b> Energy saving. For applications that do not require high dynamics.</p>		





**Asynchronous motor parameters**

Code	Name / Description	Adjustment range	Factory setting
<b>ASY -</b>	<b>[ASYNC. MOTOR]</b> Only visible if <b>[Motor control type] (C E E)</b> page <b>105</b> is not set to <b>[Sync. mot.] (S Y n)</b> .		
<b>n P r</b> ★	<b>[Rated motor power]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> page <b>105</b> is set to <b>[Sync. mot.] (S Y n)</b> . Rated motor power given on the nameplate, in kW if <b>[Standard mot. freq] (b F r)</b> is set to <b>[50Hz IEC] (S D)</b> , in HP if <b>[Standard mot. freq] (b F r)</b> is set to <b>[60Hz NEMA] (B D)</b> .	According to drive rating	According to drive rating
<b>C o S</b> ★	<b>[Motor 1 Cosinus Phi]</b> Nominal motor cos phi. This parameter can be accessed if <b>[Motor param choice] (n P C)</b> is set to <b>[Mot Cos] (C o S)</b> .	0.5 to 1	According to drive rating
<b>u n S</b> ★	<b>[Rated motor volt.]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> page <b>105</b> is set to <b>[Sync. mot.] (S Y n)</b> . Rated motor voltage given on the nameplate.	100 to 480 V	According to drive rating and <b>[Standard mot. freq] (b F r)</b>
<b>n C r</b> ★	<b>[Rated mot. current]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> page <b>105</b> is set to <b>[Sync. mot.] (S Y n)</b> . Rated motor current given on the nameplate.	0.25 to 1.5 In (1)	According to drive rating and <b>[Standard mot. freq] (b F r)</b>
<b>F r S</b> ★	<b>[Rated motor freq.]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> page <b>105</b> is set to <b>[Sync. mot.] (S Y n)</b> . Rated motor frequency given on the nameplate. The factory setting is 50 Hz, or preset to 60 Hz if <b>[Standard mot. freq] (b F r)</b> is set to 60 Hz.	10 to 800 Hz	50 Hz
<b>n S P</b> ★	<b>[Rated motor speed]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> page <b>105</b> is set to <b>[Sync. mot.] (S Y n)</b> . 0 to 9,999 rpm then 10.00 to 65.53 krpm on the integrated display terminal. If, rather than the rated speed, the nameplate indicates the synchronous speed and the slip in Hz or as a %, calculate the rated speed as follows:  Nominal speed = Synchronous speed x $\frac{100 - \text{slip as a \%}}{100}$ or Nominal speed = Synchronous speed x $\frac{50 - \text{slip in Hz}}{50}$ (50 Hz motors) or Nominal speed = Synchronous speed x $\frac{60 - \text{slip in Hz}}{60}$ (60 Hz motors).	0 to 65,535 rpm	According to drive rating

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > DRC- > ASY-

Code	Name / Description	Adjustment range	Factory setting
<p><b>t u n</b></p> <p></p> <p> 2 s</p>	<p><b>[Auto tuning]</b></p> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>⚠ WARNING</b></p> <p><b>UNEXPECTED MOVEMENT</b></p> <p>Autotuning moves the motor in order to tune the control loops.</p> <ul style="list-style-type: none"> <li>Only start the system if there are no persons or obstructions in the zone of operation.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>During autotuning, the motor makes small movements, noise development and oscillations of the system are normal.</p> <ul style="list-style-type: none"> <li>- Auto-tuning is only performed if no stop command has been activated. If a "freewheel stop" or "fast stop" function has been assigned to a logic input, this input must be set to 1 (active at 0).</li> <li>- Auto-tuning takes priority over any run or prefluxing commands, which will be taken into account after the auto-tuning sequence.</li> <li>- If auto-tuning detects a fault, the drive displays <b>[No action] (n a)</b> and, depending on the configuration of <b>[Autotune fault mgt] (t n L)</b> page 268, may switch to <b>[Auto-tuning] (t n F)</b> fault mode.</li> <li>- Auto-tuning may last for 1 to 2 seconds. Do not interrupt the process. Wait for the display to change to <b>[No action] (n a)</b>.</li> </ul> <p><b>Note:</b> Motor thermal state has a big influence on tune result. Make the tune with the motor stopped and cold. To redo a tune of the motor, wait that it is completely stopped and cold. Set first <b>[Auto tuning] (t u n)</b> to <b>[Erase tune] (C L r)</b>, then redo the motor tuning. The use of the motor tuning without doing a <b>[Erase tune] (C L r)</b> first is used to get the thermal state estimation of the motor. In any case, the motor has to be stopped before performing a tune operation. Cable length has an influence on the Tune result. If the cabling is modified, it is necessary to redo the tune operation.</p> <p><b>n a</b> <b>[No action] (n a):</b> Auto-tuning not in progress  <b>y e s</b> <b>[Do tune] (y e s):</b> Auto-tuning is performed immediatly if possible, then the parameter automatically changes to <b>[No action] (n a)</b>. If the drive state does not allow the tune operation immediatly, the parameter changes to <b>[No] (n a)</b> and the operation must be done again.  <b>C L r</b> <b>[Erase tune] (C L r):</b> The motor parameters measured by the auto-tuning function are reseted. The default motor parameters values are used to control the motor. <b>[Auto tuning status] (t u S)</b> is set to <b>[Not done] (t A b)</b>.</p>		<p><b>[No] (n a)</b></p>
<p><b>t u S</b></p> <p><b>t A b</b>  <b>P E n d</b>  <b>P r o G</b>  <b>F A i L</b>  <b>d o n E</b></p>	<p><b>[Auto tuning state]</b></p> <p>(for information only, cannot be modified)                  This parameter is not saved at drive power off. It shows the Autotuning status since last power on.</p> <p><b>[Not done] (t A b):</b> Autotune is not done  <b>[Pending] (P E n d):</b> Autotune has been requested but not yet performed  <b>[In Progress] (P r o G):</b> Autotune is in progress  <b>[Failed] (F A i L):</b> Autotune has detected a fault  <b>[Done] (d o n E):</b> The motor parameters measured by the auto-tuning function are used to control the motor</p>		<p><b>[Not done] (t A b)</b></p>
<p><b>S t u n</b></p> <p><b>t A b</b>  <b>n E A S</b>  <b>C u S</b></p>	<p><b>[Tune selection]</b></p> <p>(for information only, cannot be modified)</p> <p><b>[Default] (t A b):</b> The default values are used to control the motor  <b>[Measure] (n E A S):</b> The values measured by the auto-tuning function are used to control the motor  <b>[Custom] (C u S):</b> The values set manually are used to control the motor  <b>Note:</b> Tune of the motor will increase significantly the performances.</p>		<p><b>[Default] (t A b)</b></p>
<p><b>t u n u</b></p> <p><b>n a</b>  <b>t n</b>  <b>C t</b></p>	<p><b>[Auto tuning usage]</b></p> <p>This parameter shows the way used to modify the motor parameters according to its estimated thermal state.</p> <p><b>[No] (n a):</b> No thermal state estimation  <b>[Therm Mot] (t n):</b> Statoric thermal state estimation based on nominal current and current consumed by the motor  <b>[Cold tun] (C t):</b> Statoric thermal state estimation based on statoric resistance measured at the first cold tune and tune done at each power up</p>		<p><b>[Therm Mot] (t n)</b></p>

Code	Name / Description	Adjustment range	Factory setting
<p><i>Aut</i></p> <p></p> <p> 2 s</p>	<p><b>[Automatic autotune]</b></p> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>⚠ WARNING</b></p> <p><b>UNEXPECTED MOVEMENT</b></p> <p>If this function is activated, autotuning is performed each time the drive is switched on.</p> <ul style="list-style-type: none"> <li>Verify that activating this function does not result in unsafe conditions.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>The motor must be stopped when switching on the drive.  <b>[Automatic autotune]</b> (<i>Aut</i>) is forced to <b>[Yes]</b> (<i>Yes</i>) if <b>[Auto tuning usage]</b> (<i>Autu</i>) is set to <b>[Cold tun]</b> (<i>Ct</i>). The value of motor statoric resistance measured during the tune is used to estimate the thermal state of the motor at power up.</p> <p><i>no</i> <b>[No]</b> (<i>no</i>): Function deactivated  <i>Yes</i> <b>[Yes]</b> (<i>Yes</i>): A tune is automatically done at each power up</p>		<p><b>[No]</b> (<i>no</i>)</p>
<p><i>Flu</i></p> <p>★</p> <p> (1)</p> <p> 2 s</p>	<p><b>[Motor fluxing]</b></p> <div style="background-color: black; color: white; text-align: center; padding: 5px;"> <p><b>⚡ ⚠ DANGER</b></p> </div> <div style="border: 1px solid black; padding: 10px;"> <p><b>HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH</b></p> <p>If the parameter <b>[Motor fluxing]</b> (<i>Flu</i>) is set to <b>[Continuous]</b> (<i>Fct</i>), fluxing is always active, even if the motor does not run.</p> <ul style="list-style-type: none"> <li>Verify that using this setting does not result in unsafe conditions.</li> </ul> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p> </div> <div style="border: 1px solid black; padding: 10px; text-align: center; margin-top: 10px;"> <p><b>NOTICE</b></p> </div> <div style="border: 1px solid black; padding: 10px;"> <p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <p>Verify that the connected motor is properly rated for the flux current to be applied in order to avoid overheating and damage to the motor.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p> </div> <p>If <b>[Motor control type]</b> (<i>Ctct</i>) page 105 is set to <b>[Sync. mot.]</b> (<i>Syn</i>), the factory setting is replaced by <b>[Not cont.]</b> (<i>Fnc</i>). In order to obtain rapid high torque on startup, magnetic flux needs to already have been established in the motor. In <b>[Continuous]</b> (<i>Fct</i>) mode, the drive automatically builds up flux when it is powered up. In <b>[Not cont.]</b> (<i>Fnc</i>) mode, fluxing occurs when the motor starts up. The flux current is greater than <b>[Rated mot. current]</b> (<i>nCr</i>) (configured rated motor current) when the flux is established and is then adjusted to the motor magnetizing current.</p> <p><i>Fnc</i> <b>[Not cont.]</b> (<i>Fnc</i>): Non-continuous mode  <i>Fct</i> <b>[Continuous]</b> (<i>Fct</i>): Continuous mode. This option is not possible if <b>[Auto DC injection]</b> (<i>Adc</i>) page 176 is <b>[Yes]</b> (<i>Yes</i>) or if <b>[Type of stop]</b> (<i>Stt</i>) page 173 is <b>[Freewheel]</b> (<i>nSt</i>).  <i>Fno</i> <b>[No]</b> (<i>Fno</i>): Function inactive. This option is not possible if <b>[Brake assignment]</b> (<i>blc</i>) page 194 is not <b>[No]</b> (<i>no</i>).                      If <b>[Motor control type]</b> (<i>Ctct</i>) page 105 is set to <b>[Sync. mot.]</b> (<i>Syn</i>), the <b>[Motor fluxing]</b> (<i>Flu</i>) parameter causes the alignment of the rotor and not the fluxing.                      If <b>[Brake assignment]</b> (<i>blc</i>) page 194 is not <b>[No]</b> (<i>no</i>), the <b>[Motor fluxing]</b> (<i>Flu</i>) parameter has no effect.</p>		<p><b>[No]</b> (<i>Fno</i>)</p>

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; DRC- &gt; ASY-

Code	Name / Description	Adjustment range	Factory setting
$\Pi P C$	[Motor param choice]		[Mot Power] ( $n P r$ )
★			
$n P r$	[Mot Power] ( $n P r$ )		
$C o S$	[Mot Cos] ( $C o S$ )		

(1) In corresponds to the rated drive current indicated in the Installation manual and on the drive nameplate.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.



To change the assignment of this parameter, press the ENT key for 2 s.

## Asynchronous motor parameters: Expert mode

Code	Name / Description	Adjustment range	Factory setting
<b>ASY -</b>	<b>[ASYNC. MOTOR]</b>		
<b>r s R</b> ★ (1)	<b>[Cust stator resist.]</b> Cold state stator resistance (per winding), modifiable value. The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 65,535 mOhm	0 mOhm
<b>L f R</b> ★	<b>[Lfw]</b> Cold state leakage inductance, modifiable value. The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 655.35 mH	0 mH
<b>i d R</b> ★	<b>[Idw]</b> Customer adjusted magnetizing current. The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 6,553.5 A	0 A
<b>t r R</b> ★	<b>[Cust. rotor t const.]</b> Customer adjusted rotor time constant. The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 65,535 ms	0 ms

(1) On the integrated display unit: 0 to 9,999 then 10.00 to 65.53 (10,000 to 65,535).



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; DRC- &gt; SYN-

## Synchronous motor parameters

These parameters can be accessed if **[Motor control type] (C L E)** page 105 is set to **[Sync. mot.] (S Y n)**. In this case, the asynchronous motor parameters cannot be accessed.

Once the drive is chosen:

### 1- Enter the motor nameplate.

### 2 - Perform the tune.

- Do an **[Auto tuning] (E u n)**
  - Check the state of the synchronous motor saliency (See page 113.)
- If **[Saliency mot. state] (S n o t)** displays **[Med salient] (n L S)** or **[High salient] (H L S)**
- follow the procedure below "3 - Improve the tune result" and
  - follow the the procedure below "4 - Adjust PHS"
- Or if **[Saliency mot. state] (S n o t)** displays **[Low salient] (L L S)**
- follow the the procedure below "4 - Adjust PHS"

### 3 - Improve the tune results.

## NOTICE

### OVERHEATING AND DAMAGE TO THE MOTOR

- Verify that the motor is properly rated for the maximum current to be applied to the motor.
- Consider the duty cycle of the motor and all factors of your application including derating requirements in determining the current limit.

**Failure to follow these instructions can result in equipment damage.**

- Set **[PSI align curr. max] (n L r)** conforming to the maximum motor current. The maximum value of **[PSI align curr. max] (n L r)** is limited by **[Current Limitation] (C L i)**. Without information set **[PSI align curr. max] (n L r)** to **[Auto] (A u t o)** (see page 116)
- Do a second **(E u n)** after the **(n L r)** modification.

### 4 - Adjust PHS.

Adjust **[Syn. EMF constant] (P H S)** to have optimal behavior (See page 116.)

- Start the motor at minimal stable frequency available on the machine (without load).
- Check and note the **[% error EMF sync] (r d R E)** value. (See page 117)
  - If the **[% error EMF sync] (r d R E)** value is lower than 0%, then **[Syn. EMF constant] (P H S)** may be increased.
  - If the **[% error EMF sync] (r d R E)** value is upper than 0%, then **[Syn. EMF constant] (P H S)** may be reduced.

**[% error EMF sync] (r d R E)** value should be closed to 0%.

- Stop the motor for modify **P H S** in accordance with the value of the **r d R E** (previously noted).

### Advices:

The drive must be chosen to have enough current according to the need of behavior, but not too much, to have enough accuracy in the current measurement, especially with the high frequency signal injection (see **[HF inj. activation] (H F i)** page 116).


Performances may be higher on high saliency motors by activating high frequency injection function (see **[HF inj. activation] (H F i)** page 116).

Code	Name / Description	Adjustment range	Factory setting
<i>drC-</i>	<b>[MOTOR CONTROL] (continued)</b>		
<i>SYn-</i>	<b>[SYNCHRONOUS MOTOR]</b>		
<i>nCrS</i> ★	<b>[Nominal I sync.]</b> Rated synchronous motor current given on the nameplate.	0.25 to 1.5 In (1)	According to drive rating
<i>PPnS</i> ★	<b>[Pole pairs]</b> Number of pairs of poles on the synchronous motor.	1 to 50	According to drive rating
<i>nSPS</i> ★ (2)	<b>[Nom motor spdsync]</b> Rated motor speed given on the nameplate.	0 to 48,000 rpm	According to drive rating
<i>tqS</i> ★	<b>[Motor torque]</b> Rated motor torque given on the nameplate.	0.1 to 6,553.5 Nm	According to drive rating
<i>tun</i>  ⏪  ⌚ 2 s	<b>[Auto tuning]</b>		<b>[No] (no)</b>
<div style="border: 1px solid black; padding: 10px;"> <p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>UNEXPECTED MOVEMENT</b> Autotuning moves the motor in order to tune the control loops.</p> <ul style="list-style-type: none"> <li>• Only start the system if there are no persons or obstructions in the zone of operation.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> <p>During autotuning, the motor makes small movements, noise development and oscillations of the system are normal.</p> <ul style="list-style-type: none"> <li>- Auto-tuning is only performed if no stop command has been activated. If a "freewheel stop" or "fast stop" function has been assigned to a logic input, this input must be set to 1 (active at 0).</li> <li>- Auto-tuning takes priority over any run or prefluxing commands, which will be taken into account after the auto-tuning sequence.</li> <li>- If auto-tuning detects a fault, the drive displays <b>[No action] (no)</b> and, depending on the configuration of <b>[Autotune fault mgt] (tnL)</b> page 268, may switch to <b>[Auto-tuning] (tnF)</b> fault mode.</li> <li>- Auto-tuning may last for 1 to 2 seconds. Do not interrupt the process. Wait for the display to change to <b>[No action] (no)</b>.</li> </ul> <p><b>Note:</b> Motor thermal state has a big influence on tune result. Make the tune with the motor stopped and cold. To redo a tune of the motor, wait that it is completely stopped and cold. Set first <b>[Auto tuning] (tun)</b> to <b>[Erase tune] (CLR)</b>, then redo the motor tuning. The use of the motor tuning without doing a <b>[Erase tune] (CLR)</b> first is used to get the thermal state estimation of the motor. In any case, the motor has to be stopped before performing a tune operation. Cable length has an influence on the Tune result. If the cabling is modified, it is necessary to redo the tune operation.</p> <p><i>no</i> <b>[No action] (no)</b>: Auto-tuning not in progress  <i>YES</i> <b>[Do tune] (YES)</b>: Auto-tuning is performed immediatly if possible, then the parameter automatically changes to <b>[No action] (no)</b>. If the drive state does not allow the tune operation immediatly, the parameter changes to <b>[No] (no)</b> and the operation must be done again.  <i>CLR</i> <b>[Erase tune] (CLR)</b>: The motor parameters measured by the auto-tuning function are reseted. The default motor parameters values are used to control the motor. <b>[Auto tuning status] (tUS)</b> is set to <b>[Not done] (tAb)</b>.</p> </div>			
<i>tUS</i>	<b>[Auto tuning state]</b> (for information only, cannot be modified) This parameter is not saved at drive power off. It shows the Autotuning status since last power on.		<b>[Not done] (tAb)</b>
<i>tAb</i> <i>PEnd</i> <i>PrOG</i> <i>FRIL</i> <i>done</i>	<b>[Not done] (tAb)</b> : Autotune is not done <b>[Pending] (PEnd)</b> : Autotune has been requested but not yet performed <b>[In Progress] (PrOG)</b> : Autotune is in progress <b>[Failed] (FRIL)</b> : Autotune has detected a fault <b>[Done] (done)</b> : The motor parameters measured by the auto-tuning function are used to control the motor		



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > DRC- > SYN-

Code	Name / Description	Adjustment range	Factory setting
<p><b>5 t u n</b></p> <p><b>t r b</b> <b>n e a s</b> <b>c u s</b></p>	<p><b>[Tune selection]</b></p> <p>(for information only, cannot be modified)  <b>Note:</b> Tune of the motor will increase significantly the performances.</p> <p><b>[Default] (t r b):</b> The default values are used to control the motor  <b>[Measure] (n e a s):</b> The values measured by the auto-tuning function are used to control the motor  <b>[Custom] (c u s):</b> The values set manually are used to control the motor</p>		<b>[Default] (t r b)</b>
<p><b>t u n u</b></p> <p><b>n o</b> <b>t n</b> <b>c t</b></p>	<p><b>[Auto tuning usage]</b></p> <p>This parameter shows the way used to modify the motor parameters according to its estimated thermal state.</p> <p><b>[No] (n o):</b> No thermal state estimation  <b>[Therm Mot] (t n):</b> Statoric thermal state estimation based on nominal current and current consumed by the motor  <b>[Cold tun] (c t):</b> Statoric thermal state estimation based on statoric resistance measured at the first cold tune and tune done at each power up</p>		<b>[Therm Mot] (t n)</b>
<p><b>A u t</b></p> <p><b>( )</b></p> <p> 2 s</p>	<p><b>[Automatic autotune]</b></p> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>⚠ WARNING</b></p> <p><b>UNEXPECTED MOVEMENT</b></p> <p>If this function is activated, autotuning is performed each time the drive is switched on.</p> <ul style="list-style-type: none"> <li>Verify that activating this function does not result in unsafe conditions.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>The motor must be stopped when switching on the drive.  <b>[Automatic autotune] (A u t)</b> is forced to <b>[Yes] (Y E S)</b> if <b>[Auto tuning usage] (t u n u)</b> is set to <b>[Cold tun] (c t)</b>. The value of motor statoric resistance measured during the tune is used to estimate the thermal state of the motor at power up.</p> <p><b>[No] (n o):</b> Function deactivated  <b>[Yes] (Y E S):</b> A tune is automatically done at each power up</p>		<b>[No] (n o)</b>
<p><b>S n o t</b></p> <p>★</p>	<p><b>[Saliency mot. state]</b></p> <p>(for information only, cannot be modified)  Information on synchronous motor saliency.  This parameter can be accessed if <b>[Tune selection] (5 t u n)</b> is set to <b>[Measure] (n e a s)</b>.  <b>Note:</b> In case of motor with low saliency, the standard control law is advised.</p> <p><b>[No] (n o):</b> Tune not done  <b>[Low salient] (L L S):</b> Low saliency level (Recommended configuration: <b>[Angle setting type] (A S t) = [PSI align] (P S i)</b> or <b>[PSIO align] (P S i o)</b> and <b>[HF inj. activation] (H F i) = [No] (n o)</b>).  <b>[Med salient] (M L S):</b> Medium saliency level (<b>[Angle setting type] (A S t) = [SPM align] (S P n A)</b> is possible. <b>[HF inj. activation] (H F i) = [Yes] (Y E S)</b> could work).  <b>[High salient] (H L S):</b> High saliency level (<b>[Angle setting type] (A S t) = [IPM align] (i P n A)</b> is possible. <b>[HF inj. activation] (H F i) = [Yes] (Y E S)</b> is possible).</p>		
<p><b>A S t</b></p> <p>★</p> <p><b>i P n A</b> <b>S P n A</b> <b>P S i</b> <b>P S i o</b> <b>n o</b></p>	<p><b>[Angle setting type]</b></p> <p>Mode for measuring the phase-shift angle. Visible only if <b>[Motor control type] (C t t)</b> is set to <b>[Sync. mot.] (S Y n)</b>.  <b>[PSI align] (P S i)</b> and <b>[PSIO align] (P S i o)</b> are working for all type of synchronous motors. <b>[SPM align] (S P n A)</b> and <b>[IPM align] (i P n A)</b> increase performances depending on the type of synchronous motor.</p> <p><b>[IPM align] (i P n A):</b> Alignment for IPM motor. Alignment mode for Interior-buried Permanent Magnet motor (usually, this kind of motor has a high saliency level). It uses high frequency injection, which is less noisy than standard alignment mode.  <b>[SPM align] (S P n A):</b> Alignment for SPM motor. Mode for Surface-mounted Permanent Magnet motor (usually, this kind of motor has a medium or low saliency level). It uses high frequency injection, which is less noisy than standard alignment mode.  <b>[PSI align] (P S i):</b> Pulse signal injection. Standard alignment mode by pulse signal injection.  <b>[PSIO align] (P S i o):</b> Pulse signal injection - Optimized. Standard optimized alignment mode by pulse signal injection. The phase shift angle measurement time is reduced after the first run order or tune operation, even if the drive has been turned off.  <b>[No align] (n o):</b> No alignment</p>		<b>[PSIO align.] (P S i o)</b>

Parameters described in this page can be accessed by: DRI- > CONF > FULL > DRC- > SYN-

Code	Name / Description	Adjustment range	Factory setting
HF ;  ★  no YES	<p><b>[HF inj. activation]</b></p> <p>Activation of high frequency signal injection in RUN. This function allows to estimate the motor speed in a view to have torque at low speed without speed feedback.</p> <p><b>Note:</b> The more the saliency is high, the more the <b>[HF inj. activation]</b> (HF ;) function will be efficient.</p> <p>In order to ensure the performances, it could be necessary to adjust the speed loop parameters (<b>[K speed loop filter]</b> (SFL), <b>[Speed time integral]</b> (SLE) and <b>[Speed prop. gain]</b> (SPG), see page 118) and the speed estimation phase locked loop (Expert parameters <b>[HF pll bandwidth]</b> (SPB) and <b>[HF pll dump. factor]</b> (SPF), see page 116).</p> <p>High frequency injection is not efficient with low saliency motors (see <b>[Saliency mot. state]</b> (SPaE) page 114). It is advised to have 4 kHz of pwm frequency (<b>[Switching freq.]</b> (SFr)).</p> <p>In case of instability with no load, it is advised to decrease <b>[Speed prop. gain]</b> (SPG) and <b>[HF pll bandwidth]</b> (SPB). Then, adjust the speed loop parameters to have the dynamic behavior and the PLL gains to have a good speed estimation at low speed.</p> <p>In case of instability with load, it could help to increase the <b>[Angle error Comp.]</b> (PEL) parameter (mainly for SPM motor).</p> <p><b>[No]</b> (no): Function deactivated  <b>[Yes]</b> (YES): High frequency injection is used for speed estimation</p>		<b>[No]</b> (no)

- (1) In corresponds to the rated drive current indicated in the Installation manual and on the drive nameplate.
- (2) On the integrated display unit: 0 to 9,999 then 10.00 to 65.53 (10,000 to 65,536).



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.



To change the assignment of this parameter, press the ENT key for 2 s.

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; DRC- &gt; SYN-

## Synchronous motor: Expert mode

Code	Name / Description	Adjustment range	Factory setting
<b>SYN -</b>	<b>[SYNCHRONOUS MOTOR]</b>		
<b>rSR5</b> ★ (1)	<b>[Cust. stator R syn]</b> Cold state stator resistance (per winding). The factory setting is replaced by the result of the auto-tuning operation, if it has been performed. The value can be entered by the user, if he knows it.	0 to 65,535 mOhm	0 mOhm
<b>Ld5</b> ★	<b>[Autotune L d-axis]</b> Axis "d" stator inductance in mH (per phase). On motors with smooth poles <b>[Autotune L d-axis] (Ld5) = [Autotune L q-axis] (Lq5) = Stator inductance L</b> . The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 655.35 mH	0 mH
<b>Lq5</b> ★	<b>[Autotune L q-axis]</b> Axis "q" stator inductance in mH (per phase). On motors with smooth poles <b>[Autotune L d-axis] (Ld5) = [Autotune L q-axis] (Lq5) = Stator inductance L</b> . The factory setting is replaced by the result of the auto-tuning operation, if it has been performed.	0 to 655.35 mH	0 mH
<b>PHS</b> ★ (1)	<b>[Syn. EMF constant]</b> Synchronous motor EMF constant, in mV per rpm (peak voltage per phase). PHS adjustment allows to reduce the current in operation without load.	0 to 6,553.5 mV/rpm	0 mV/rpm
<b>Frs5</b> ★ (1)	<b>[Nominal freq sync.]</b> Nominal motor frequency for synchronous motor in Hz unit. Automatically updated according to <b>[Nom motor spdsync] (nSP5)</b> and <b>[Pole pairs] (PPn5)</b> data.	10 to 800 Hz	nSPS * PPN5 / 60
<b>SPb</b> ★	<b>[HF pll bandwidth]</b> Bandwidth of the stator frequency PII.	0 to 100 Hz	25 Hz
<b>SPF</b> ★	<b>[HF pll dump. factor]</b> Dumping factor of the stator frequency PII.	0 to 200%	100%
<b>PEC</b> ★ <b>Auto</b>	<b>[Angle error Comp.]</b> Error compensation of the angle position in high frequency mode. It increases performances at low speed in generator and motor mode, particularly for SPM motors. <b>[Auto] (Auto)</b> : The drive takes a value equal to the rated slip of the motor, calculated using the drive parameters.	0 to 500%	0%
<b>Fri</b> ★	<b>[HF injection freq.]</b> Frequency of the high frequency injection signal. It has an influence on the noise during angle shift measurement and speed estimation accuracy.	250 to 1,000 Hz	500 Hz
<b>Hir</b> ★	<b>[HF current level]</b> Ratio for the current level of the high frequency injection signal. It has an influence on the noise during angle shift measurement and speed estimation accuracy.	0 to 200%	25%
<b>PIr</b> ★	<b>[PSI align curr. max]</b> Current level in % of <b>[Nominal I sync.] (nCr5)</b> for <b>[PSI align] (PSi)</b> and <b>[PSIO align] (PSIo)</b> angle shift measurement modes. This parameter has an impact on the inductor measurement. <b>[PSI align curr. max] (PIr)</b> is used for tune operation. This current must be equal or higher than the maximum current level of the application, otherwise instability may occur. If <b>[PSI align curr. max] (PIr)</b> is set to <b>[Auto] (Auto)</b> , <b>[PSI align curr. max] (PIr) = 150%</b> of <b>[Nominal I sync.] (nCr5)</b> during the tune operation and 100% of <b>[Nominal I sync.] (nCr5)</b> during angle shift measurement in case of standard alignment ( <b>[PSI align] (PSi)</b> or <b>[PSIO align] (PSIo)</b> ).	<b>[Auto] (Auto)</b> to 300%	<b>[Auto] (Auto)</b>
<b>ILr</b> ★	<b>[Injection level align]</b> Current level in % of <b>[Nominal I sync.] (nCr5)</b> for high frequency phase-shift angle measurement IPMA type.	0 to 200%	50%


**Parameters described in this page can be accessed by:** DRI- > CONF > FULL > DRC-

Code	Name / Description	Adjustment range	Factory setting
<i>S<sub>ir</sub></i> ★	<b>[Boost level align.]</b> Current level in % of <b>[Nominal I sync.]</b> ( <i>nCrS</i> ) for high frequency phase-shift angle measurement SPMA type.	0 to 200%	100%
<i>r dRE</i>	<b>[% error EMF sync]</b> Ratio D-Axis Current Use <i>r dRE</i> to adjust <b>[Syn. EMF constant]</b> ( <i>PHS</i> ), <i>r dRE</i> should be closed to 0. If the <b>[% error EMF sync]</b> ( <i>r dRE</i> ) value is lower than 0%, then <b>[Syn. EMF constant]</b> ( <i>PHS</i> ), may be increased. If the <b>[% error EMF sync]</b> ( <i>r dRE</i> ) value is upper than 0%, then <b>[Syn. EMF constant]</b> ( <i>PHS</i> ), may be reduced.	-3276.7 to 3275.8 %	-

(1) On the integrated display unit: 0 to 9,999 then 10.00 to 65.53 (10,000 to 65,536).



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; DRC-


Code	Name / Description	Adjustment range	Factory setting
<b>d r C -</b>	<b>[MOTOR CONTROL] (continued)</b>		
<b>S P G</b> ★ ( )	<b>[Speed prop. gain]</b> Speed loop proportional gain. Visible if <b>[Motor control type] (C E E)</b> is not set to <b>[Standard] (S E d)</b> , <b>[V/F 5pts] (u F 5)</b> or <b>[V/F Quad.] (u F 9)</b> .	0 to 1,000%	40%
<b>S P G u</b> ★ ( )	<b>[UF inertia comp.]</b> Inertia factor for following motor control laws. Visible if <b>[Motor control type] (C E E)</b> is set to <b>[Standard] (S E d)</b> , <b>[V/F 5pts] (u F 5)</b> or <b>[V/F Quad.] (u F 9)</b> .	0 to 1,000%	40%
<b>S i t</b> ★ ( )	<b>[Speed time integral]</b> Speed loop integral time constant. Visible if <b>[Motor control type] (C E E)</b> is not set to <b>[Standard] (S E d)</b> , <b>[V/F 5pts] (u F 5)</b> or <b>[V/F Quad.] (u F 9)</b> .	1 to 65,535 ms	63 ms
<b>S F C</b> ★ ( )	<b>[K speed loop filter]</b> Speed filter coefficient (0(IP) to 100(PI)).	0 to 100	65
<b>F F H</b> ★	<b>[Spd est. filter time]</b> Accessible in Expert mode only. Frequency to filter the estimated speed.	0 to 100 ms	6.4 ms
<b>C r t F</b> ★	<b>[Cur. ref. filter time]</b> Accessible in Expert mode only. Filter time of the current reference filter [of control law (if <b>[No] (n o)</b> : stator natural frequency)].	0 to 100 ms	3.2 ms
<b>u F r</b> ( )	<b>[IR compensation]</b> Used to optimize torque at very low speed, or to adapt to special cases (for example: for motors connected in parallel, decrease <b>[IR compensation] (u F r)</b> ). If there is insufficient torque at low speed, increase <b>[IR compensation] (u F r)</b> . A too high value can avoid the motor to start (locking) or change the current limiting mode.	0 to 200%	100%
<b>S L P</b> ★ ( )	<b>[Slip compensation]</b> This parameter cannot be accessed if <b>[Motor control type] (C E E)</b> is set to <b>[Sync. mot.] (S Y n)</b> . This parameter is written at 0% when <b>[Motor control type] (C E E)</b> is set to <b>[V/F Quad.] (u F 9)</b> . Adjusts the slip compensation around the value set by the rated motor speed. The speeds given on motor nameplates are not necessarily exact. If slip setting is lower than actual slip: The motor is not rotating at the correct speed in steady state, but at a speed lower than the reference. If slip setting is higher than actual slip: The motor is overcompensated and the speed is unstable.	0 to 300%	100%
<b>u I</b> ★	<b>[U1]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type] (C E E)</b> is set to <b>[V/F 5pts] (u F 5)</b> .	0 to 800 V according to rating	0 V
<b>F 1</b> ★	<b>[F1]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type] (C E E)</b> is set to <b>[V/F 5pts] (u F 5)</b> .	0 to 599 Hz	0 Hz
<b>u 2</b> ★	<b>[U2]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type] (C E E)</b> is set to <b>[V/F 5pts] (u F 5)</b> .	0 to 800 V according to rating	0 V
<b>F 2</b> ★	<b>[F2]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type] (C E E)</b> is set to <b>[V/F 5pts] (u F 5)</b> .	0 to 599 Hz	0 Hz

Code	Name / Description	Adjustment range	Factory setting
<span style="color: green;">U3</span> <span style="color: blue;">★</span>	<b>[U3]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 800 V according to rating	0 V
<span style="color: green;">F3</span> <span style="color: blue;">★</span>	<b>[F3]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 599 Hz	0 Hz
<span style="color: green;">U4</span> <span style="color: blue;">★</span>	<b>[U4]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 800 V according to rating	0 V
<span style="color: green;">F4</span> <span style="color: blue;">★</span>	<b>[F4]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 599 Hz	0 Hz
<span style="color: green;">U5</span> <span style="color: blue;">★</span>	<b>[U5]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 800 V according to rating	0 V
<span style="color: green;">F5</span> <span style="color: blue;">★</span>	<b>[F5]</b> V/F profile setting. This parameter can be accessed if <b>[Motor control type]</b> ( <span style="color: green;">LEL</span> ) is set to <b>[V/F 5pts]</b> ( <span style="color: green;">UF5</span> ).	0 to 599 Hz	0 Hz
<span style="color: green;">CL</span> <span style="color: blue;">★</span> <span style="font-size: 1.2em;">()</span>	<b>[Current Limitation]</b>  <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>NOTICE</b></p> <p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <ul style="list-style-type: none"> <li>Verify that the motor is properly rated for the maximum current to be applied to the motor.</li> <li>Consider the duty cycle of the motor and all factors of your application including derating requirements in determining the current limit.</li> </ul> <p><b>Failure to follow these instructions can result in equipment damage.</b></p> </div> <p>First current limitation.  <b>Note:</b> If the setting is less than 0.25 In, the drive may lock in <b>[Output Phase Loss]</b> (<span style="color: green;">oPL</span>) fault mode if this has been enabled (see page 256). If it is less than the no-load motor current, the motor cannot run.</p>	0 to 1.5 In (1)	1.5 In (1)
<span style="color: green;">SFL</span> <span style="color: green;">HF1</span> <span style="color: green;">HF2</span>	<b>[Switch. freq type]</b> The motor switching frequency will be modified (reduced) when the internal temperature of the drive will be too high. Allows the system to adapt the switching frequency according to the motor frequency. Allows the system to keep a constant chosen switching frequency <b>[Switching freq.]</b> ( <span style="color: green;">SFr</span> ) whatever the motor frequency <b>[Output frequency]</b> ( <span style="color: green;">rFr</span> ). In the event of overheating, the drive automatically decreases the switching frequency. It is restored to its original value when the temperature returns to normal.		<b>[SFR type 1]</b> ( <span style="color: green;">HF1</span> )
<span style="color: green;">SFr</span> <span style="font-size: 1.2em;">()</span>	<b>[Switching freq.]</b>  <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p><b>NOTICE</b></p> <p><b>DAMAGE TO THE MOTOR</b></p> <p>Verify that the switching frequency of the drive does not exceed 4 kHz if the EMC filter is disconnected for operation of the drive in an IT mains.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p> </div> <p>This applies to the following drive versions: ATV320●●●M2●</p> <p>Switching frequency setting.                      Adjustment range: The maximum value is limited to 4 kHz if <b>[Motor surge limit]</b> (<span style="color: green;">SUL</span>) parameter page 120 is configured.  <b>Note:</b> In the event of excessive temperature rise, the drive will automatically reduce the switching frequency and reset it once the temperature returns to normal.                      In case of high speed motor, it is advised to increase the Pulse Width Modulation (PWM) frequency <b>[Switching freq.]</b> (<span style="color: green;">SFr</span>) at 8, 12 or 16 kHz.</p>	2 to 16 kHz	4 kHz

Code	Name / Description	Adjustment range	Factory setting
<i>n r d</i>	<b>[Noise reduction]</b> Random frequency modulation helps to prevent any resonance, which may occur at a fixed frequency.		<b>[No]</b> ( <i>n o</i> )
<i>n o</i> <i>y e s</i>	<b>[No]</b> ( <i>n o</i> ): Fixed frequency <b>[Yes]</b> ( <i>y e s</i> ): Frequency with random modulation		
<i>b o A</i>	<b>[Boost activation]</b>		<b>[Dynamic]</b> ( <i>d y n A</i> )
<i>n o</i> <i>d y n A</i> <i>s t A t</i>	<b>[Inactive]</b> ( <i>n o</i> ): No boost <b>[Dynamic]</b> ( <i>d y n A</i> ): Dynamic boost <b>[Static]</b> ( <i>s t A t</i> ): Static boost		
<i>b o o</i>	<b>[Boost]</b> This parameter can be accessed if <b>[Boost activation]</b> ( <i>b o A</i> ) is not set to <b>[No]</b> ( <i>n o</i> ). Adjustment of the motor magnetizing current at low speed, as a % of the rated magnetizing current. This parameter is used to increase or reduce the time taken to establish the torque. It allows gradual adjustment up to the frequency set by <b>[Action Boost]</b> ( <i>F A b</i> ). Negative values apply particularly to tapered rotor motors.	-100 to 100%	0%
★			
<i>F A b</i>	<b>[Action Boost]</b> This parameter can be accessed if <b>[Boost activation]</b> ( <i>b o A</i> ) is not set to <b>[No]</b> ( <i>n o</i> ). Frequency above which the magnetizing current is no longer affected by <b>[Boost]</b> ( <i>b o o</i> ).	0 to 599 Hz	0 Hz
★			
<i>S u L</i>	<b>[Motor surge limit.]</b> This function limits motor overvoltages and is useful in the following applications: - NEMA motors - Japanese motors - Spindle motors - Rewound motors This parameter can remain set to <b>[No]</b> ( <i>n o</i> ) for 230/400 V motors used at 230 V, or if the length of cable between the drive and the motor does not exceed: - 4 m with unshielded cables - 10 m with shielded cables <b>Note:</b> When <b>[Motor surge limit.]</b> ( <i>S u L</i> ) is set to <b>[Yes]</b> ( <i>y e s</i> ), the maximum switching frequency <b>[Switching freq.]</b> ( <i>S F r</i> ) is modified, see page 120.		<b>[No]</b> ( <i>n o</i> )
<i>n o</i> <i>y e s</i>	<b>[No]</b> ( <i>n o</i> ): Function inactive <b>[Yes]</b> ( <i>y e s</i> ): Function active		
<i>S o P</i>	<b>[Volt surge limit. opt]</b> Optimization parameter for transient overvoltages at the motor terminals. This parameter can be accessed if <b>[Motor surge limit.]</b> ( <i>S u L</i> ) is set to <b>[Yes]</b> ( <i>y e s</i> ).		10 μs
★			
<i>6</i> <i>8</i> <i>10</i>	Set to 6, 8 or 10 μs, according to the following table. <b>Note:</b> This parameter is useful for ATV320●●●N4● drives.		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.

The value of the **[Volt surge limit. opt] (5 o P)** parameter corresponds to the attenuation time of the cable used. It is defined to help to prevent the superimposition of voltage wave reflections resulting from long cable lengths. It limits overvoltages to twice the DC bus rated voltage.

The tables on the following page give examples of correspondence between the **[Volt surge limit. opt] (5 o P)** parameter and the length of the cable between the drive and the motor. For longer cable lengths, an output of the filter or a dV/dt protection filter must be used.

For motors in parallel, the sum of all the cable lengths must be taken into consideration. Compare the length given in the table row corresponding to the power for one motor with that corresponding to the total power, and select the shorter length.

Example: Two 7.5 kW (10 HP) motors

Take the lengths on the 15 kW (20 HP) table row, which are shorter than those on the 7.5 kW (10 HP) row, and divide by the number of motors to obtain the length per motor (with unshielded "GORSE" cable and SOP = 6, the result is  $40/2 = 20$  m maximum for each 7.5 kW (10 HP) motor).

In special cases (for example, different types of cable, different motor powers in parallel, different cable lengths in parallel, etc.), we recommend using an oscilloscope to check the overvoltage values obtained at the motor terminals.


To retain the overall drive performance, do not increase the SOP value unnecessarily.

#### Tables giving the correspondence between the SOP parameter and the cable length, for 400 V supply mains

Altivar 320 Reference	Motor		Cable cross-section (min)		Maximum cable length in meters								
	Power kW	HP	in mm <sup>2</sup>	AWG	Unshielded "GORSE" cable Type H07 RN-F 4Gxx			Shielded "GORSE" cable Type GVCSTV-LS/LH			Shielded "BELDEN" cable Type 2950x		
					SOP = 10	SOP = 8	SOP = 6	SOP = 10	SOP = 8	SOP = 6	SOP = 10	SOP = 8	SOP = 6
ATV320U04N4●	0.37	0.50	1.5	14	100 m	70 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U06N4●	0.55	0.75	1.5	14	100 m	70 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U07N4●	0.75	1	1.5	14	100 m	70 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U11N4●	1.1	1.5	1.5	14	100 m	70 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U15N4●	1.5	2	1.5	14	100 m	70 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U22N4●	2.2	3	1.5	14	110 m	65 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U30N4●	3	-	1.5	14	110 m	65 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U40N4●	4	5	2.5	12	110 m	65 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U55N4●	5.5	7.5	4	10	120 m	65 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320U75N4●	7.5	10	6	8	120 m	65 m	45 m	105 m	85 m	65 m	50 m	40 m	30 m
ATV320D11N4●	11	15	10	8	115 m	60 m	45 m	100 m	75 m	55 m	50 m	40 m	30 m
ATV320D15N4●	15	20	16	6	105 m	60 m	40 m	100 m	70 m	50 m	50 m	40 m	30 m


For 230/400 V motors used at 230 V, the **[Motor surge limit.] (5 u L)** parameter can remain set to **[No] (n o)**.



Code	Name / Description	Adjustment range	Factory setting
u b r ( )	<b>[Braking level]</b> Braking transistor command level.	335 to 820 V	According to drive rating voltage
L b A ★	<b>[Load sharing]</b> When 2 motors are connected mechanically and therefore at the same speed, and each is controlled by a drive, this function can be used to improve torque distribution between the two motors. To do this, it varies the speed based on the torque. This parameter can only be accessed if <b>[Motor control type]</b> (C b E) page 105 is set to <b>[SVC V]</b> (u u C). [No] (n o) [Yes] (Y E S): Function active		[No] (n o)
L b C ★ ( )	<b>[Load correction]</b> Rated correction in Hz. This parameter can be accessed if <b>[Load sharing]</b> (L b A) is set to <b>[Yes]</b> (Y E S). 	0 to 599 Hz	0 Hz




These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.





Parameter that can be modified during operation or when stopped.

**Load sharing, parameters that can be accessed at expert level**

Principle:




The load sharing factor K is determined by the torque and speed, with two factors K1 and K2 ( $K = K1 \times K2$ ).




Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; I\_O-






Code	Name / Description	Adjustment range	Factory setting
L b C 1 ★ ( )	<b>[Correction min spd]</b> This parameter can be accessed if <b>[Load sharing] (L b R)</b> is set to <b>[Yes] (Y E S)</b> . Minimum speed for load correction in Hz. Below this threshold, no corrections are made. Used to cancel correction at very low speed if this would hamper rotation of the motor.	0 to 598.9 Hz	0 Hz
L b C 2 ★ ( )	<b>[Correction max spd]</b> This parameter can be accessed if <b>[Load sharing] (L b R)</b> is set to <b>[Yes] (Y E S)</b> . Speed threshold in Hz above which maximum load correction is applied.	<b>[Correction min spd] (L b C 1) + 0.1 at 599 Hz</b>	0.1 Hz
L b C 3 ★ ( )	<b>[Torque offset]</b> This parameter can be accessed if <b>[Load sharing] (L b R)</b> is set to <b>[Yes] (Y E S)</b> . Minimum torque for load correction as a % of the rated torque. Below this threshold, no corrections are made. Used to avoid torque instabilities when the torque direction is not constant.	0 to 300%	0%
L b F ★ ( )	<b>[Sharing filter]</b> This parameter can be accessed if <b>[Load sharing] (L b R)</b> is set to <b>[Yes] (Y E S)</b> . Time constant (filter) for correction in ms. Used in the event of flexible mechanical coupling in order to avoid instabilities.	0 to 20 s	100 ms

 These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

 Parameter that can be modified during operation or when stopped.

**Inputs / outputs CFG**

The parameters in the **[INPUTS / OUTPUTS CFG]** ( *i\_o\_c* ) menu can only be modified when the drive is stopped and no run command is present.

Code	Name / Description	Adjustment range	Factory setting
<b>FULL</b>	<b>[FULL] (continued)</b>		
<b>i_o_c</b>	<b>[INPUTS / OUTPUTS CFG]</b>		
<b>lcl</b>	<b>[2/3 wire control]</b>		<b>[2 wire] (2c)</b>
 2 s	<b>⚠ WARNING</b> <b>UNANTICIPATED EQUIPMENT OPERATION</b> If this parameter is changed, the parameters <b>[Reverse assign.] (rr5)</b> and <b>[2 wire type] (lcl)</b> and the assignments of the digital inputs are reset to the factory setting. Verify that this change is compatible with the type of wiring used. <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>		
<b>2c</b>	<b>[2 wire] (2c)</b> <b>2-wire control (level commands):</b> This is the input state (0 or 1) or edge (0 to 1 or 1 to 0) which controls running or stopping.  Example of "source" wiring:  L11: forward L1x: reverse		
<b>3c</b>	<b>[3 wire] (3c)</b> <b>3-wire control (pulse commands):</b> A "forward" or "reverse" pulse is sufficient to command starting, a "stop" pulse is sufficient to command stopping.  Example of "source" wiring:  L11: stop L12: forward L1x: reverse		
<b>lcn</b>	<b>[2 wire type]</b>		<b>[Transition] (lcn)</b>
  2 s	<b>⚠ WARNING</b> <b>UNANTICIPATED EQUIPMENT OPERATION</b> Verify that the parameter setting is compatible with the type of wiring used. <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>		
<b>lel</b>	<b>[Level] (lel):</b> State 0 or 1 is taken into account for run (1) or stop (0)		
<b>lcn</b>	<b>[Transition] (lcn):</b> A change of state (transition or edge) is necessary to initiate operation, in order to avoid accidental restarts after a break in the power supply		
<b>pf0</b>	<b>[Fwd priority] (pf0):</b> State 0 or 1 is taken into account for run or stop, but the "forward" input takes priority over the "reverse" input		

Parameters described in this page can be accessed by:


DRI- &gt; CONF &gt; FULL &gt; I\_O- &gt; L1-

Code	Name / Description	Adjustment range	Factory setting
<i>run</i> ★	<b>[Drive Running]</b> Assignment of the stop command. Visible only if <b>[2/3 wire control]</b> ( <i>EE</i> ) is set to <b>[3 wire]</b> ( <i>3E</i> ).		<b>[No]</b> ( <i>no</i> )
<i>L I 1</i> <i>Cd00</i> <i>OL01</i> ... <i>OL 10</i>	<b>[LI1]</b> ( <i>L I 1</i> ): Logical input LI1 if not in <b>[I/O profile]</b> ( <i>io</i> ) <b>[Cd00]</b> ( <i>Cd00</i> ): In <b>[I/O profile]</b> ( <i>io</i> ), can be switched with possible logic inputs <b>[OL01]</b> ( <i>OL01</i> ): Function blocks: Logical Output 01 ... <b>[OL10]</b> ( <i>OL 10</i> ): Function blocks: Logical Output 10		
<i>Frd</i>	<b>[Forward]</b> Assignment of the forward direction command.		<b>[LI1]</b> ( <i>L I 1</i> )
<i>L I 1</i> <i>Cd00</i> <i>OL01</i> ... <i>OL 10</i>	<b>[LI1]</b> ( <i>L I 1</i> ): Logical input LI1 if not in <b>[I/O profile]</b> ( <i>io</i> ) <b>[Cd00]</b> ( <i>Cd00</i> ): In <b>[I/O profile]</b> ( <i>io</i> ), can be switched with possible logic inputs <b>[OL01]</b> ( <i>OL01</i> ): Function blocks: Logical Output 01 ... <b>[OL10]</b> ( <i>OL 10</i> ): Function blocks: Logical Output 10		
<i>rrs</i>	<b>[Reverse assign.]</b> Assignment of the reverse direction command.		<b>[LI2]</b> ( <i>L I 2</i> )
<i>no</i> <i>L I 1</i> ...	<b>[No]</b> ( <i>no</i> ): Not assigned <b>[LI1]</b> ( <i>L I 1</i> ): Logical input LI1 ... <b>[...]</b> (...): See the assignment conditions on page <a href="#">153</a>		

Parameters described in this page can be accessed by: DRI- > CONF > FULL > I\_O- > L1-

Code	Name / Description	Adjustment range	Factory setting
<b>L I -</b>	<b>[LI1 CONFIGURATION]</b>		
<b>L I A</b>	<b>[LI1 assignment]</b>		
	Read-only parameter, cannot be configured. It displays all the functions that are assigned to input LI1 in order to check for multiple assignments.		
<b>n o</b>	<b>[No] (n o):</b> Not assigned		
<b>r u n</b>	<b>[Run] (r u n):</b> Run Enable		
<b>F r d</b>	<b>[Forward] (F r d):</b> Forward operation		
<b>r r S</b>	<b>[Reverse] (r r S):</b> Reverse operation		
<b>r P S</b>	<b>[Ramp switching] (r P S):</b> Ramp switching		
<b>J o G</b>	<b>[Jog] (J o G):</b> Jog operation		
<b>u S P</b>	<b>[+Speed] (u S P):</b> + speed		
<b>d S P</b>	<b>[- speed] (d S P):</b> - speed		
<b>P S 2</b>	<b>[2 preset speeds] (P S 2):</b> 2 Preset speeds		
<b>P S 4</b>	<b>[4 preset speeds] (P S 4):</b> 4 Preset speeds		
<b>P S 8</b>	<b>[8 preset speeds] (P S 8):</b> 8 Preset speeds		
<b>r F C</b>	<b>[Ref. 2 switching] (r F C):</b> Reference switching		
<b>n S t</b>	<b>[Freewheel stop] (n S t):</b> Freewheel stop		
<b>d C i</b>	<b>[DC injection] (d C i):</b> Injection DC stop		
<b>F S t</b>	<b>[Fast stop] (F S t):</b> Fast stop		
<b>F L o</b>	<b>[Forced local] (F L o):</b> Forced local mode		
<b>r S F</b>	<b>[Fault reset] (r S F):</b> Fault reset		
<b>t u L</b>	<b>[Auto-tuning] (t u L):</b> Auto-tuning		
<b>S P n</b>	<b>[Ref. memo.] (S P n):</b> Save reference		
<b>F L i</b>	<b>[Pre Fluxing] (F L i):</b> Motor fluxing		
<b>P R u</b>	<b>[Auto / manual] (P R u):</b> PI(D) auto-manu		
<b>P i S</b>	<b>[PID integral reset] (P i S):</b> Integral shunting PI(D)		
<b>P r 2</b>	<b>[2 preset PID ref.] (P r 2):</b> 2 Preset PI(D) references		
<b>P r 4</b>	<b>[4 preset PID ref.] (P r 4):</b> 4 Preset PI(D) references		
<b>t L A</b>	<b>[Torque limitation] (t L A):</b> Permanent torque limitation		
<b>E t F</b>	<b>[External fault] (E t F):</b> External fault		
<b>r C A</b>	<b>[Output contact. fdbk] (r C A):</b> Downstream contactor feedback		
<b>C n F 1</b>	<b>[2 config. switching] (C n F 1):</b> Configuration switching 1		
<b>C n F 2</b>	<b>[3 config. switching] (C n F 2):</b> Configuration switching 2		
<b>C H A 1</b>	<b>[2 parameter sets] (C H A 1):</b> Parameter switching 1		
<b>C H A 2</b>	<b>[3 parameter sets] (C H A 2):</b> Parameter switching 2		
<b>t L C</b>	<b>[Activ. Analog torque limitation] (t L C):</b> Torque limitation: Activation (analog input) by a logic input		
<b>C C S</b>	<b>[Cmd switching] (C C S):</b> Command channel switching		
<b>i n H</b>	<b>[Fault inhibition] (i n H):</b> Fault inhibition		
<b>P S 16</b>	<b>[16 preset speeds] (P S 16):</b> 16 preset speeds		
<b>L C 2</b>	<b>[Current limit 2] (L C 2):</b> Current limitation switching		
<b>r C b</b>	<b>[Ref 1B switching] (r C b):</b> Reference channel switching (1 to 1B)		
<b>t r C</b>	<b>[Traverse control] (t r C):</b> Traverse control		
<b>b C i</b>	<b>[Brake contact] (b C i):</b> Brake logic input contact		
<b>S A F</b>	<b>[Stop FW limit sw.] (S A F):</b> Stop switch forward		
<b>S A r</b>	<b>[Stop RV limit sw.] (S A r):</b> Stop switch reverse		
<b>d A F</b>	<b>[Slowdown forward] (d A F):</b> Slowdown attained forward		
<b>d A r</b>	<b>[Slowdown reverse] (d A r):</b> Slowdown attained reverse		
<b>C L S</b>	<b>[Disable limit sw.] (C L S):</b> Limits switches clearing		
<b>L E S</b>	<b>[Drive lock (Line contact. ctrl)] (L E S):</b> Emergency stop		
<b>r t r</b>	<b>[Init. traverse ctrl.] (r t r):</b> Reload traverse control		
<b>S n C</b>	<b>[Counter wobble] (S n C):</b> Counter wobble synchronization		
<b>r P A</b>	<b>[Prod. reset] (r P A):</b> Reset Product		
<b>S H 2</b>	<b>[2 HSP] (S H 2):</b> High Speed 2		
<b>S H 4</b>	<b>[4 HSP] (S H 4):</b> High Speed 4		
<b>F P S 1</b>	<b>[Preset spd2] (F P S 1):</b> Function key preset speed 1 assignment		
<b>F P S 2</b>	<b>[Preset spd3] (F P S 2):</b> Function key preset speed 2 assignment		
<b>F P r 1</b>	<b>[PID ref. 2] (F P r 1):</b> Function key preset PI 1 assignment		
<b>F P r 2</b>	<b>[PID ref. 3] (F P r 2):</b> Function key preset PI 2 assignment		
<b>F u S P</b>	<b>[+Speed] (F u S P):</b> Function key faster assignment		
<b>F d S P</b>	<b>[-Speed] (F d S P):</b> Function key slower assignment		
<b>F t</b>	<b>[T/K] (F t):</b> Function key bumpless assignment		
<b>u S i</b>	<b>[+speed around ref.] (u S i):</b> + Speed around ref		
<b>d S i</b>	<b>[-speed around ref.] (d S i):</b> - Speed around ref		

Code	Name / Description	Adjustment range	Factory setting
<p> <i>u5</i> : [+speed around ref.] (<i>u5</i> ) : + Speed around ref  <i>d5</i> : [-speed around ref.] (<i>d5</i> ) : - Speed around ref  <i>IL01</i> (<i>IL01</i>) : Function blocks: Logical Input 1                      ...  <i>IL10</i> (<i>IL10</i>) : Function blocks: Logical Input 10  <i>FB start</i> (<i>FB start</i>) : Function blocks: Run mode  <i>SLS1</i> (<i>SLS ch.1</i>) (<i>SLS1</i>) : SLS safety function Channel 1  <i>SLS2</i> (<i>SLS ch.2</i>) (<i>SLS2</i>) : SLS safety function Channel 2  <i>SS11</i> (<i>SS1 ch.1</i>) (<i>SS11</i>) : SS1 safety function Channel 1  <i>SS12</i> (<i>SS1 ch.2</i>) (<i>SS12</i>) : SS1 safety function Channel 2  <i>STO1</i> (<i>STO ch.1</i>) (<i>STO1</i>) : STO safety function Channel 1  <i>STO2</i> (<i>STO ch.2</i>) (<i>STO2</i>) : STO safety function Channel 2  <i>SMS1</i> (<i>SMS ch.1</i>) (<i>SMS1</i>) : SMS safety function Channel 1  <i>SMS2</i> (<i>SMS ch.2</i>) (<i>SMS2</i>) : SMS safety function Channel 2                 </p> <p><b>Note:</b> Safety function channels are available for LI3-LI4 and LI5-LI6 only.</p>			
<i>L1d</i>	<p><b>[LI1 On Delay]</b></p> <p>This parameter is used to take account of the change of the logic input to state 1 with a delay that can be adjusted between 0 and 200 milliseconds, in order to filter out possible interference. The change to state 0 is taken into account without delay.</p>	0 to 200 ms	0 ms
<i>i-o-</i>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<i>L2-</i> to <i>L6-</i>	<b>[LIx CONFIGURATION]</b> All the logic inputs available on the drive are processed as in the example for LI1 above, up to LI6.		
<i>L5-</i>	<b>[LI5 CONFIGURATION]</b> Specific parameters for LI5 used as a pulse input.		
<i>P, A</i>	<p><b>[RP assignment]</b></p> <p>Read-only parameter, cannot be configured. It displays all the functions associated with the Pulse input in order to check, for example, for compatibility problems.</p> <p>Identical to <b>[AI1 assignment]</b> (<i>A1IA</i>) page 133.</p>		
<i>P, L</i>	<p><b>[RP min value]</b></p> <p>Pulse input scaling parameter of 0% in Hz * 10 unit.</p>	0 to 20.00 kHz	0 kHz
<i>P, F, r</i>	<p><b>[RP max value]</b></p> <p>Pulse input scaling parameter of 100% in Hz * 10 unit.</p>	0 to 20.00 kHz	20.00 kHz
<i>P, F, i</i>	<p><b>[RP filter]</b></p> <p>I/O ext Pulse input cutoff time of the low-filter.</p>	0 to 1,000 ms	0 ms
<i>LA1-</i> <i>LA2-</i>	<b>[LAX CONFIGURATION]</b> The 2 analog inputs AI1 and AI2 on the drive could be used as LI inputs and are processed as in the example for LI1 above.		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.





To change the assignment of this parameter, press the ENT key for 2 s.

### Configuration of analog inputs and Pulse input

The minimum and maximum input values (in volts, mA, etc.) are converted to % in order to adapt the references to the application.

#### Minimum and maximum input values:

The minimum value corresponds to a reference of 0% and the maximum value to a reference of 100%. The minimum value may be greater than the maximum value:



For +/- bidirectional inputs, the min. and max. are relative to the absolute value, for example +/- 2 to 8 V.









Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; I\_O-

**Range (output values): For analog inputs only:**

This parameter is used to configure the reference range to [0% → 100%] or [-100% → +100%] in order to obtain a bidirectional output from a unidirectional input.



Code	Name / Description	Adjustment range	Factory setting
<b>1 - 0 -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>b 5 P</b>	<b>[Reference template]</b>		<b>[Standard] (b 5 d)</b>
<b>b 5 d</b>	<b>[Standard] (b 5 d)</b>		
<b>( )</b>	 <p>At zero reference the frequency = LSP</p>		
<b>b L 5</b>	<b>[Pedestal] (b L 5)</b>		
<b>( )</b>	 <p>At reference = 0 to LSP the frequency = LSP</p>		
<b>b n 5</b>	<b>[Deadband] (b n 5)</b>		
<b>( )</b>	 <p>At reference = 0 to LSP the frequency = 0</p>		
<b>b n 5 0</b>	<b>[Deadband 0] (b n 5 0)</b>		
<b>( )</b>	 <p>This operation is the same as <b>[Standard] (b 5 d)</b>, except that in the following cases at zero reference, the frequency = 0:                  The signal is less than <b>[Min value]</b>, which is greater than 0 (example 1 V on a 2 - 10 V input)                  The signal is greater than <b>[Min value]</b>, which is greater than <b>[Max value]</b> (example: 11 V on a 10 - 0 V input).                  If the input range is configured as "bidirectional", operation remains identical to <b>[Standard] (b 5 d)</b>.                  This parameter defines how the speed reference is taken into account, for analog inputs and Pulse input only. In the case of the PID regulator, this is the PID output reference.                  The limits are set by the <b>[Low speed] (L 5 P)</b> and <b>[High speed] (H 5 P)</b> parameters, page 87.</p>		

**( )** Parameter that can be modified during operation or when stopped.


**Delinearization: For analog inputs only:**

The input can be delinearized by configuring an intermediate point on the input/output curve of this input:

Parameters described in this page can be accessed by:


DRI- > CONF > FULL > I\_O- > AI1-

For range 0 → 100%



**Note:** For [Interm. point X], 0% corresponds to [Min value] and 100% to [Max value].

For range -100% → 100%



Code	Name / Description	Adjustment range	Factory setting
<b>A I I -</b>	<b>[AI1 CONFIGURATION]</b>		
<b>A I I A</b>	<b>[AI1 assignment]</b>		
	Read-only parameter, cannot be configured. It displays all the functions associated with input AI1 in order to check, for example, for compatibility problems.		
<b>n o</b>	<b>[No]</b> ( <b>n o</b> ): Not assigned		
<b>A o I</b>	<b>[AO1 assignment]</b> ( <b>A o I</b> ): Analog output AO1		
<b>F r 1</b>	<b>[Ref.1 channel]</b> ( <b>F r 1</b> ): Reference source 1		
<b>F r 2</b>	<b>[Ref.2 channel]</b> ( <b>F r 2</b> ): Reference source 2		
<b>S R 2</b>	<b>[Summing ref. 2]</b> ( <b>S R 2</b> ): Summing reference 2		
<b>P , F</b>	<b>[PID feedback]</b> ( <b>P , F</b> ): PI feedback (PI control)		
<b>t A A</b>	<b>[Torque limitation]</b> ( <b>t A A</b> ): Torque limitation: Activation by an analog value		
<b>d R 2</b>	<b>[Subtract. ref. 2]</b> ( <b>d R 2</b> ): Subtracting reference 2		
<b>P , n</b>	<b>[Manual PID ref.]</b> ( <b>P , n</b> ): Manual speed reference of the PI(D) regulator (auto-man)		
<b>F P , i</b>	<b>[PID speed ref.]</b> ( <b>F P , i</b> ): Speed reference of the PI(D) regulator (predictive reference)		
<b>S R 3</b>	<b>[Summing ref. 3]</b> ( <b>S R 3</b> ): Summing reference 3		
<b>F r 1 b</b>	<b>[Ref.1B channel]</b> ( <b>F r 1 b</b> ): Reference source 1B		
<b>d R 3</b>	<b>[Subtract. ref. 3]</b> ( <b>d R 3</b> ): Subtracting reference 3		
<b>F L o C</b>	<b>[Forced local]</b> ( <b>F L o C</b> ): Forced local reference source		
<b>n A 2</b>	<b>[Ref.2 multiplier]</b> ( <b>n A 2</b> ): Multiplying reference 2		
<b>n A 3</b>	<b>[Ref. 3 multiplier]</b> ( <b>n A 3</b> ): Multiplying reference 3		
<b>P E 5</b>	<b>[Weight input]</b> ( <b>P E 5</b> ): Hoisting: External weight measurement function		
<b>, A 0 1</b>	<b>[IA01]</b> ( <b>, A 0 1</b> ): Function blocks: Analog Input 01		
...	...		
<b>, A 1 0</b>	<b>[IA10]</b> ( <b>, A 1 0</b> ): Function blocks: Analog Input 10		
<b>A I I t</b>	<b>[AI1 Type]</b>		<b>[Voltage]</b> ( <b>I O u</b> )
<b>I O u</b>	<b>[Voltage]</b> ( <b>I O u</b> ): Positive voltage input 0 - 10 V (negative values are interpreted as zero: the input is unidirectional)		
<b>u , L I</b>	<b>[AI1 min value]</b>	0 to 10.0 V	0 V
	AI1 voltage scaling parameter of 0%.		
<b>u , H I</b>	<b>[AI1 max value]</b>	0 to 10.0 V	10.0 V
	AI1 voltage scaling parameter of 100%.		
<b>A I I F</b>	<b>[AI1 filter]</b>	0 to 10.00 s	0 s
	Interference filtering.		
<b>A I I L</b>	<b>[AI1 range]</b>		<b>[0 - 100%]</b> ( <b>P o 5</b> )
<b>P o 5</b>	<b>[0 - 100%]</b> ( <b>P o 5</b> ): Positive logical		
<b>n E G</b>	<b>[+/- 100%]</b> ( <b>n E G</b> ): Positive and negative logical		
<b>A I I E</b>	<b>[AI1 Interm. point X]</b>	0 to 100%	0%
	Input delinearization point coordinate. Percentage of the physical input signal. 0% corresponds to <b>[AI1 min value]</b> ( <b>u , L I</b> ). 100% corresponds to <b>[AI1 max value]</b> ( <b>u , H I</b> ).		
<b>A I I S</b>	<b>[AI1 Interm. point Y]</b>	0 to 100%	0%
	Output delinearization point coordinate (frequency reference). Percentage of the internal frequency reference corresponding to the <b>[AI1 Interm. point X]</b> ( <b>A I I E</b> ) percentage of physical input signal.		
<b>I _ o -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>A I 2 -</b>	<b>[AI2 CONFIGURATION]</b>		
<b>A I 2 A</b>	<b>[AI2 assignment]</b>		
	Identical to <b>[AI1 assignment]</b> ( <b>A I I A</b> ) page 133.		
<b>A I 2 t</b>	<b>[AI2 Type]</b>		<b>[Voltage +/-]</b> ( <b>n I O u</b> )
<b>I O u</b>	<b>[Voltage]</b> ( <b>I O u</b> ): Positive voltage input 0 - 10 V (negative values are interpreted as zero: the input is unidirectional)		
<b>n I O u</b>	<b>[Voltage +/-]</b> ( <b>n I O u</b> ): Positive and negative voltage input +/- 10 V (the input is bidirectional)		
<b>u , L 2</b>	<b>[AI2 min value]</b>	0 to 10.0 V	0 V
	AI2 voltage scaling parameter of 0%.		

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; I\_O- &gt; AU2-

Code	Name / Description	Adjustment range	Factory setting
<b>U I H 2</b>	<b>[AI2 max. value]</b> AI2 voltage scaling parameter of 100%.	0 to 10.0 V	10.0 V
<b>R I 2 F</b>	<b>[AI2 filter]</b> Interference filtering.	0 to 10.00 s	0 s
<b>R I 2 L</b>	<b>[AI2 range]</b> This parameter is forced to <b>[0 - 100%]</b> ( <b>P 0 5</b> ) and can not be accessed if <b>[AI2 Type]</b> ( <b>R I 2 L</b> ) (page 133) is set to <b>[Voltage +/-]</b> ( <b>n I 0 u</b> ).		<b>[0 - 100%]</b> ( <b>P 0 5</b> )
<b>P 0 5</b> <b>n E G</b>	<b>[0 - 100%]</b> ( <b>P 0 5</b> ): Positive logical <b>[+/- 100%]</b> ( <b>n E G</b> ): Positive and negative logical		
<b>R I 2 E</b>	<b>[AI2 Interm. point X]</b> Input delinearization point coordinate. Percentage of the physical input signal. 0% corresponds to <b>[Min value]</b> if the range is 0 → 100%.  0% corresponds to $\frac{[\text{Max value}] + [\text{Min value}]}{2}$ if the range is -100% → +100%. 100% corresponds to <b>[Max value]</b> .	0 to 100%	0%
<b>R I 2 S</b>	<b>[AI2 Interm. point Y]</b> Output delinearization point coordinate (frequency reference). Percentage of the internal frequency reference corresponding to the <b>[AI2 Interm. point X]</b> ( <b>R I 2 E</b> ) percentage of physical input signal.	0 to 100%	0%
<b>I O -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>R I 3 -</b>	<b>[AI3 CONFIGURATION]</b>		
<b>R I 3 A</b>	<b>[AI3 assignment]</b> Identical to <b>[AI1 assignment]</b> ( <b>R I 1 A</b> ) page 133.		
<b>R I 3 E</b> <b>O A</b>	<b>[AI3 Type]</b> <b>[Current]</b> ( <b>O A</b> ): Current input 0 - 20 mA		<b>[Current]</b> ( <b>O A</b> )
<b>C r L 3</b>	<b>[AI3 min. value]</b> AI3 current scaling parameter of 0%.	0 to 20.0 mA	0 mA
<b>C r H 3</b>	<b>[AI3 max. value]</b> AI3 current scaling parameter of 100%.	0 to 20.0 mA	20.0 mA
<b>R I 3 F</b>	<b>[AI3 filter]</b> Interference filtering.	0 to 10.00 s	0 s
<b>R I 3 L</b> <b>P 0 5</b> <b>n E G</b>	<b>[AI3 range]</b> <b>[0 - 100%]</b> ( <b>P 0 5</b> ): Unidirectional input <b>[+/- 100%]</b> ( <b>n E G</b> ): Bidirectional input Example: On a 4 - 20 mA input. 4 mA corresponds to reference -100%. 12 mA corresponds to reference 0%. 20 mA corresponds to reference +100%. Since AI3 is, in physical terms, a bidirectional input, the <b>[+/- 100%]</b> ( <b>n E G</b> ) configuration must only be used if the signal applied is unidirectional. A bidirectional signal is not compatible with a bidirectional configuration.		<b>[0 - 100%]</b> ( <b>P 0 5</b> )
<b>R I 3 E</b>	<b>[AI3 Interm. point X]</b> Input delinearization point coordinate. Percentage of the physical input signal. 0% corresponds to <b>[Min value]</b> ( <b>C r L 3</b> ) if the range is 0 → 100%.  0% corresponds to $\frac{[\text{AI3 max. value}] (\text{C r H 3}) - [\text{AI3 min. value}] (\text{C r L 3})}{(\text{C r L 3})}$ if the range is -100% → +100%. 100% corresponds to <b>[AI3 max. value]</b> ( <b>C r H 3</b> ).	0 to 100%	0%

**Parameters described in this page can be accessed by:** DRI- > CONF > FULL > I\_O- > IEn-


Code	Name / Description	Adjustment range	Factory setting
<i>R I 35</i>	<b>[AI3 Interm. point Y]</b> Output delinearization point coordinate (frequency reference). Percentage of the internal frequency reference corresponding to the <b>[AI3 Interm. point X]</b> ( <i>R I 3E</i> ) percentage of physical input signal.	0 to 100%	0%
<i>I O -</i>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<i>R U 1 -</i>	<b>[VIRTUAL AI1]</b>		
<i>R U 1 A</i>	<b>[AIV1 assignment]</b> Virtual analog input 1 via the jog dial available on the front side of the product. Identical to <b>[AI1 assignment]</b> ( <i>R I 1 A</i> ) page 133.		
<i>R U 2 -</i>	<b>[VIRTUAL AI2]</b>		
<i>R U 2 A</i>	<b>[AIV2 assignment]</b> Possible assignments for <b>[AI virtual 2]</b> ( <i>R U 2</i> ): Virtual analog input 2 via communication channel, to be configured with <b>[AI2 net. channel]</b> ( <i>R I C 2</i> ).  Identical to <b>[AIV1 assignment]</b> ( <i>R U 1 A</i> ) page 133.		
<i>R I C 2</i>  ★  <i>n o</i> <i>M o d b</i> <i>C A N</i> <i>n E t</i>	<b>[AI2 net. Channel]</b> <b>[VIRTUAL AI2]</b> ( <i>R U 2 A</i> ) source channel. This parameter can also be accessed in the <b>[PID REGULATOR]</b> ( <i>P I d -</i> ) submenu page 210. Scale: The value 8192 transmitted by this input is equivalent to 10 V on a 10 V input.  <i>n o</i> <b>[No]</b> ( <i>n o</i> ): Not assigned <i>M o d b</i> <b>[Modbus]</b> ( <i>M o d b</i> ): Integrated Modbus <i>C A N</i> <b>[CANopen]</b> ( <i>C A N</i> ): Integrated CANopen® <i>n E t</i> <b>[Com. card]</b> ( <i>n E t</i> ): Communication card (if inserted)		<b>[No]</b> ( <i>n o</i> )
<i>I E n -</i>	<b>[ENCODER CONFIGURATION]</b> Following parameters can be accessed if the speed monitoring card VW3A3620 has been inserted.		
<i>E n u</i>  <i>n o</i> <i>S E C</i>	<b>[Encoder usage]</b> <i>n o</i> <b>[No]</b> ( <i>n o</i> ): Function inactive. <i>S E C</i> <b>[Fdbk monit.]</b> ( <i>S E C</i> ): The encoder provides speed feedback for monitoring.		<b>[No]</b> ( <i>n o</i> )
<i>E n 5</i>  ★  <i>A A B b b</i> <i>A b</i>	<b>[Encoder type]</b> Encoder usage configuration.  Encoder usage configuration. To be configured in accordance with the type of encoder used.  <i>A A B b b</i> <b>[AABB]</b> ( <i>A A b b</i> ): For signals A, /A, B, /B. <i>A b</i> <b>[AB]</b> ( <i>A b</i> ): For signals A, B.  Following parameters can be accessed if <b>[Encoder usage]</b> ( <i>E n u</i> ) is set to <b>[Fdbk monit.]</b> ( <i>S E C</i> ).		<b>[AABB]</b> ( <i>A A b b</i> )
<i>P C I</i>  ★	<b>[Number of pulses]</b> Encoder usage configuration.  Number of pulses per encoder revolution. Following parameters can be accessed if <b>[Encoder usage]</b> ( <i>E n u</i> ) is set to <b>[Fdbk monit.]</b> ( <i>S E C</i> ).	100 to 3600	1024

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > I\_O- > IEn-

Load slip detection :



The drive will detect an error and display the error code [Load slipping] (RnF) in the following cases:

- As soon as the RUN order is received, if the sign of the output frequency and the speed feedback are in opposite way during [ANF Time Thd.] (tAnF).
- During operation:
  - if the speed feedback is in the same direction than the output frequency
  - and the speed feedback is over [ANF Detection level] (LAnF).
  - and,
    - "if [ANF Direction check] (dAnF) is set to [Over] (Over), the difference between the output frequency and the speed feedback is over [ANF Frequency Thd.] (FRnF) during [ANF Time Thd.] (TAnF) (Overspeed detection).
    - or,
    - "if [ANF Direction check] (dAnF) is set to [Both] (Both), the difference between the output frequency and the speed feedback is over [ANF Frequency Thd.] (FRnF) or below - [ANF Frequency Thd.] (FRnF) during [ANF Time Thd.] (tAnF) (Overspeed or underspeed detection).

Code	Name / Description	Adjustment range	Factory setting
I_o-	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
IEn-	<b>[ENCODER CONFIGURATION] (continued)</b> Following parameters can be accessed if the speed monitoring card VW3A3620 has been inserted and if [Encoder usage] (Enu) is set to [Fdbk monit.] (SEL).		
FRnF ★	<b>[ANF Frequency Thd.]</b> Level of [Load slipping] (RnF) detected error.  The drive will not detect the error [Load slipping] (RnF) if the difference between the output frequency and the speed feedback is below than [ANF Frequency Thd.] (FRnF).	0.1 to 50 Hz	5.0 Hz
LAnF ★	<b>[ANF Detection level]</b> Level of ANF detected error.  The drive will not detect the error [Load slipping] (RnF) if the speed feedback is below [ANF Detection level] (LAnF).	0 to 10 Hz	0.0 Hz

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > I\_O- > LO1-

Code	Name / Description	Adjustment range	Factory setting
<i>dRnF</i>	<b>[ANF Direction check]</b>		<b>[Over]</b> ( <i>ouEr</i> )
★ <i>ouEr</i> <i>both</i>	Available [Load slipping] ( <i>RnF</i> ) detection direction.  <i>[Over]</i> ( <i>ouEr</i> ): The drive will detect the error [Load slipping] ( <i>RnF</i> ) in case of overspeed. <i>[Both]</i> ( <i>both</i> ): The drive will detect the error [Load slipping] ( <i>RnF</i> ) in case of overspeed or underspeed.		
<i>tRnF</i>	<b>[ANF Time Thd.]</b>	0 to 10 s	0.10 s
★	Level of [Load slipping] ( <i>RnF</i> ) detected error.  The drive will detect the error [Load slipping] ( <i>RnF</i> ) if the conditions are present during [ANF Time Thd.] ( <i>RnF</i> ).		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > I\_O- > DO1-

Code	Name / Description	Adjustment range	Factory setting
<b>I - O -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>r l -</b>	<b>[R1 CONFIGURATION]</b>		
<b>r l</b>	<b>[R1 Assignment]</b>		<b>[No drive flt] (F L E)</b>
<b>no</b>	[No] ( <b>no</b> ): Not assigned		
<b>F L E</b>	[No drive flt] ( <b>F L E</b> ): Drive fault detection status (relay normally energized, and de-energized in the event of an error)		
<b>r un</b>	[Drv running] ( <b>r un</b> ): Drive running		
<b>F t A</b>	[Freq. Th. attain.] ( <b>F t A</b> ): Frequency threshold attained ( <b>[Freq. threshold]</b> ( <b>F t d</b> ) page 102)		
<b>F L A</b>	[HSP attain.] ( <b>F L A</b> ): High speed attained		
<b>C t A</b>	[I attained] ( <b>C t A</b> ): Current threshold attained ( <b>[Current threshold]</b> ( <b>C t d</b> ) page 102)		
<b>S r A</b>	[Freq.ref.att] ( <b>S r A</b> ): Frequency reference attained		
<b>t S A</b>	[Th.mot. att.] ( <b>t S A</b> ): Motor 1 thermal state attained		
<b>P E E</b>	[PID error al] ( <b>P E E</b> ): PID error alarm		
<b>P F A</b>	[PID fdbk al] ( <b>P F A</b> ): PID feedback alarm		
<b>F 2 A</b>	[Freq. Th. 2 attained] ( <b>F 2 A</b> ): Frequency threshold 2 attained ( <b>[Freq. threshold 2]</b> ( <b>F 2 d</b> ) page 102)		
<b>t A d</b>	[Th. drv. att.] ( <b>t A d</b> ): Drive thermal state attained		
<b>u L A</b>	[Pro.Undload] ( <b>u L A</b> ): Underload alarm		
<b>o L A</b>	[Ovld.P.Alrm] ( <b>o L A</b> ): Overload alarm		
<b>r S d A</b>	[Rope slack] ( <b>r S d A</b> ): Rope slack (see <b>[Rope slack config.]</b> ( <b>r S d</b> ) parameter page 205)		
<b>t t H A</b>	[High tq. att.] ( <b>t t H A</b> ): Motor torque overshooting high threshold ( <b>[High torque thd.]</b> ( <b>t t H</b> ) page 102)		
<b>t t L A</b>	[Low tq. att.] ( <b>t t L A</b> ): Motor torque undershooting low threshold ( <b>[Low torque thd.]</b> ( <b>t t L</b> ) page 102)		
<b>F F r d</b>	[Forward] ( <b>F F r d</b> ): Motor in forward rotation		
<b>R r r S</b>	[Reverse] ( <b>R r r S</b> ): Motor in reverse rotation		
<b>t S 2</b>	[Th.mot2 att] ( <b>t S 2</b> ): Motor 2 thermal threshold (TTD2) reached		
<b>t S 3</b>	[Th.mot3 att] ( <b>t S 3</b> ): Motor 3 thermal threshold (TTD3) reached		
<b>A t S</b>	[Neg Torque] ( <b>A t S</b> ): Negative torque (braking)		
<b>C n F 0</b>	[Cnfg.0 act.] ( <b>C n F 0</b> ): Configuration 0 active		
<b>C n F 1</b>	[Cnfg.1 act.] ( <b>C n F 1</b> ): Configuration 1 active		
<b>C n F 2</b>	[Cnfg.2 act.] ( <b>C n F 2</b> ): Configuration 2 active		
<b>C F P 1</b>	[Set 1 active] ( <b>C F P 1</b> ): Parameter set 1 active		
<b>C F P 2</b>	[Set 2 active] ( <b>C F P 2</b> ): Parameter set 2 active		
<b>C F P 3</b>	[Set 3 active] ( <b>C F P 3</b> ): Parameter set 3 active		
<b>d b L</b>	[DC charged] ( <b>d b L</b> ): DC bus charging		
<b>b r S</b>	[In braking] ( <b>b r S</b> ): Drive braking		
<b>P r n</b>	[P. removed] ( <b>P r n</b> ): Drive locked by "Safe Torque Off" input		
<b>F 9 L A</b>	[Fr.met. alar.] ( <b>F 9 L A</b> ): Measured speed threshold attained ( <b>[Pulse warning thd.]</b> ( <b>F 9 L</b> ) page 102)		
<b>n C P</b>	[I present] ( <b>n C P</b> ): Motor current present		
<b>L S A</b>	[Limit sw. att] ( <b>L S A</b> ): Limit switch attained		
<b>d L d A</b>	[Load alarm] ( <b>d L d A</b> ): Load variation detection (see page 267)		
<b>A G 1</b>	[Alarm Grp 1] ( <b>A G 1</b> ): Alarm group 1		
<b>A G 2</b>	[Alarm Grp 2] ( <b>A G 2</b> ): Alarm group 2		
<b>A G 3</b>	[Alarm Grp 3] ( <b>A G 3</b> ): Alarm group 3		
<b>P L A</b>	[LI6=PTC al.] ( <b>P L A</b> ): LI6 = PTCL alarm		
<b>E F A</b>	[Ext. fault al] ( <b>E F A</b> ): External fault alarm		
<b>u S A</b>	[Under V. al.] ( <b>u S A</b> ): Undervoltage alarm		
<b>u P A</b>	[Uvoltage warn] ( <b>u P A</b> ): Undervoltage threshold		
<b>t H A</b>	[Al. °C drv] ( <b>t H A</b> ): Drive overheating		
<b>S S A</b>	[Lim T/I att.] ( <b>S S A</b> ): Torque limit alarm		
<b>t J A</b>	[IGBT al.] ( <b>t J A</b> ): Thermal junction alarm		
<b>A P 3</b>	[AI3 Al. 4-20] ( <b>A P 3</b> ): AI3 4-20 mA loss alarm		
<b>r d Y</b>	[Ready] ( <b>r d Y</b> ): Ready to start		
<b>r l -</b>	<b>[R1 CONFIGURATION] (continued)</b>		
<b>r l d</b> (1)	<b>[R1 Delay time]</b>	0 to 60,000 ms	0 ms
	The change in state only takes effect once the configured time has elapsed, when the information becomes true. The delay cannot be set for the <b>[No drive flt] (F L E)</b> assignment, and remains at 0.		
<b>r l S</b>	<b>[R1 Active at]</b>		<b>[1] (P o S)</b>
	Configuration of the operating logic:		
<b>P o S</b>	<b>[1] (P o S)</b> : State 1 when the information is true		
<b>n E G</b>	<b>[0] (n E G)</b> : State 0 when the information is true		
	Configuration <b>[1] (P o S)</b> cannot be modified for the <b>[No drive flt] (F L E)</b> assignment.		

Code	Name / Description	Adjustment range	Factory setting
<i>r 1H</i>	<b>[R1 Holding time]</b> The change in state only takes effect once the configured time has elapsed, when the information becomes false. The holding time cannot be set for the <b>[No drive flt]</b> ( <i>FLt</i> ) assignment, and remains at 0.	0 to 9,999 ms	0 ms
<i>r 1F</i>	<b>[Enable Relay1 fallback]</b> Available if <b>[R1 Assignment]</b> ( <i>r 1</i> ) page 138 is set <b>[No]</b> ( <i>no</i> ) : Not assigned		<b>[No]</b> ( <i>no</i> )
<i>YES</i> <i>no</i>	<b>[YES]</b> ( <i>YES</i> ): Relay controlled by OL1R. The relay is de-energized if the drive is in operating state "Fault" <b>[No]</b> ( <i>no</i> ): Relay controlled by OL1R.		
<i>1 - 0 -</i>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<i>r 2 -</i>	<b>[R2 CONFIGURATION]</b>		
<i>r 2</i>	<b>[R2 Assignment]</b> Identical to <b>[R1 Assignment]</b> ( <i>r 1</i> ) page 138 with the addition of: <i>b L C</i> <b>[Brk control]</b> ( <i>b L C</i> ): Brake contactor control <i>L L C</i> <b>[Input cont.]</b> ( <i>L L C</i> ): Line contactor control <i>o C C</i> <b>[Output cont.]</b> ( <i>o C C</i> ): Output contactor control <i>E b o</i> <b>[End reel]</b> ( <i>E b o</i> ): End of reel (traverse control function) <i>t 5 y</i> <b>[Sync. wobble]</b> ( <i>t 5 y</i> ): "Counter wobble" synchronization <i>d C o</i> <b>[DC charging]</b> ( <i>d C o</i> ): DC bus precharging contactor control <i>o L 0 1</i> <b>[OL01]</b> ( <i>o L 0 1</i> ): Function blocks: Logical Output 01 ... <i>o L 1 0</i> <b>[OL10]</b> ( <i>o L 1 0</i> ): Function blocks: Logical Output 10		<b>[No]</b> ( <i>no</i> )
<i>r 2 d</i> (1)	<b>[R2 Delay time]</b> The delay cannot be set for the <b>[No drive flt]</b> ( <i>FLt</i> ), <b>[Brk control]</b> ( <i>b L C</i> ), <b>[Output cont.]</b> ( <i>o C C</i> ) and <b>[Input cont.]</b> ( <i>L L C</i> ) assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes true.	0 to 60,000 ms	0 ms
<i>r 2 5</i>	<b>[R2 Active at]</b> Configuration of the operating logic: <i>P o 5</i> <b>[1]</b> ( <i>P o 5</i> ): State 1 when the information is true <i>n E 0</i> <b>[0]</b> ( <i>n E 0</i> ): State 0 when the information is true The configuration <b>[1]</b> ( <i>P o 5</i> ) cannot be modified for the <b>[No drive flt]</b> ( <i>FLt</i> ), <b>[Brk control]</b> ( <i>b L C</i> ), <b>[DC charging]</b> ( <i>d C o</i> ), and <b>[Input cont.]</b> ( <i>L L C</i> ) assignments.		<b>[1]</b> ( <i>P o 5</i> )
<i>r 2 H</i>	<b>[R2 Holding time]</b> The holding time cannot be set for the <b>[No drive flt]</b> ( <i>FLt</i> ), <b>[Brk control]</b> ( <i>b L C</i> ) and <b>[Input cont.]</b> ( <i>L L C</i> ) assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes false.	0 to 9,999 ms	0 ms
<i>r 2 F</i>	<b>[Enable Relay2 fallback]</b> Available if <b>[R2 Assignment]</b> ( <i>r 2</i> ) page 139 is set <b>[No]</b> ( <i>no</i> ) : Not assigned		<b>[No]</b> ( <i>no</i> )
<i>YES</i> <i>no</i>	<b>[YES]</b> ( <i>YES</i> ): Relay controlled by OL1R. The relay is de-energized if the drive is in operating state "Fault" <b>[No]</b> ( <i>no</i> ): Relay controlled by OL1R.		
<i>1 - 0 -</i>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<i>L o 1 -</i>	<b>[LO1 CONFIGURATION]</b>		
<i>L o 1</i>	<b>[LO1 assignment]</b> Identical to <b>[R1 Assignment]</b> ( <i>r 1</i> ) page 138 with the addition of following parameter value (shown for information only as these selections can only be configured in the <b>[APPLICATION FUNCT.]</b> ( <i>F u n -</i> ) menu): <i>b L C</i> <b>[Brk control]</b> ( <i>b L C</i> ): Brake contactor control <i>L L C</i> <b>[Input cont.]</b> ( <i>L L C</i> ): Line contactor control <i>o C C</i> <b>[Output cont.]</b> ( <i>o C C</i> ): Output contactor control <i>E b o</i> <b>[End reel]</b> ( <i>E b o</i> ): End of reel(traverse control function) <i>t 5 y</i> <b>[Sync. wobble]</b> ( <i>t 5 y</i> ): "Counter wobble" synchronization <i>d C o</i> <b>[DC charging]</b> ( <i>d C o</i> ): DC bus precharging contactor control <i>o L 0 1</i> <b>[OL01]</b> ( <i>o L 0 1</i> ): Function blocks: Logical Output 01 ... <i>o L 1 0</i> <b>[OL10]</b> ( <i>o L 1 0</i> ): Function blocks: Logical Output 10 <i>G d L</i> <b>[GDL]</b> ( <i>G d L</i> ): GDL safety function		<b>[No]</b> ( <i>no</i> )
<i>L o 1 d</i>	<b>[LO1 delay time]</b> The delay cannot be set for the <b>[No drive flt]</b> ( <i>FLt</i> ), <b>[Brk control]</b> ( <i>b L C</i> ), <b>[Output cont.]</b> ( <i>o C C</i> ) and <b>[Input cont.]</b> ( <i>L L C</i> ) assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes true.	0 to 60,000 ms (1)	0 ms

Code	Name / Description	Adjustment range	Factory setting
<b>L o I S</b>  <b>P o S</b> <b>n E G</b>	<b>[LO1 active at]</b> Configuration of the operating logic: <b>[1] (P o S)</b> : State 1 when the information is true <b>[0] (n E G)</b> : State 0 when the information is true The configuration <b>[1] (P o S)</b> cannot be modified for the <b>[No drive flt] (F L E)</b> , <b>[Brk control] (b L C)</b> and <b>[Input cont.] (L L C)</b> assignments.		<b>[1] (P o S)</b>
<b>L o I H</b>	<b>[LO1 holding time]</b> The holding time cannot be set for the <b>[No drive flt] (F L E)</b> , <b>[Brk control] (b L C)</b> and <b>[Input cont.] (L L C)</b> assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes false.	0 to 9,999 ms	0

(1) 0 to 9,999 ms then 10.00 to 60.00 s on the integrated display terminal.

**Use of analog output AO1 as a logic output**

Analog output AO1 can be used as a logic output, by assigning DO1. In this case, when set to 0, this output corresponds to the AO1 min. value (0 V, or 0 mA for example), and when set to 1 to the AO1 max. value (10 V, or 20 mA for example).

The electrical characteristics of this analog output remain unchanged. As these characteristics are different from logic output characteristics, check that it is still compatible with the intended application.

Code	Name / Description	Adjustment range	Factory setting
<b>1 - 0 -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>d o 1 -</b>	<b>[DO1 CONFIGURATION]</b>		
<b>d o 1</b>	<b>[DO1 assignment]</b>		<b>[No] (n o)</b>
	Identical to <b>[R1 Assignment] (r 1)</b> page 138 with the addition of the following parameter values (shown for information only as these selections can only be configured in the <b>[APPLICATION FUNCT.] (F u n -)</b> menu):		
<b>b L C</b>	<b>[Brk control] (b L C)</b> : Brake contactor control		
<b>L L C</b>	<b>[Input cont.] (L L C)</b> : Line contactor control		
<b>o C C</b>	<b>[Output cont] (o C C)</b> : Output contactor control		
<b>E b o</b>	<b>[End reel] (E b o)</b> : End of reel(traverse control function)		
<b>t 5 y</b>	<b>[Sync. wobble] (t 5 y)</b> : "Counter wobble" synchronization		
<b>d C o</b>	<b>[DC charging] (d C o)</b> : DC bus precharging contactor control		
<b>o L 0 1</b>	<b>[OL01] (o L 0 1)</b> : Function blocks: Logical Output 01		
...	...		
<b>o L 1 0</b>	<b>[OL10] (o L 1 0)</b> : Function blocks: Logical Output 10		
<b>d o 1 d</b>	<b>[DO1 delay time]</b>	0 to 60,000 ms (1)	0 ms
	The delay cannot be set for the <b>[No drive flt] (F L t)</b> , <b>[Brk control] (b L C)</b> , <b>[Output cont.] (o C C)</b> and <b>[Input cont.] (L L C)</b> assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes true.		
<b>d o 1 5</b>	<b>[DO1 active at]</b>		<b>[1] (P o 5)</b>
	Configuration of the operating logic:		
<b>P o 5</b>	<b>[1] (P o 5)</b> : State 1 when the information is true		
<b>n E C</b>	<b>[0] (n E C)</b> : State 0 when the information is true		
	The configuration <b>[1] (P o 5)</b> cannot be modified for the <b>[No drive flt] (F L t)</b> , <b>[Brk control] (b L C)</b> and <b>[Input cont.] (L L C)</b> assignments.		
<b>d o 1 H</b>	<b>[DO1 holding time]</b>	0 to 9,999 ms	0 ms
	The holding time cannot be set for the <b>[No drive flt] (F L t)</b> , <b>[Brk control] (b L C)</b> and <b>[Input cont] (L L C)</b> assignments, and remains at 0. The change in state only takes effect once the configured time has elapsed, when the information becomes false.		

(1) 0 to 9,999 ms then 10.00 to 60.00 s on the integrated display terminal.



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > I\_O- > A1C-

**Configuration of analog output**

**Minimum and maximum values (output values):**

The minimum output value, in volts, corresponds to the lower limit of the assigned parameter and the maximum value corresponds to its upper limit. The minimum value may be greater than the maximum value.




## Scaling of the assigned parameter

The scale of the assigned parameter can be adapted in accordance with requirements by modifying the values of the lower and upper limits by means of two parameters for each analog output.

These parameters are given in %. 100% corresponds to the total variation range of the configured parameter, so:  $100\% = \text{upper limit} - \text{lower limit}$ . For example, **[Sign. torque] (5 L 9)** which varies between -3 and +3 times the rated torque, 100% corresponds to 6 times the rated torque.

- The **[Scaling AOx min] (R 5 L x)** parameter modifies the lower limit:  $\text{new value} = \text{lower limit} + (\text{range} \times \text{ASLx})$ . The value 0% (factory setting) does not modify the lower limit.
- The **[Scaling AOx max] (R 5 H x)** parameter modifies the upper limit:  $\text{new value} = \text{lower limit} + (\text{range} \times \text{ASHx})$ . The value 100% (factory setting) does not modify the upper limit.
- **[Scaling AOx min] (R 5 L x)** must always be lower than **[Scaling AOx max] (R 5 H x)**.



## Application example 2

The value of the motor current at the AO1 output is to be transferred with 0 - 20 mA, range 2 In motor, In motor being the equivalent of a 0.8 In drive.

The **[I motor] (a L r)** parameter varies between 0 and 2 times the rated drive current, or a range of 2.5 times the rated drive current.

**[Scaling AO1 min] (R 5 L I)** must not modify the lower limit, which therefore remains at its factory setting of 0%.

**[Scaling AO1 max] (R 5 H I)** must modify the upper limit by 0.5x the rated motor torque, or  $100 - 100/5 = 80\%$  (new value = lower limit + (range x ASH1)).

Code	Name / Description	Adjustment range	Factory setting
<b>I O -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>		
<b>R O I -</b>	<b>[AO1 CONFIGURATION]</b>		
<b>R O I</b>	<b>[AO1 assignment]</b>		<b>[No] (n o)</b>
<b>n o</b>	<b>[No] (n o):</b> Not assigned		
<b>o C r</b>	<b>[I motor] (o C r):</b> Current in the motor, between 0 and 2 In (In = rated drive current indicated in the Installation manual and on the drive nameplate)		
<b>o F r</b>	<b>[Motor freq.] (o F r):</b> Output frequency, from 0 to <b>[Max frequency] (E F r)</b>		
<b>o F 5</b>	<b>[Sig. o/p frq.] (o F 5):</b> Signed output frequency, between - <b>[Max frequency] (E F r)</b> and + <b>[Max frequency] (E F r)</b>		
<b>o r P</b>	<b>[Ramp out.] (o r P):</b> From 0 to <b>[Max frequency] (E F r)</b>		
<b>E r 9</b>	<b>[Motor torq.] (E r 9):</b> Motor torque, between 0 and 3 times the rated motor torque		
<b>5 E 9</b>	<b>[Sign. torque] (5 E 9):</b> Signed motor torque, between -3 and +3 times the rated motor torque. The + sign corresponds to the motor mode and the - sign to the generator mode (braking).		
<b>o r 5</b>	<b>[sign ramp] (o r 5):</b> Signed ramp output, between - <b>[Max frequency] (E F r)</b> and + <b>[Max frequency] (E F r)</b> .		
<b>o P 5</b>	<b>[PID ref.] (o P 5):</b> PID regulator reference between <b>[Min PID reference] (P , P 1)</b> and <b>[Max PID reference] (P , P 2)</b> .		
<b>o P F</b>	<b>[PID feedbk] (o P F):</b> PID regulator feedback between <b>[Min PID feedback] (P , F 1)</b> and <b>[Max PID feedback] (P , F 2)</b>		
<b>o P E</b>	<b>[PID error] (o P E):</b> PID regulator error between - 5 % and + 5 % of ( <b>[Max PID feedback] (P , F 2)</b> - <b>[Min PID feedback] (P , F 1)</b> )		
<b>o P i</b>	<b>[PID output] (o P i):</b> PID regulator output between <b>[Low speed] (L 5 P)</b> and <b>[High speed] (H 5 P)</b>		
<b>o P r</b>	<b>[Mot. power] (o P r):</b> Motor power, between 0 and 2.5 times <b>[Rated motor power] (n P r)</b>		
<b>u o P</b>	<b>[Motor volt.] (u o P):</b> Voltage applied to the motor, between 0 and <b>[Rated motor volt.] (u n 5)</b>		
<b>E H r</b>	<b>[Mot thermal] (E H r):</b> Motor thermal state, between 0 and 200% of the rated thermal state		
<b>E H r 2</b>	<b>[Mot therm2] (E H r 2):</b> Motor thermal state 2, between 0 and 200 % of the rated thermal state		
<b>E H r 3</b>	<b>[Mot therm3] (E H r 3):</b> Motor thermal state 3, between 0 and 200% of the rated thermal state		
<b>E H d</b>	<b>[Drv thermal] (E H d):</b> Drive thermal state, between 0 and 200% of the rated thermal state		
<b>E 9 L</b>	<b>[Torque lim.] (E 9 L):</b> Torque limit, between 0 and 3 times the rated motor torque		
<b>d o I</b>	<b>[dO1] (d o I):</b> Assignment to a logic output. This assignment can only appear if <b>[DO1 assignment] (d o I)</b> has been assigned. This is the only possible choice in this case, and is only displayed for informational purposes.		
<b>E 9 N 5</b>	<b>[Torque 4Q] (E 9 N 5):</b> Signed motor torque, between -3 and +3 times the rated motor torque. The + sign and the - sign correspond to the physical direction of the torque, regardless of mode (motor or generator).		
<b>o R O 1</b>	<b>[OA01] (o R O 1):</b> Function blocks: Analog Output 01		
...			
<b>o R 10</b>	<b>[OA10] (o R 10):</b> Function blocks: Analog Output 10		
<b>R O I E</b>	<b>[AO1 Type]</b>		<b>[Current] (O R)</b>
<b>I O u</b>	<b>[Voltage] ( I O u):</b> Voltage output		
<b>O R</b>	<b>[Current] (O R):</b> Current output		
<b>R O L I</b>	<b>[AO1 min Output]</b>	0 to 20.0 mA	0 mA
★	This parameter can be accessed if <b>[AO1 Type] (R O I E)</b> is set to <b>[Current] (O R)</b> .		
<b>R O H I</b>	<b>[AO1 max Output]</b>	0 to 20.0 mA	20.0 mA
★	This parameter can be accessed if <b>[AO1 Type] (R O I E)</b> is set to <b>[Current] (O R)</b> .		
<b>u o L I</b>	<b>[AO1 min Output]</b>	0 to 10.0 V	0 V
★	This parameter can be accessed if <b>[AO1 Type] (R O I E)</b> is set to <b>[Voltage] ( I O u)</b> .		
<b>u o H I</b>	<b>[AO1 max Output]</b>	0 to 10.0 V	10.0 V
★	This parameter can be accessed if <b>[AO1 Type] (R O I E)</b> is set to <b>[Voltage] ( I O u)</b> .		
<b>R S L I</b>	<b>[Scaling AO1 min]</b>	0 to 100.0%	0%
	Scaling of the lower limit of the assigned parameter, as a % of the maximum possible variation.		
<b>R S H I</b>	<b>[Scaling AO1 max]</b>	0 to 100.0%	100.0%
	Scaling of the upper limit of the assigned parameter, as a % of the maximum possible variation.		
<b>R o I F</b>	<b>[AO1 Filter]</b>	0 to 10.00 s	0 s
	Interference filtering. This parameter is forced to 0 if <b>[AO1 assignment] (R o I)</b> is set to <b>[dO1] (d o I)</b> .		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

The following submenus group the alarms into 1 to 3 groups, each of which can be assigned to a relay or a logic output for remote signaling. These groups can also be displayed on the graphic display terminal (see [\[3.3 MONITORING CONFIG.\] \(ΠCF -\)](#) menu page [284](#)) and viewed via the [\[1.2 MONITORING\] \(Πσπ -\)](#) menu page [47](#).

When one or a number of alarms selected in a group occurs, this alarm group is activated.

Code	Name / Description
<b>Ι - σ -</b>	<b>[INPUTS / OUTPUTS CFG] (continued)</b>
<b>A I C -</b>	<b>[ALARM GRP1 DEFINITION]</b>
	Selection to be made from the following list:
<i>PLA</i>	[LI6=PTC al.] ( <i>PLA</i> ): LI6 = PTCL alarm
<i>EFA</i>	[Ext. fault al.] ( <i>EFA</i> ): External fault alarm
<i>υSA</i>	[Under V. al.] ( <i>υSA</i> ): Undervoltage alarm
<i>CEA</i>	[I attained] ( <i>CEA</i> ): Current threshold attained ( <a href="#">[Current threshold] (CEd)</a> page <a href="#">102</a> )
<i>FtA</i>	[Freq.Th.att.] ( <i>FtA</i> ): Frequency threshold attained ( <a href="#">[Freq. threshold] (Ftd)</a> page <a href="#">102</a> )
<i>F2A</i>	[Freq. th.2 attained] ( <i>F2A</i> ): Frequency threshold 2 attained ( <a href="#">[Freq. threshold 2] (F2d)</a> page <a href="#">102</a> )
<i>SrA</i>	[Freq.ref.att.] ( <i>SrA</i> ): Frequency reference attained
<i>tSA</i>	[Th.mot. att.] ( <i>tSA</i> ): Motor 1 thermal state attained
<i>tS2</i>	[Th.mot2 att] ( <i>tS2</i> ): Motor 2 thermal state attained
<i>tS3</i>	[Th.mot3 att] ( <i>tS3</i> ): Motor 3 thermal state attained
<i>υPA</i>	[Uvolt warn] ( <i>υPA</i> ): Undervoltage threshold
<i>FLA</i>	[HSP attain.] ( <i>FLA</i> ): High speed attained
<i>tHA</i>	[Al. °C drv] ( <i>tHA</i> ): Drive overheating
<i>PEE</i>	[PID error al] ( <i>PEE</i> ): PID error alarm
<i>PFA</i>	[PID fdbk al.] ( <i>PFA</i> ): PID feedback alarm
<i>AP3</i>	[AI3 Al. 4-20] ( <i>AP3</i> ): Alarm indicating absence of 4-20 mA signal on input AI3
<i>SSA</i>	[Lim T/I att.] ( <i>SSA</i> ): Torque limit alarm
<i>tAd</i>	[Th. drv. att.] ( <i>tAd</i> ): Drive thermal state attained
<i>tJA</i>	[IGBT alarm] ( <i>tJA</i> ): IGBT alarm
<i>υLA</i>	[Underload. Proc. Al.] ( <i>υLA</i> ): Underload alarm
<i>σLA</i>	[Overload. Proc. Al.] ( <i>σLA</i> ): Overload alarm
<i>rSdA</i>	[Rope slack alarm] ( <i>rSdA</i> ): Rope slack (see <a href="#">[Rope slack config.] (rSd)</a> parameter page <a href="#">205</a> )
<i>t t HA</i>	[High torque alarm] ( <i>t t HA</i> ): Motor torque overshooting high threshold <a href="#">[High torque thd.] (t t H)</a> page <a href="#">102</a> .
<i>t t LA</i>	[Low torque alarm] ( <i>t t LA</i> ): Motor torque undershooting low threshold <a href="#">[Low torque thd.] (t t L)</a> page <a href="#">102</a> .
<i>F9LA</i>	[Freq. meter Alarm] ( <i>F9LA</i> ): Measured speed threshold attained: <a href="#">[Pulse warning thd.] (F9L)</a> page <a href="#">102</a> .
<i>dLdA</i>	[Dynamic load alarm] ( <i>dLdA</i> ): Load variation detection (see <a href="#">[DYNAMIC LOAD DETECT.] (dLd -)</a> page <a href="#">267</a> ).
	See the multiple selection procedure on page <a href="#">33</a> for the integrated display terminal, and page <a href="#">24</a> for the graphic display terminal.
<b>A 2 C -</b>	<b>[ALARM GRP2 DEFINITION]</b>
	Identical to <a href="#">[ALARM GRP1 DEFINITION] (A I C -)</a> page <a href="#">145</a> .
<b>A 3 C -</b>	<b>[ALARM GRP3 DEFINITION]</b>
	Identical to <a href="#">[ALARM GRP1 DEFINITION] (A I C -)</a> page <a href="#">145</a> .



## Command

The parameters in the **[COMMAND] (C E L -)** menu can only be modified when the drive is stopped and no run command is present.

## Command and reference channels

Run commands (forward, reverse, stop, etc.) and references can be sent using the following channels:

Command	Reference
Terminals: logic inputs LI or analog inputs used as logic inputs LA	Terminals: analog inputs AI, pulse input
Function blocks	Function blocks
Remote display terminal	Remote display terminal
Graphic display terminal	Graphic display terminal
Integrated Modbus	Integrated Modbus
Integrated CANopen®	Integrated CANopen®
Communication card	Communication card
	+/- speed via the terminals
	+/- speed via the graphic display terminal

## ⚠ WARNING

### UNANTICIPATED EQUIPMENT OPERATION

If analog inputs **[AI1] (A I 1)** or **[AI2] (A I 2)** are used as logic inputs (**[LA1] (L A 1)** or **[LA2] (L A 2)**), they remain active in their behaviors in analog input mode (example : **[Ref.1 channel] (F r 1)** is still set to **[AI1] (A I 1)**).

- Remove the configuration of **[AI1] (A I 1)** or **[AI2] (A I 2)** in analog input mode

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**Note:** **[LA1] (L A 1)** and **[LA2] (L A 2)** can be used as 2 logic inputs in source mode only.

- + 24 V power supply (max. 30 V)
- State 0 if < 7.5 V, state 1 if > 8.5 V.

**Note:** The stop keys on the graphic display terminal or remote display can be programmed as non-priority keys. A stop key can only have priority if the **[Stop Key priority] (P 5 E)** parameter in the **[COMMAND] (C E L -)** menu, page 154 is set to **[Yes] (Y E 5)**.

The behavior of the Altivar 320 can be adapted according to requirements:


- **[Not separ.] (5 , 1)**: Command and reference are sent via the same channel.
- **[Separate] (5 E P)**: Command and reference may be sent via different channels.

In these configurations, control via the communication bus is performed in accordance with the DRIVECOM standard with only 5 freely-assignable bits (see Communication Parameters Manual). The application functions cannot be accessed via the communication interface.

- **[I/O profile] ( , 0)**: The command and the reference can come from different channels. This configuration both simplifies and extends use via the communication interface. Commands may be sent via the logic inputs on the terminals or via the communication bus. When commands are sent via a bus, they are available on a word, which acts as virtual terminals containing only logic inputs. Application functions can be assigned to the bits in this word. More than one function can be assigned to the same bit.

**Note:** Stop commands from the graphic display terminal or remote display terminal remain active even if the terminals are not the active command channel.

Reference channel for [Not separ.] (5, n), [Separate] (SEP) and [I/O profile] (io) configurations, PID not configured



*Fr 1, SA2, SA3, dA2, dA3, nA2, nA3:*

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card

*Fr 1b*, for SEP and io:

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card

*Fr 1b*, for S, n:


- Terminals, only accessible if *Fr 1* = terminals

*Fr 2:*

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card, and +/- speed

**Note:** [Ref.1B channel] (*Fr 1b*) and [Ref 1B switching] (*rCb*) must be configured in the [APPLICATION FUNCT.] (*Fun-*) menu.

Reference channel for [Not separ.] (S, I, P), [Separate] (SEP) and [I/O profile] (IO) configurations, PID configured with PID references at the terminals



**Note:** Forced local is not active in [I/O profile].

(1) Ramps not active if the PID function is active in automatic mode.

**Fr 1:**

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card

**Fr 1b, for SEP and IO:**

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card

**Fr 1b, for S, I, P:**

- Terminals, only accessible if Fr 1 = terminals

**SA2, SA3, dA2, dA3:**

- Terminals only

**Fr 2:**

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card, **and +/- speed**


**Note:** [Ref.1B channel] (Fr 1b) and [Ref 1B switching] (rCb) must be configured in the [APPLICATION FUNCT.] (Fun-) menu.

**Command channel for [Not separ.] (5, 7) configuration**


Reference and command, not separate

The command channel is determined by the reference channel. Parameters  $F_{r1}$ ,  $F_{r2}$ ,  $rFC$ ,  $FLo$  and  $FLoC$  are common to reference and command.

Example: If the reference is  $F_{r1} = R, 1$  (analog input at the terminals), control is via  $L, 1$  (logic input at the terminals).



**Key:**




**Command channel for [Separate] (SEP) configuration**

Separate reference and command


Parameters *FL0* and *FL0C* are common to reference and command.

Example: If the reference is in forced local mode via *R1I* (analog input at the terminals), command in forced local mode is via *L1* (logic input at the terminals).

The command channels *Cd1* and *Cd2* are independent of the reference channels *Frl*, *Frlb* and *Fr2*.



**Key:**



Parameter:  
The black square represents the factory setting assignment, except for [Profile].


***Cd1, Cd2:***

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card


**Command channel for [I/O profile] ( , ) configuration**

Separate reference and command, as in [Separate] (SEP) configuration

The command channels *C d 1* and *C d 2* are independent of the reference channels *F r 1*, *F r 1 b* and *F r 2*.



**Key:**



***C d 1*, *C d 2*:**

- Terminals, graphic display terminal, integrated Modbus, integrated CANopen®, communication card

A command or an action can be assigned:

- To a fixed channel by selecting an *L ,* input or a Cxxx bit:
  - By selecting, for example, *L , 3*, this action will be triggered by *L , 3* regardless of which command channel is switched.
  - By selecting, for example, *C 2 14*, this action will be triggered by integrated CANopen® with bit 14 regardless of which command channel is switched.
- To a switchable channel by selecting a CDxx bit:
  - By selecting, for example, *C d 1 1*, this action will be triggered by:
    - L , 12* if the terminals channel is active
    - C 1 1 1* if the integrated Modbus channel is active
    - C 2 1 1* if the integrated CANopen® channel is active
    - C 3 1 1* if the communication card channel is active

If the active channel is the graphic display terminal, the functions and commands assigned to CDxx switchable internal bits are inactive.

**Note:** *C d 0 6* to *C d 1 3* can only be used for switching between 2 networks. They do not have equivalent logic inputs.

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; CTL-

Terminals	Integrated Modbus	Integrated CANopen®	Communication card	Internal bit, can be switched
				CD00
LI2 (1)	C101 (1)	C201 (1)	C301 (1)	CD01
LI3	C102	C202	C302	CD02
LI4	C103	C203	C303	CD03
LI5	C104	C204	C304	CD04
LI6	C105	C205	C305	CD05
-	C106	C206	C306	CD06
-	C107	C207	C307	CD07
-	C108	C208	C308	CD08
-	C109	C209	C309	CD09
-	C110	C210	C310	CD10
-	C111	C211	C311	CD11
-	C112	C212	C312	CD12
LAI1	C113	C213	C313	CD13
LAI2	C114	C214	C314	CD14
-	C115	C215	C315	CD15
OL01 to OL10				

(1) If [2/3 wire control] (E C C) page 85 is set to [3 wire] (3 C), L , 2, C 10 I, C 20 I and C 30 I cannot be accessed.

**Assignment conditions for logic inputs and control bits**

The following elements are available for every command or function that can be assigned to a logic input or a control bit:

[L11] (L 1 1) to [L16] (L 1 6)	Drive with or without option
[LAI1] (L A 1 1) to [LAI2] (L A 1 2)	Logical inputs
[C101] (C 1 0 1) to [C110] (C 1 1 0)	With integrated Modbus in [I/O profile] ( , ) configuration
[C111] (C 1 1 1) to [C115] (C 1 1 5)	With integrated Modbus regardless of configuration
[C201] (C 2 0 1) to [C210] (C 2 1 0)	With integrated CANopen® in [I/O profile] ( , ) configuration
[C211] (C 2 1 1) to [C215] (C 2 1 5)	With integrated CANopen® regardless of configuration
[C301] (C 3 0 1) to [C310] (C 3 1 0)	With a communication card in [I/O profile] ( , ) configuration
[C311] (C 3 1 1) to [C315] (C 3 1 5)	With a communication card regardless of configuration
[CD00] (C d 0 0) to [CD10] (C d 1 0)	In [I/O profile] ( , ) configuration
[CD11] (C d 1 1) to [CD15] (C d 1 5)	Regardless of configuration
[OL01] (o L 0 1) to [OL10] (o L 1 0)	Regardless of configuration

**Note:** In [I/O profile] ( , ) configuration, L 1 1 cannot be accessed and if [2/3 wire control] (L C C) page 85 is set to [3 wire] (3 C), L 1 2, C 1 0 1, C 2 0 1 and C 3 0 1 cannot be accessed either.

## WARNING

**LOSS OF CONTROL**

Inactive communication channels are not monitored (no error detection in the event of a communication interruption).



Verify that using the commands and functions assigned to bits C101 to C315 does not result in unsafe conditions in the event of a communication interruption.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > CTL-


Code	Name / Description	Adjustment range	Factory setting
<b>FULL</b>	<b>[FULL] (continued)</b>		
<b>CTL -</b>	<b>[COMMAND]</b>		
<b>Fr I</b>	<b>[Ref.1 channel]</b>		<b>[AI1] (R I I)</b>
<b>A I 1</b>	<b>[AI1] (R I I):</b> Analog input A1		
<b>A I 2</b>	<b>[AI2] (R I 2):</b> Analog input A2		
<b>A I 3</b>	<b>[AI3] (R I 3):</b> Analog input A3		
<b>L C C</b>	<b>[HMI] (L C C):</b> Graphic display terminal or remote display terminal source		
<b>Mod b</b>	<b>[Modbus] (Mod b):</b> Integrated Modbus		
<b>CAN</b>	<b>[CANopen] (CAN):</b> Integrated CANopen®		
<b>net</b>	<b>[Com. card] (net):</b> Communication card (if inserted)		
<b>P I</b>	<b>[RP] (P I):</b> Pulse input		
<b>A I virtual 1</b>	<b>[AI virtual 1] (A I virtual 1):</b> Virtual analog input 1 with the jog dial (only available if <b>[Profile] (C H C F)</b> is not set to <b>[Not separ.] (S , N)</b> )		
<b>OA 0 1</b>	<b>[OA01] (OA 0 1):</b> Function blocks: Analog Output 01		
...	...		
<b>OA 1 0</b>	<b>[OA10] (OA 1 0):</b> Function blocks: Analog Output 10		
<b>r i n</b>	<b>[RV Inhibition]</b>		<b>[No] (n o)</b>
	Inhibition of movement in reverse direction, does not apply to direction requests sent by logic inputs. Reverse direction requests sent by logic inputs are taken into account. Reverse direction requests sent by the graphic display terminal are not taken into account. Reverse direction requests sent by the fieldbus are not taken into account. Any reverse speed reference originating from the PID, summing input, etc., is interpreted as a zero reference (0 Hz).		
<b>n o</b>	<b>[No] (n o)</b>		
<b>Y E S</b>	<b>[Yes] (Y E S)</b>		
<b>P S t</b>	<b>[Stop Key priority]</b>		<b>[Yes] (Y E S)</b>
 2 s	<div style="border: 1px solid black; padding: 10px;"> <p style="font-size: 24px; font-weight: bold; margin: 0;">⚠ WARNING</p> <p style="font-weight: bold; margin: 5px 0 0 0;">LOSS OF CONTROL</p> <p>This function disables the Stop keys of the Remote Display Terminal if the setting of the parameter <b>[Command channel] (C N D C)</b> is not <b>[HMI] (H N I)</b>.</p> <p>Only set this parameter to <b>[No] (n o)</b> if you have implemented appropriate alternative stop functions.</p> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div> <p>This will be a freewheel stop. If the active command channel is the graphic display terminal, the stop will be performed according to the <b>[Type of stop] (S E t)</b> page <a href="#">173</a> irrespective of the configuration of <b>[Stop Key priority] (P S t)</b>.</p>		
<b>n o</b>	<b>[No] (n o)</b>		
<b>Y E S</b>	<b>[Yes] (Y E S):</b> Gives priority to the STOP key on the graphic display terminal when the graphic display terminal is not enabled as the command channel.		
<b>C H C F</b>	<b>[Profile]</b>		<b>[Not separ.] (S , N)</b>
 2 s	<div style="border: 1px solid black; padding: 10px;"> <p style="font-size: 24px; font-weight: bold; margin: 0;">⚠ WARNING</p> <p style="font-weight: bold; margin: 5px 0 0 0;">UNANTICIPATED EQUIPMENT OPERATION</p> <p>Disabling <b>[I/O profile] ( , o)</b> resets the drive to the factory settings.</p> <ul style="list-style-type: none"> <li>Verify that restoring the factory settings is compatible with the type of wiring used.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div>		
<b>S , N</b>	<b>[Not separ.] (S , N):</b> Reference and command, not separate		
<b>S E P</b>	<b>[Separate] (S E P):</b> Separate reference and command. This assignment cannot be accessed in <b>[I/O profile] ( , o)</b> .		
<b>, o</b>	<b>[I/O profile] ( , o):</b> I/O profile		

**Parameters described in this page can be accessed by:** DRI- > CONF > FULL > FBM- > MFB-

Code	Name / Description	Adjustment range	Factory setting
<b>C C 5</b>  ★  C d 1 C d 2 L , I ...	<b>[Cmd switching]</b>  This parameter can be accessed if [Profile] (C H C F) is set to [Separate] (S E P) or [I/O profile] ( , o). If the assigned input or bit is at 0, channel [Cmd channel 1] (C d 1) is active. If the assigned input or bit is at 1, channel [Cmd channel 2] (C d 2) is active.  [ch1 active] (C d 1): [Cmd channel 1] (C d 1) active (no switching) [ch2 active] (C d 2): [Cmd channel 2] (C d 2) active (no switching) [LI1] (L , I): Logical input LI1 [...]: See the assignment conditions on page 153 (not C d 0 0 to C d 1 5)		[ch1 active] (C d 1)
<b>C d 1</b>  ★  t E r L C C M d b C A n n E t	<b>[Cmd channel 1]</b>  This parameter can be accessed if [Profile] (C H C F) is set to [Separate] (S E P) or [I/O profile] ( , o).  [Terminals] (t E r): Terminals [HMI] (L C C): Graphic display terminal or remote display terminal [Modbus] (M d b): Integrated Modbus [CANopen] (C A n): Integrated CANopen® [Com. card] (n E t): Communication card (if inserted)		[Terminals] (t E r)
<b>C d 2</b>  ★  t E r L C C M d b C A n n E t	<b>[Cmd channel 2]</b>  This parameter can be accessed if [Profile] (C H C F) is set to [Separate] (S E P) or [I/O profile] ( , o).  [Terminals] (t E r): Terminals [HMI] (L C C): Graphic display terminal or remote display terminal [Modbus] (M d b): Integrated Modbus [CANopen] (C A n): Integrated CANopen® [Com. card] (n E t): Communication card (if inserted)		[Modbus] (M d b)
<b>r F C</b>    F r 1 F r 2 L , I ...	<b>[Ref. 2 switching]</b>  This parameter can be accessed if [Profile] (C H C F) is set to [Separate] (S E P) or [I/O profile] ( , o). If the assigned input or bit is at 0, channel [Cmd channel 1] (C d 1) is active. If the assigned input or bit is at 1, channel [Cmd channel 2] (C d 2) is active.  [Ref. 1 channel] (F r 1): [Cmd channel 1] (C d 1) active (no switching) [Ref. 2 channel] (F r 2): [Cmd channel 2] (C d 2) active (no switching) [LI1] (L , I): Logical input LI1 [...]: See the assignment conditions on page 153 (not C d 0 0 to C d 1 5)		[Ref.1 channel] (F r 1)
<b>F r 2</b>  n o  A I 1 A I 2 A I 3 u P d t L C C M d b C A n n E t P , A , u I O A 0 I ... o A 1 0	<b>[Ref.2 channel]</b>  [No] (n o): Not assigned. If [Profile] (C H C F) is set to [Not separ.] (S , N), the command is at the terminals with a zero reference. If [Profile] (C H C F) is set to [Separate] (S E P) or [I/O profile] ( , o), the reference is zero.  [AI1] (A I 1): Analog input A1 [AI2] (A I 2): Analog input A2 [AI3] (A I 3): Analog input A3 [+/-Speed] (u P d t): +/- speed command [HMI] (L C C): Graphic display terminal or remote display terminal [Modbus] (M d b): Integrated Modbus [CANopen] (C A n): Integrated CANopen® [Com. card] (n E t): Communication card (if inserted) [RP] (P ,): Pulse input [AI virtual 1] (A , u I): Virtual analog input 1 with the jog dial [OA01] (o A 0 I): Function blocks: Analog Output 01 [...] [OA10] (o A 1 0): Function blocks: Analog Output 10		[No] (n o)

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; FBM-

Code	Name / Description	Adjustment range	Factory setting
<i>C o P</i>	<b>[Copy channel 1 &lt;&gt; 2]</b>		<b>[No] (n o)</b>
 2 s	<div style="border: 1px solid black; padding: 10px;"> <p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>UNANTICIPATED EQUIPMENT OPERATION</b></p> <p>This parameter can cause unintended movements, for example, inversion of the direction of rotation of the motor, sudden acceleration or stops.</p> <ul style="list-style-type: none"> <li>• Verify that the setting of this parameter does not cause unintended movements.</li> <li>• Verify that the setting of this parameter does not result in unsafe conditions</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p> </div>		
	<p>Can be used to copy the current reference and/or the command by means of switching, in order to avoid speed surges, for example.</p> <p>If <b>[Profile] (C H C F)</b> page 154 is set to <b>[Not separ.] (S , N)</b> or <b>[Separate] (S E P)</b>, copying will only be possible from channel 1 to channel 2.</p> <p>If <b>[Profile] (C H C F)</b> is set to <b>[I/O profile] ( , o)</b>, copying will be possible in both directions.</p> <p>A reference or a command cannot be copied to a channel on the terminals.</p> <p>The reference copied is <b>[Frequency ref.] (F r H)</b> (before ramp) unless the destination channel reference is set via +/- speed. In this case, the reference copied is <b>[Output frequency] (r F r)</b> (after ramp).</p> <p><i>n o</i> <b>[No] (n o)</b>: No copy  <i>S P</i> <b>[Reference] (S P)</b>: Copy reference  <i>C d</i> <b>[Command] (C d)</b>: Copy command  <i>R L L</i> <b>[Cmd + ref.] (R L L)</b>: Copy command and reference</p>		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



To change the assignment of this parameter, press the ENT key for 2 s.

As the graphic display terminal may be selected as the command and/or reference channel, its action modes can be configured.

The parameters on this page can only be accessed on the graphic display terminal, and not on the integrated display terminal.

Comments:

- The display terminal command/reference is only active if the command and/or reference channels from the terminal are active with the exception of **[T/K] (F E)** (command via the display terminal), which takes priority over these channels. Press **[T/K] (F E)** (command via the display terminal) again to revert control to the selected channel.
- Command and reference via the display terminal are impossible if the latter is connected to more than one drive.
- The JOG, preset speed and +/- speed functions can only be accessed if **[Profile] (C H C F)** is set to **[Not separ.] (S , N)**.
- The preset PID reference functions can only be accessed if **[Profile] (C H C F)** is set to **[Not separ.] (S , N)** or **[Separate] (S E P)**.
- The **[T/K] (F E)** (command via the display terminal) can be accessed regardless of the **[Profile] (C H C F)**.

Code	Name / Description	Adjustment range	Factory setting
<b>F n 1</b>	<b>[F1 key assignment]</b>		<b>[No] (n o)</b>
<b>n o</b>	<b>[No] (n o):</b> Not assigned		
<b>F J o G</b>	<b>[Jog] (F J o G):</b> JOG operation		
<b>F P S 1</b>	<b>[Preset spd2] (F P S 1):</b> Press the key to run the drive at the 2nd preset speed <b>[Preset speed 2] (S P 2)</b> page 97. Press STOP to stop the drive.		
<b>F P S 2</b>	<b>[Preset spd3] (F P S 2):</b> Press the key to run the drive at the 3rd preset speed <b>[Preset speed 3] (S P 3)</b> page 97. Press STOP to stop the drive.		
<b>F P r 1</b>	<b>[PID ref. 2] (F P r 1):</b> Sets a PID reference equal to the 2nd preset PID reference <b>[Preset ref. PID 2] (r P 2)</b> page 99, without sending a run command. Only operates if <b>[Ref.1 channel] (F r 1)</b> is set to <b>[HMI] (L C C)</b> . Does not operate with the <b>[T/K] (F E)</b> function.		
<b>F P r 2</b>	<b>[PID ref. 3] (F P r 2):</b> Sets a PID reference equal to the 3rd preset PID reference <b>[Preset ref. PID 3] (r P 3)</b> page 100, without sending a run command. Only operates if <b>[Ref.1 channel] (F r 1)</b> is set to <b>[HMI] (L C C)</b> . Does not operate with the <b>[T/K] (F E)</b> function.		
<b>F u S P</b>	<b>[+speed] (F u S P):</b> Faster, only operates if <b>[Ref.2 channel] (F r 2)</b> is set to <b>[HMI] (L C C)</b> . Press the key to run the drive and increase the speed. Press STOP to stop the drive.		
<b>F d S P</b>	<b>[- speed] (F d S P):</b> Slower, only operates if <b>[Ref.2 channel] (F r 2)</b> is set to <b>[HMI] (L C C)</b> and if a different key has been assigned to <b>[+ speed]</b> . Press the key to run the drive and decrease the speed. Press STOP to stop the drive.		
<b>F E</b>	<b>[T/K] (F E):</b> Command via the display terminal: Takes priority over <b>[Cmd switching] (C C 5)</b> and over <b>[Ref. 2 switching] (r F C)</b> .		
<b>F n 2</b>	<b>[F2 key assignment]</b>		<b>[No] (n o)</b>
	Identical to <b>[F1 key assignment] (F n 1)</b> page 157.		
<b>F n 3</b>	<b>[F3 key assignment]</b>		<b>[No] (n o)</b>
	Identical to <b>[F1 key assignment] (F n 1)</b> page 157.		
<b>F n 4</b>	<b>[F4 key assignment]</b>		<b>[No] (n o)</b>
	Identical to <b>[F1 key assignment] (F n 1)</b> page 157.		
<b>b n P</b>	<b>[HMI cmd.]</b>		<b>[Stop] (S t o P)</b>
★	When the <b>[T/K] (F E)</b> function is assigned to a key and that function is active, this parameter defines the behavior at the moment when control returns to the graphic display terminal or remote display terminal.		
<b>S t o P</b>	<b>[Stop] (S t o P):</b> Stops the drive (although the controlled direction of operation and reference of the previous channel are copied (to be taken into account on the next RUN command)).		
<b>b u n P</b>	<b>[Bumpless] (b u n P):</b> Does not stop the drive (the controlled direction of operation and the reference of the previous channel are copied)		




★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Parameters described in this page can be accessed by:









DRI- &gt; CONF &gt; FULL &gt; FBM- &gt; FBP-

## Function Block Management

Code	Name / Description	Adjustment range	Factory setting
<b>FULL</b>	<b>[FULL] (continued)</b>		
<b>FbΠ-</b>	<b>[FUNCTION BLOCKS]</b>		
<b>ΠFb-</b>	<b>[MONIT. FUN. BLOCKS]</b> <b>Note:</b> This section shows only what is possible to do with local or remote display on the drive. For advanced configuration using PC software, please refer to the dedicated Function blocks manual.		
<b>FbSt</b>	<b>[FB Status]</b> <b>idle</b> [Idle] ( <b>idle</b> ): No binary file in the target, the FB is waiting for a download <b>CHEC</b> [Check prog.] ( <b>CHEC</b> ): Check the program downloaded <b>StoP</b> [Stop] ( <b>StoP</b> ): The Function blocks application is stopped <b>init</b> [Init] ( <b>init</b> ): Check coherency between ATVLogic program and Function blocks parameters <b>run</b> [Run] ( <b>run</b> ): The Function blocks application is running <b>Err</b> [Error] ( <b>Err</b> ): An internal error has been detected. The Function blocks application is in fault state mode.		
<b>FbFt</b>	<b>[FB Fault]</b> <b>no</b> [No] ( <b>no</b> ): No detected fault <b>int</b> [Internal] ( <b>int</b> ): Internal detected error <b>bin</b> [Binary file] ( <b>bin</b> ): Binary file corrupted <b>inP</b> [Intern Para.] ( <b>inP</b> ): Internal parameter detected error <b>PAR</b> [Para. RW] ( <b>PAR</b> ): Parameter access detected error <b>CAL</b> [Calculation] ( <b>CAL</b> ): Calculation detected error <b>toAU</b> [TO AUX] ( <b>toAU</b> ): TimeOut AUX task <b>toPP</b> [TO synch] ( <b>toPP</b> ): TimeOut in PRE/POST task <b>ADL</b> [Bad ADLC] ( <b>ADL</b> ): ADLC with bad parameter <b>in</b> [Input assig.] ( <b>in</b> ): Input not configured		
<b>FbI-</b>	<b>[FB IDENTIFICATION]</b>		
<b>buEr</b> ★	<b>[Program version]</b> Program user version.	0 to 255	-
<b>bnS</b> ★	<b>[Program size]</b> Program file size.	0 to 65,535	-
<b>bnv</b>	<b>[Prg. format version]</b> Binary format version of the drive.	0 to 255	-
<b>Ctu</b>	<b>[Catalog version]</b> Catalog version of the drive.	0 to 65,535	-
<b>FbΠ-</b>	<b>[FUNCTION BLOCKS] (continued)</b>		
<b>FbCd</b> ( )	<b>[FB Command]</b> Allows to start and stop the function blocks manually.  <b>[FB Command] (FbCd)</b> is forced to <b>[Stop] (StoP)</b> if there is no valid function blocks application in the drive memory. <b>[FB Command] (FbCd)</b> is set to <b>[Start] (StErT)</b> when the function blocks application switch to Run according to <b>[FB start mode] (FbrΠ)</b> configuration. <b>Note:</b> As soon as the function blocks are started, the drive is considered as in running state and the modification of configuration parameters is no longer possible.  <b>StoP</b> [Stop] ( <b>StoP</b> ): Function blocks application Stop command <b>StErT</b> [Start] ( <b>StErT</b> ): Function blocks application Start command		

Code	Name / Description	Adjustment range	Factory setting
<i>F b r Π</i>	<b>[FB start mode]</b>		<b>[No]</b> ( <i>n o</i> )
 2 s	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  <b>WARNING</b> </div> <div style="border: 1px solid black; padding: 5px;"> <b>UNANTICIPATED EQUIPMENT OPERATION</b>                      Depending on the setting of this parameter, function blocks may be immediately executed.                     <ul style="list-style-type: none"> <li>Verify that this setting does not result in unsafe conditions.</li> </ul> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b> </div>		
	Allows to choose the different ways of starting the Function blocks application. <b>Note:</b> Modifications of this parameter are not taken into account if the Function blocks application is running.		
<i>n o</i>	<b>[No]</b> ( <i>n o</i> ): Function blocks application is controlled by <b>[FB command]</b> ( <i>F b C d</i> ) parameter		
<i>Y E S</i>	<b>[Yes]</b> ( <i>Y E S</i> ): Function blocks application switches to Run automatically at drive power on		
<i>L I 1</i>	<b>[L1]</b> ( <i>L I 1</i> ): Function blocks application switches to Run on a rising edge of the logic input. It switch to Stop on falling edge of the logic input.		
...	[...] [...]: See the assignment conditions on page 153 (not <b>[OL10]</b> ( <i>o L 10</i> ) to <b>[OL10]</b> ( <i>o L 10</i> )).		
<i>F b S Π</i>	<b>[Stop FB Stop motor]</b>		<b>[Freewheel]</b> ( <i>Y E S</i> )
	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  <b>WARNING</b> </div> <div style="border: 1px solid black; padding: 5px;"> <b>LOSS OF CONTROL</b>                      If <b>[Stop FB stop motor]</b> (<i>F b S Π</i>) is set to <b>[No]</b> (<i>n o</i>), the motor will not stop when the program will be stopped.                     <ul style="list-style-type: none"> <li>Only set this parameter to <b>[No]</b> (<i>n o</i>) if you have implemented appropriate alternative stop functions.</li> </ul> <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b> </div>		
	Allows to setup the way of working of the drive when function blocks are stopped.		
<i>n o</i>	<b>[Ignore]</b> ( <i>n o</i> ): The drive does not stop		
<i>Y E S</i>	<b>[Freewheel]</b> ( <i>Y E S</i> ): Motor stops in freewheel		
<i>r Π P</i>	<b>[Ramp stop]</b> ( <i>r Π P</i> ): Ramp stop		
<i>F S t</i>	<b>[Fast stop]</b> ( <i>F S t</i> ): Fast stop		
<i>d C i</i>	<b>[DC injection]</b> ( <i>d C i</i> ): DC injection		
<i>F b d F</i>	<b>[FB on drive fault]</b>		<b>[Stop]</b> ( <i>S t o P</i> )
	Behavior of function blocks when the drive trips.		
<i>S t o P</i>	<b>[Stop]</b> ( <i>S t o P</i> ): Function blocks stops when the drive trips, outputs are released		
<i>i G n</i>	<b>[Ignore]</b> ( <i>i G n</i> ): Function blocks continue to work when the drive trips (except CFF and INFE)		
<b><i>F b A -</i></b>	<b>[INPUTS ASSIGNMENTS]</b>		
<i>i L 0 1</i>	<b>[Logic input 1 assignment]</b>		<b>[No]</b> ( <i>n o</i> )
	Possible assignment for the Function block logic input.		
<i>n o</i>	<b>[No]</b> ( <i>n o</i> ): Not assigned		
<i>F L t</i>	<b>[No drive fit]</b> ( <i>F L t</i> ): Drive fault detection status (relay normally energized, and de-energized in the event of an error)		
<i>F t A</i>	<b>[Freq. Th. attain.]</b> ( <i>F t A</i> ): Frequency threshold attained ( <b>[Freq. threshold]</b> ( <i>F t d</i> ) page 102)		
<i>F t A</i>	<b>[Freq. Th. 2 attained]</b> ( <i>F t A</i> ): Frequency threshold 2 attained ( <b>[Freq. threshold 2]</b> ( <i>F t d</i> ) page 102)		
<i>F r 1</i>	<b>[Ref.1 channel]</b> ( <i>F r 1</i> ) Reference source 1		
<i>F r 2</i>	<b>[Ref.2 channel]</b> ( <i>F r 2</i> ) Reference source 2		
<i>C d 1</i>	<b>[ch1 active]</b> ( <i>C d 1</i> ): Command channel = channel 1 (for <b>[Cmd switching]</b> ( <i>C S S</i> ))		
<i>C d 2</i>	<b>[ch2 active]</b> ( <i>C d 2</i> ): Command channel = channel 2 (for <b>[Cmd switching]</b> ( <i>C S S</i> ))		
<i>F r 1 b</i>	<b>[Ref.1B channel]</b> ( <i>F r 1 b</i> ): Reference channel = channel 1b (for <b>[Ref. 2 switching]</b> ( <i>r F C</i> ))		
<i>Y E S</i>	<b>[Yes]</b> ( <i>Y E S</i> ): Yes		
<i>L I 1</i>	<b>[L1]</b> ( <i>L I 1</i> ): Logical input L1		
...	[...] [...]: See the assignment conditions on page 153		
<i>i L - -</i>	<b>[Logic input x assignment]</b>		<b>[No]</b> ( <i>n o</i> )
	All the Function Blocks logic inputs available on the drive are processed as in the example for <b>[Logic input 1 assignment]</b> ( <i>i L 0 1</i> ) above, up to <b>[Logic input 10 assignment]</b> ( <i>i L 1 0</i> ).		


Code	Name / Description	Adjustment range	Factory setting
<b>IA01</b>	<b>[Analog input 1 assignment]</b> Possible assignment for the Function block analog input.		<b>[No] (no)</b>
no	[No] (no): Not assigned		
AI1	[AI1] (AI1): Analog input A1		
AI2	[AI2] (AI2): Analog input A2		
AI3	[AI3] (AI3): Analog input A3		
ICr	[I motor] (ICr): Motor current		
IFr	[Motor freq.] (IFr): Motor speed		
ORP	[Ramp. out] (ORP): Ramp output		
Trq	[Motor torq.] (Trq): Motor torque		
Stq	[Sign torque] (Stq): Signed motor torque		
OR5	[Sign ramp] (OR5): Signed ramp output		
OP5	[PID ref.] (OP5): PI(D) reference		
OPF	[PID feedbk] (OPF): PI(D) feedback		
OPe	[PID error] (OPe): PI(D) error		
OPi	[PID output] (OPi): PI(D) integral		
OPr	[Mot. power] (OPr): Motor power		
Thr	[Mot. thermal] (Thr): Motor thermal state		
Thd	[Drv thermal] (Thd): Drive thermal state		
TqNS	[Torque 4Q] (TqNS): Signed motor torque		
UPdt	[+/-Speed] (UPdt): Up/Down function is assigned by Lix		
UPdH	[+/-spd HMI] (UPdH): Up/Down function is assigned by graphic display terminal or remote display terminal		
LCC	[HMI] (LCC): Graphic display terminal or remote display terminal source		
Modb	[Modbus] (Modb): Integrated Modbus		
CAN	[CANopen] (CAN): Integrated CANopen®		
CEt	[Com. card] (CEt): Communication option board source		
OF5	[Sig. o/p freq.] (OF5): Signed output frequency		
Thr2	[Mot therm2] (Thr2): Motor 2 thermal state		
Thr3	[Mot therm3] (Thr3): Motor 3 thermal state		
TqL	[Torque lim.] (TqL): Torque limitation		
UP	[Motor volt.] (UP): Motor voltage		
Pi	[RP] (Pi): Pulse input		
AIv1	[AI virtual 1] (AIv1): Virtual analog input 1 with the jog dial		
DO1	[DO1] (DO1): Analog/logical output DO1		
AIv2	[AI virtual 2] (AIv2): Virtual analog input 2 by the communication bus		
OA01	[OA01] (OA01): Function blocks: Analog Output 01		
...	...		
OA10	[OA10] (OA10): Function blocks: Analog Output 10		
<b>IA--</b>	<b>[Analog input x assignment]</b> All the Function blocks analog inputs available on the drive are processed as in the example for [IA01] (IA01) above, up to [IA10] (IA10).		<b>[No] (no)</b>
<b>FbN-</b>	<b>[FUNCTION BLOCKS] (continued)</b>		
<b>FAd-</b>	<b>[ADL CONTAINERS]</b> ADL containers contain Modbus logical address of internal parameters of the drive. If the chosen address is valid, the display shows the parameter name instead of the address.		
<b>LA01</b>	ADL Container 01	3,015 to 64,299	0
<b>LA02</b>	ADL Container 02	3,015 to 64,299	0
<b>LA03</b>	ADL Container 03	3,015 to 64,299	0
<b>LA04</b>	ADL Container 04	3,015 to 64,299	0
<b>LA05</b>	ADL Container 05	3,015 to 64,299	0
<b>LA06</b>	ADL Container 06	3,015 to 64,299	0
<b>LA07</b>	ADL Container 07	3,015 to 64,299	0
<b>LA08</b>	ADL Container 08	3,015 to 64,299	0

Code	Name / Description	Adjustment range	Factory setting
<b>F b Π -</b>	<b>[FUNCTION BLOCKS] (continued)</b>		
<b>F b P -</b>	<b>[FB PARAMETERS]</b> Internal parameters available for the user program.		
<b>n0001</b> (1) 	<b>[ ]</b> M001 Parameter saved in EEPROM.	0 to 65,535	0
<b>n0002</b> (1) 	<b>[ ]</b> M002 Parameter saved in EEPROM	0 to 65,535	0
<b>n0003</b> (1) 	<b>[ ]</b> M003 Parameter saved in EEPROM	0 to 65,535	0
<b>n0004</b> (1) 	<b>[ ]</b> M004 Parameter saved in EEPROM	0 to 65,535	0
<b>n0005</b> (1) 	<b>[ ]</b> M005 Parameter written in RAM	0 to 65,535	0
<b>n0006</b> (1) 	<b>[ ]</b> M006 Parameter written in RAM	0 to 65,535	0
<b>n0007</b> (1) 	<b>[ ]</b> M007 Parameter written in RAM	0 to 65,535	0
<b>n0008</b> (1) 	<b>[ ]</b> M008 Parameter written in RAM	0 to 65,535	0

(1) If a graphic display terminal is not in use, values greater than 9,999 will be displayed on the 4-digit display with a period mark after the thousand digit, for example, 15.65 for 15,650.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.




To change the assignment of this parameter, press the ENT key for 2 s.



**[APPLICATION FUNCT.] (Funct.)**

Summary of functions:

Code	Name	Page
(REF-)	[REFERENCE SWITCH.]	<a href="#">167</a>
(REF-)	[REF. OPERATIONS]	<a href="#">168</a>
(RAMP-)	[RAMP]	<a href="#">170</a>
(STOP-)	[STOP CONFIGURATION]	<a href="#">173</a>
(ADDC-)	[AUTO DC INJECTION]	<a href="#">176</a>
(JOG-)	[JOG]	<a href="#">178</a>
(PSS-)	[PRESET SPEEDS]	<a href="#">181</a>
(UPD)	[+/- SPEED]	<a href="#">185</a>
(SRE-)	[+/-SPEED AROUND REF.]	<a href="#">187</a>
(SPN-)	[MEMO REFERENCE]	<a href="#">188</a>
(FLI-)	[FLUXING BY LI]	<a href="#">189</a>
(BLC-)	[BRAKE LOGIC CONTROL]	<a href="#">194</a>
(ELN-)	[EXTERNAL WEIGHT MEAS.]	<a href="#">200</a>
(HSH-)	[HIGH SPEED HOISTING]	<a href="#">205</a>
(PID-)	[PID REGULATOR]	<a href="#">210</a>
(PRI-)	[PID PRESET REFERENCES]	<a href="#">214</a>
(EOL-)	[TORQUE LIMITATION]	<a href="#">216</a>
(CLI-)	[2nd CURRENT LIMIT.]	<a href="#">218</a>
(I2E-)	[DYN CURRENT LIMIT]	<a href="#">219</a>
(LLC-)	[LINE CONTACTOR COMMAND]	<a href="#">221</a>
(OCC-)	[OUTPUT CONTACTOR CMD]	<a href="#">223</a>
(LPO-)	[POSITIONING BY SENSORS]	<a href="#">227</a>
(PLP-)	[PARAM. SET SWITCHING]	<a href="#">230</a>
(MPC-)	[MULTIMOTORS/CONFIG.]	<a href="#">235</a>
(ENL-)	[AUTO TUNING BY LI]	<a href="#">236</a>
(TRO-)	[TRAVERSE CONTROL]	<a href="#">237</a>
(CHS-)	[HSP SWITCHING]	<a href="#">244</a>
(DCC-)	[DC BUS]	<a href="#">245</a>

The parameters in the **[APPLICATION FUNCT.] (Funct.)** menu can only be modified when the drive is stopped and there is no run command, except for parameters with a  symbol in the code column, which can be modified with the drive running or stopped.

**Note:** Compatibility of functions

The choice of application functions may be limited by the number of I/O and by the fact that some functions are incompatible with others. Functions that are not listed in the table below are fully compatible.

If there is an incompatibility between functions, the first function configured will help to prevent the others being configured.

Each of the functions on the following pages can be assigned to one of the inputs or outputs.

 <b>WARNING</b>
--

<b>UNANTICIPATED EQUIPMENT OPERATION</b>
--

Multiple functions can be assigned to and simultaneously activated via a single input.
--

- |  |
|--|
| <ul style="list-style-type: none"><li>• Verify that assigning multiple functions to a single input does not result in unsafe conditions.</li></ul> |
|--|

<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>
---

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > REF-

It is only possible to assign one input to several functions at **[Advanced]** (*A d v*) and **[Expert]** (*E P r*) levels. Before assigning a command, reference or function to an input or output, the user must check that this input or output has not already been assigned and that another input or output has not been assigned to an incompatible function.

The drive factory setting or macro configurations automatically configure functions, **which may help to prevent other functions being assigned.**

**In some case, it is necessary to unconfigure one or more functions in order to be able to enable another.** Check the compatibility table below.

Stop functions have priority over run commands.

Speed references via logic command have priority over analog references.

**Note:** This compatibility table does not affect commands that can be assigned to the keys of the graphic display terminal (see page [24](#)).

**Compatibility table**

	Reference operations (page 168)	+/- speed (3) (page 185)	Preset speeds (page 180)	PID regulator (page 210)	Traverse control (page 242)	JOG operation (page 178)	Reference switching (page 167)	Skip frequency (page 183)	Brake logic control (page 194)	Auto DC injection (page 176)	Catch on the fly (page 253)	Output contactor command (page 223)	DC injection stop (page 173)	Fast stop (page 173)	Freewheel stop (page 173)	+/- speed around a reference (page 187)	High speed hoisting (page 205)	Load sharing (page 122)	Positioning by sensors (page 227)
Reference operations (page 168)			↑	● (2)		↑	↑	↑											
+/- speed (3) (page 185)					●	●	↑	↑											
Preset speeds (page 180)	←					↑	↑	↑											
PID regulator (page 210)	● (2)				●	●	↑	↑	●							●	●	●	●
Traverse control (page 242)		●		●		●	↑	↑								●	●		
JOG operation (page 178)	←	●	←	●	●			↑	●	←						●	●		
Reference switching (page 167)	←	←	←	←	←			↑								↑			
Skip frequency (page 183)	←	←	←	←	←	←	←									←			
Brake logic control (page 194)				●	●						●	●	●						
Auto DC injection (page 176)						↑							↑		↑				
Catch on the fly (page 253)									●										
Output contactor command (page 223)									●										
DC injection stop (page 173)									●	←				● (1)	↑				
Fast stop (page 173)													● (1)		↑				
Freewheel stop (page 173)										←			←	←					
+/- speed around a reference (page 187)				●	●	●	←	↑											
High speed hoisting (page 205)				●	●	●													
Load sharing (page 122)				●															
Positioning by sensors (page 227)				●															

(1) Priority is given to the first of these two stop modes to be activated.

(2) Only the multiplier reference is incompatible with the PID regulator.

● Incompatible functions      □ Compatible functions      ■ Not applicable

Priority functions (functions which cannot be active at the same time):

← ↑ The function indicated by the arrow has priority over the other.

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; FUN- &gt; OAI-

## Incompatible Functions

The following function will be inaccessible or deactivated after an Automatic restart.

This is only possible for control type if [2/3 wire control] (E C C) is set to [2 wire] (P C) and if [2 wire type] (E C E) is set to [Level] (L E L) or [Fwd priority] (P F O). See [2/3 wire control] (E C C) page 85.

The [1.2 MONITORING] (M o n -) menu page 47 can be used to display the functions assigned to each input in order to check their compatibility.

When a function is assigned, a ✓ appears on the graphic display terminal, as illustrated in the example below:

RDY	Term	0.0Hz	0A
APPLICATION FUNCT.			
REFERENCE SWITCH.			
REF. OPERATIONS			
RAMP			
STOP CONFIGURATION			
AUTO DC INJECTION			
Code	<<	>>	Quick

If you attempt to assign a function that is incompatible with another function that has already been assigned, an alarm message will appear:

- With the graphic display terminal:

RDY	Term	+0.0 Hz	0.0 A
INCOMPATIBILITY			
The function can't be assigned because an incompatible function is already selected. See programming book.			
ENT or ESC to continue			

- With the integrated display terminal and the remote display terminal:  
COMP flashes until ENT or ESC is pressed.

When you assign a logic input, an analog input, a reference channel or a bit to a function, pressing the HELP key will display the functions that may already have been activated by this input, bit or channel.

When a logic input, an analog input, a reference channel or a bit that has already been assigned is assigned to another function, the following screens appear:

- With the graphic display terminal:

RUN	Term	0.0 Hz	0.0 A
WARNING - ASSIGNED TO			
Forward			
ENT-Valid.		ESC-Abort	

If the access level permits this new assignment, pressing ENT confirms the assignment.

If the access level does not permit this new assignment, pressing ENT results in the following display:

RUN	Term	0.0 Hz	0.0 A
ASSIGNMENT FORBIDDEN			
Un-assign the present functions, or select "Advanced" access level			

- With the integrated display terminal:

The code for the first function, which is already assigned, is displayed flashing.

If the access level permits this new assignment, pressing ENT confirms the assignment.

If the access level does not permit this new assignment, pressing ENT has no effect, and the message continues to flash. It is only possible to exit by pressing ESC.

## REFERENCE SWITCHING


Code	Name / Description	Adjustment range	Factory setting
<i>F u n -</i>	<b>[APPLICATION FUNCT.]</b>		
<i>r E F -</i>	<b>[REFERENCE SWITCH.]</b>		
<i>r C b</i>	<b>[Ref 1B switching]</b>		<b>[ch1 active] (F r l)</b>
	<p>See the diagrams on pages <a href="#">147</a> and <a href="#">148</a>.</p> <p>If the assigned input or bit is at 0, <b>[Ref.1 channel] (F r l)</b> is active (see <b>[Ref.1 channel] (F r l)</b> page <a href="#">154</a>).</p> <p>If the assigned input or bit is at 1, <b>[Ref.1B channel] (F r l b)</b> is active.</p> <p><b>[Ref 1B switching] (r C b)</b> is forced to <b>[ch1 active] (F r l)</b> if <b>[Profile] (C H C F)</b> is set to <b>[Not separ.] (S , n)</b> with <b>[Ref.1 channel] (F r l)</b> assigned via the terminals (analog inputs, pulse input). See <b>[Ref.1 channel] (F r l)</b> page <a href="#">154</a>.</p>		
<i>F r l</i>	<b>[ch1 active] (F r l)</b> : No switching, <b>[Ref.1 channel] (F r l)</b> active		
<i>F r l b</i>	<b>[ch1B active] (F r l b)</b> : No switching, <b>[Ref.1B channel] (F r l b)</b> active		
<i>L i l</i>	<b>[LI1] (L i l)</b> : Logical input LI1		
...	<b>[...] (...)</b> : See the assignment conditions on page <a href="#">153</a> (not <b>[Cd00] (C d o o)</b> to <b>[Cd15] (C d 1 5)</b> ).		
<i>F r l b</i>	<b>[Ref.1B channel]</b>		<b>[No] (n o)</b>
<i>n o</i>	<b>[No] (n o)</b> : Not assigned		
<i>A 1 1</i>	<b>[AI1] (A 1 1)</b> : Analog input A1		
<i>A 1 2</i>	<b>[AI2] (A 1 2)</b> : Analog input A2		
<i>A 1 3</i>	<b>[AI3] (A 1 3)</b> : Analog input A3		
<i>L C C</i>	<b>[HMI] (L C C)</b> : Graphic display terminal or remote display terminal source		
<i>n d b</i>	<b>[Modbus] (n d b)</b> : Integrated Modbus		
<i>C A n</i>	<b>[CANopen] (C A n)</b> : Integrated CANopen®		
<i>n E t</i>	<b>[Com. card] (n E t)</b> : Communication option board source		
<i>P i</i>	<b>[RP] (P i)</b> : Pulse input		
<i>A i v 1</i>	<b>[AI virtual 1] (A i v 1)</b> : Virtual analog input 1 with the jog dial (only available if <b>[Profile] (C H C F)</b> is not set to <b>[Not separ.] (S , n)</b> )		
<i>o A 0 1</i>	<b>[OA01] (o A 0 1)</b> : Function blocks: Analog Output 01		
...	...		
<i>o A 1 0</i>	<b>[OA10] (o A 1 0)</b> : Function blocks: Analog Output 10		

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > FUN- > RPT-

## REFERENCE OPERATIONS

### Summing input / Subtracting input / Multiplier



$$A = (Fr1 \text{ or } Fr1b + SA2 + SA3 - dA2 - dA3) \times MA2 \times MA3$$

- If *SA2*, *SA3*, *dA2*, *dA3* are not assigned, they are set to 0.
- If *MA2*, *MA3* are not assigned, they are set to 1.
- A is limited by the minimum *LSP* and maximum *HSP* parameters.
- For multiplication, the signal on *MA2* or *MA3* is interpreted as a %. 100% corresponds to the maximum value of the corresponding input. If *MA2* or *MA3* is sent via the communication bus or graphic display terminal, an *PFr* multiplication variable, page 284 must be sent via the bus or graphic display terminal.
- Reversal of the direction of operation in the event of a negative result can be inhibited (see [\[RV Inhibition\]](#) (*SVn*) page 154).

Code	Name / Description	Adjustment range	Factory setting
<i>F u n -</i>	<b>[APPLICATION FUNCT.] (continued)</b>		
<i>o A i -</i>	<b>[REF. OPERATIONS]</b> Reference = (Fr1 or Fr1b + SA2 + SA3 - dA2 - dA3) x MA2 x MA3. See the diagrams on pages 147 and 148. <b>Note:</b> This function cannot be used with certain other functions. Follow the instructions on page 163.		
<i>S A 2</i>	<b>[Summing ref. 2]</b> Selection of a reference to be added to <a href="#">[Ref.1 channel]</a> ( <i>Fr I</i> ) or <a href="#">[Ref.1B channel]</a> ( <i>Fr Ib</i> ).		<b>[No]</b> ( <i>no</i> )
<i>no</i>	<b>[No]</b> ( <i>no</i> ): Not assigned		
<i>A I 1</i>	<b>[AI1]</b> ( <i>A I 1</i> ): Analog input A1		
<i>A I 2</i>	<b>[AI2]</b> ( <i>A I 2</i> ): Analog input A2		
<i>A I 3</i>	<b>[AI3]</b> ( <i>A I 3</i> ): Analog input A3		
<i>L C C</i>	<b>[HMI]</b> ( <i>L C C</i> ): Graphic display terminal or remote display terminal source		
<i>M o d b u s</i>	<b>[Modbus]</b> ( <i>M o d b u s</i> ): Integrated Modbus		
<i>C A N</i>	<b>[CANopen]</b> ( <i>C A N</i> ): Integrated CANopen®		
<i>n E E</i>	<b>[Com. card]</b> ( <i>n E E</i> ): Communication option board source		
<i>P v</i>	<b>[RP]</b> ( <i>P v</i> ): Motor voltage		
<i>A i v 1</i>	<b>[AI virtual 1]</b> ( <i>A i v 1</i> ): Virtual analog input 1 with the jog dial		
<i>A i v 2</i>	<b>[AI virtual 2]</b> ( <i>A i v 2</i> ): Virtual analog input 2 by the communication bus		
<i>o A O 1</i>	<b>[OA01]</b> ( <i>o A O 1</i> ): Function blocks: Analog Output 01		
...	...		
<i>o A O 10</i>	<b>[OA10]</b> ( <i>o A O 10</i> ): Function blocks: Analog Output 10		
<i>S A 3</i>	<b>[Summing ref. 3]</b> Selection of a reference to be added to <a href="#">[Ref.1 channel]</a> ( <i>Fr I</i> ) or <a href="#">[Ref.1B channel]</a> ( <i>Fr Ib</i> ). Identical to <a href="#">[Summing ref. 2]</a> ( <i>S A 2</i> ) page 168.		<b>[No]</b> ( <i>no</i> )
<i>d A 2</i>	<b>[Subtract. ref. 2]</b> Selection of a reference to be subtracted from <a href="#">[Ref.1 channel]</a> ( <i>Fr I</i> ) or <a href="#">[Ref.1B channel]</a> ( <i>Fr Ib</i> ). Identical to <a href="#">[Summing ref. 2]</a> ( <i>S A 2</i> ) page 168.		<b>[No]</b> ( <i>no</i> )

Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; FUN- &gt; RPT-




Code	Name / Description	Adjustment range	Factory setting
SR3	<b>[Subtract. ref. 3]</b> Selection of a reference to be subtracted from <b>[Ref.1 channel]</b> (Fr I) or <b>[Ref.1B channel]</b> (Fr Ib). Identical to <b>[Summing ref. 2]</b> (SR2) page 168.		[No] (no)
MR2	<b>[Multiplier ref. 2]</b> Selection of a multiplier reference <b>[Ref.1 channel]</b> (Fr I) or <b>[Ref.1B channel]</b> (Fr Ib). Identical to <b>[Summing ref. 2]</b> (SR2) page 168.		[No] (no)
MR3	<b>[Multiplier ref. 3]</b> Selection of a multiplier reference <b>[Ref.1 channel]</b> (Fr I) or <b>[Ref.1B channel]</b> (Fr Ib). Identical to <b>[Summing ref. 2]</b> (SR2) page 168.		[No] (no)



Parameters described in this page can be accessed by:

DRI- > CONF > FULL > FUN- > STT-

**RAMP**

Code	Name / Description	Adjustment range	Factory setting
<b>F u n -</b>	<b>[APPLICATION FUNCT.] (continued)</b>		
<b>r P t -</b>	<b>[RAMP]</b>		
<b>r P t</b>	<b>[Ramp type]</b>		<b>[Linear] (L i n)</b>
<b>L i n</b>	<b>[Linear] (L i n)</b>		
<b>S</b>	<b>[S ramp] (S)</b>		
<b>u</b>	<b>[U ramp] (u)</b>		
<b>C u s</b>	<b>[Customized] (C u s)</b>		
<b>(C)</b>	<p>S ramps</p>  <p>The rounding coefficient is fixed,  t1 = 0.6 set ramp time (linear)  t2 = 0.4 set ramp time (round)  t3 = 1.4 set ramp time</p> <p>U ramps</p>  <p>The rounding coefficient is fixed,  t1 = 0.5 set ramp time (linear)  t2 = 1.0 set ramp time (round)  t3 = 1.5 set ramp time</p> <p>Customized ramps</p>  <p>tA1: adjustable from 0 to 100%  tA2: adjustable from 0 to (100% - tA1)  tA3: adjustable from 0 to 100%  tA4: adjustable from 0 to (100% - tA3)</p> <p>t12 = ACC * (tA1(%) / 100 + tA2(%) / 100 + 1)  t34 = DEC * (tA3(%) / 100 + tA4(%) / 100 + 1)</p>		
<b>i n c</b>	<b>[Ramp increment]</b>		<b>[0,1] (0.1)</b>
<b>(C)</b>	This parameter is valid for <b>[Acceleration] (A C C)</b> , <b>[Deceleration] (d E C)</b> , <b>[Acceleration 2] (A C 2)</b> and <b>[Deceleration 2] (d E 2)</b> .		
<b>(1)</b>			
<b>0.01</b>	<b>[0,01]:</b> Ramp up to 99.99 seconds		
<b>0.1</b>	<b>[0,1]:</b> Ramp up to 999.9 seconds		
<b>1</b>	<b>[1]:</b> Ramp up to 6,000 seconds		
<b>A C C</b>	<b>[Acceleration]</b>	0.00 to 6,000 s (2)	3.0 s
<b>(C)</b>	Time to accelerate from 0 to the <b>[Rated motor freq.] (F r 5)</b> (page 86). To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application.		
<b>(1)</b>			
<b>d E C</b>	<b>[Deceleration]</b>	0.00 to 6,000 s (2)	3.0 s
<b>(C)</b>	Time to decelerate from the <b>[Rated motor freq.] (F r 5)</b> (page 86) to 0. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application.		
<b>(1)</b>			
<b>t A 1</b>	<b>[Begin Acc round]</b>	0 to 100%	10%
<b>(C)</b>	Rounding of start of acceleration ramp as a % of the <b>[Acceleration] (A C C)</b> or <b>[Acceleration 2] (A C 2)</b> ramp time. Can be set between 0 and 100%. This parameter can be accessed if the <b>[Ramp type] (r P t)</b> is <b>[Customized] (C u s)</b> .		
<b>(1)</b>			

Parameters described in this page can be accessed by: DRI- > CONF > FULL > FUN- > STT-

Code	Name / Description	Adjustment range	Factory setting															
<p><b>EA2</b></p> <p>★</p> <p>( )</p> <p>(1)</p>	<p><b>[End Acc round]</b></p> <p>Rounding of end of acceleration ramp as a % of the <b>[Acceleration]</b> (AE1) or <b>[Acceleration 2]</b> (AE2) ramp time. Can be set between 0 and (100% - <b>[Begin Acc round]</b> (EA1)). This parameter can be accessed if the <b>[Ramp type]</b> (RPE) is <b>[Customized]</b> (CU5).</p>	0 to 100%	10%															
<p><b>EA3</b></p> <p>★</p> <p>( )</p> <p>(1)</p>	<p><b>[Begin Dec round]</b></p> <p>Rounding of start of deceleration ramp as a % of the <b>[Deceleration]</b> (dE1) or <b>[Deceleration 2]</b> (dE2) ramp time. Can be set between 0 and 100%. This parameter can be accessed if the <b>[Ramp type]</b> (RPE) is <b>[Customized]</b> (CU5).</p>	0 to 100%	10%															
<p><b>EA4</b></p> <p>★</p> <p>( )</p> <p>(1)</p>	<p><b>[End Dec round]</b></p> <p>Rounding of end of deceleration ramp as a % of the <b>[Deceleration]</b> (dE1) or <b>[Deceleration 2]</b> (dE2) ramp time. Can be set between 0 and (100% - <b>[Begin Dec round]</b> (EA3)). This parameter can be accessed if the <b>[Ramp type]</b> (RPE) is <b>[Customized]</b> (CU5).</p>	0 to 100%	10%															
<p><b>FRt</b></p>	<p><b>[Ramp 2 threshold]</b></p> <p>Ramp switching threshold The 2nd ramp is switched if the value of <b>[Ramp 2 threshold]</b> (FRt) is not 0 (0 deactivates the function) and the output frequency is greater than <b>[Ramp 2 threshold]</b> (FRt). Threshold ramp switching can be combined with <b>[Ramp switch ass.]</b> (RPS) switching as follows:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>LI or bit</th> <th>Frequency</th> <th>Ramp</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>&lt; Frt</td> <td>ACC, dEC</td> </tr> <tr> <td>0</td> <td>&gt; Frt</td> <td>AC2, dE2</td> </tr> <tr> <td>1</td> <td>&lt; Frt</td> <td>AC2, dE2</td> </tr> <tr> <td>1</td> <td>&gt; Frt</td> <td>AC2, dE2</td> </tr> </tbody> </table>	LI or bit	Frequency	Ramp	0	< Frt	ACC, dEC	0	> Frt	AC2, dE2	1	< Frt	AC2, dE2	1	> Frt	AC2, dE2	0 to 599 Hz according to rating	0 Hz
LI or bit	Frequency	Ramp																
0	< Frt	ACC, dEC																
0	> Frt	AC2, dE2																
1	< Frt	AC2, dE2																
1	> Frt	AC2, dE2																
<p><b>RPS</b></p>	<p><b>[Ramp switch ass.]</b></p> <p>Identical to <b>[Ref.1B channel]</b> (FR1b) page 167.</p>		<b>[No]</b> (na)															
<p><b>AE2</b></p> <p>★</p> <p>( )</p> <p>(1)</p>	<p><b>[Acceleration 2]</b></p> <p>Time to accelerate from 0 to the <b>[Rated motor freq.]</b> (FR5). To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. This parameter can be accessed if <b>[Ramp 2 threshold]</b> (FRt) is greater than 0 or if <b>[Ramp switch ass.]</b> (RPS) is assigned.</p>	0.00 to 6,000 s (2)	5.0 s															
<p><b>dE2</b></p> <p>★</p> <p>( )</p> <p>(1)</p>	<p><b>[Deceleration 2]</b></p> <p>Time to decelerate from <b>[Rated motor freq.]</b> (FR5) to 0. To have repeatability in ramps, the value of this parameter must be set according to the possibility of the application. This parameter can be accessed if <b>[Ramp 2 threshold]</b> (FRt) is greater than 0 or if <b>[Ramp switch ass.]</b> (RPS) is assigned.</p>	0.00 to 6,000 s (2)	5.0 s															


Parameters described in this page can be accessed by:

DRI- &gt; CONF &gt; FULL &gt; FUN- &gt; STT-

Code	Name / Description	Adjustment range	Factory setting
<i>brA</i>	<b>[Dec ramp adapt.]</b>		<b>[Yes] (YES)</b>
<b>NOTICE</b>			
<b>DAMAGE TO THE MOTOR</b>			
<ul style="list-style-type: none"> <li>Only set this parameter to <b>[Yes] (YES)</b> or <b>[No] (NO)</b> if the connected motor is a permanent magnet synchronous motor.</li> </ul> Other settings demagnetize permanent magnet synchronous motors. <b>Failure to follow these instructions can result in equipment damage.</b>			
Activating this function automatically adapts the deceleration ramp, if this has been set at a too low value according to the inertia of the load, which can cause an overvoltage detected fault. <b>[Dec ramp adapt.] (brA)</b> is forced to <b>[No] (NO)</b> if the brake logic control <b>[Brake assignment] (BLC)</b> is assigned (page 194). The function is incompatible with applications requiring: <ul style="list-style-type: none"> <li>- Positioning on a ramp.</li> <li>- The use of a braking resistor (the resistor would not operate correctly).</li> </ul>			
<i>no</i>	<b>[No] (NO)</b> : Function inactive		
<i>YES</i>	<b>[Yes] (YES)</b> : Function active, for applications that do not require strong deceleration		
The following selections appear depending on the rating of the drive and <b>[Motor control type] (LTL)</b> page 105. They enable stronger deceleration to be obtained than with <b>[Yes] (YES)</b> . Use comparative testing to determine your selection.			
<i>dYnA</i>	<b>[High torq. A] (dYnA)</b> : Addition of a constant current flow component.		
When <b>[Dec ramp adapt.] (brA)</b> is configured on <b>[High torq. x] (dYnX)</b> , the dynamic performances for braking are improved by the addition of a current flow component. The aim is to increase the iron loss and magnetic energy stored in the motor.			

(1) The parameter can also be accessed in the **[SETTINGS] (SEt-)** menu.(2) Range 0.01 to 99.99 s or 0.1 to 999.9 s or 1 to 6,000 s according to **[Ramp increment] (irr)** page 170.

These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.






Parameter that can be modified during operation or when stopped.

## STOP CONFIGURATION

Code	Name / Description	Adjustment range	Factory setting
<i>F u n -</i>	<b>[APPLICATION FUNCT.] (continued)</b>		
<i>S t t -</i>	<b>[STOP CONFIGURATION]</b> <b>Note:</b> Some types of stops cannot be used with all other functions. Follow the instructions on page <a href="#">163</a> .		
<i>S t t</i>	<b>[Type of stop]</b> Stop mode on disappearance of the run command or appearance of a stop command. <b>Note:</b> If the "brake logic" function on page <a href="#">194</a> has been enabled, or if <b>[Low speed time out]</b> ( <i>ℓ ℓ 5</i> ) page <a href="#">95</a> or <a href="#">213</a> is not 0, only ramp type stops may be configured.		<b>[Ramp stop]</b> ( <i>r Π P</i> )
<i>r Π P</i> <i>F 5 ℓ</i> <i>n 5 ℓ</i> <i>d ℓ i</i>	<b>[Ramp stop]</b> ( <i>r Π P</i> ): Stop on ramp <b>[Fast stop]</b> ( <i>F 5 ℓ</i> ): Fast stop <b>[Freewheel]</b> ( <i>n 5 ℓ</i> ): Freewheel stop <b>[DC injection]</b> ( <i>d ℓ i</i> ): DC injection stop. Available only if <b>[Motor control type]</b> ( <i>ℓ ℓ ℓ</i> ) page <a href="#">105</a> is not set to <b>[Sync. mot.]</b> ( <i>5 4 n</i> ).		
<i>F F ℓ</i> ★ ⌚ (1)	<b>[Freewheel stop Thd.]</b> Speed threshold below which the motor will switch to freewheel stop. This parameter supports switching from a ramp stop or a fast stop to a freewheel stop below a low speed threshold. This parameter can be accessed if <b>[Type of stop]</b> ( <i>S t t</i> ) is set to <b>[Fast stop]</b> ( <i>F 5 ℓ</i> ) or <b>[Ramp stop]</b> ( <i>r Π P</i> ) and if <b>[Brake assignment]</b> ( <i>b ℓ ℓ</i> ) or <b>[Auto DC injection]</b> ( <i>ℓ d ℓ</i> ) are configured.	0.2 to 599 Hz	0.2 Hz
<i>n 5 ℓ</i>	<b>[Freewheel stop ass.]</b> The stop is activated when the input or the bit changes to 0. If the input returns to state 1 and the run command is still active, the motor will only restart if <b>[2/3 wire control]</b> ( <i>ℓ ℓ ℓ</i> ) page <a href="#">85</a> is set to <b>[2 wire]</b> ( <i>ℓ ℓ</i> ) and if <b>[2 wire type]</b> ( <i>ℓ ℓ ℓ</i> ) is set to <b>[Level]</b> ( <i>ℓ ℓ ℓ</i> ) or <b>[Fwd priority]</b> ( <i>ℓ ℓ ℓ</i> ). If not, a new run command must be sent.		<b>[No]</b> ( <i>n o</i> )
<i>n o</i> <i>ℓ i i</i> ...	<b>[No]</b> ( <i>n o</i> ): Not assigned <b>[LI1]</b> ( <i>ℓ i i</i> ): Logical input LI1 <b>[...]</b> (...): See the assignment conditions on page <a href="#">153</a>		
<i>F 5 ℓ</i>	<b>[Fast stop assign.]</b> The stop is activated when the input changes to 0 or the bit changes to 1 (bit in <b>[I/O profile]</b> ( <i>i o</i> ) at 0). If the input returns to state 1 and the run command is still active, the motor will only restart if <b>[2/3 wire control]</b> ( <i>ℓ ℓ ℓ</i> ) page <a href="#">85</a> is set to <b>[2 wire]</b> ( <i>ℓ ℓ</i> ) and if <b>[2 wire type]</b> ( <i>ℓ ℓ ℓ</i> ) is set to <b>[Level]</b> ( <i>ℓ ℓ ℓ</i> ) or <b>[Fwd priority]</b> ( <i>ℓ ℓ ℓ</i> ). If not, a new run command must be sent. <b>Note:</b> This function cannot be used with certain other functions. Follow the instructions on page <a href="#">163</a> .		<b>[No]</b> ( <i>n o</i> )
<i>n o</i> <i>ℓ i i</i> ...	<b>[No]</b> ( <i>n o</i> ): Not assigned <b>[LI1]</b> ( <i>ℓ i i</i> ): Logical input LI1 <b>[...]</b> (...): See the assignment conditions on page <a href="#">153</a>		
<i>d ℓ F</i> ★ ⌚ (1)	<b>[Ramp divider]</b> This parameter can be accessed if <b>[Type of stop]</b> ( <i>S t t</i> ) is set to <b>[Fast stop]</b> ( <i>F 5 ℓ</i> ) and if <b>[Fast stop assign.]</b> ( <i>F 5 ℓ</i> ) is not <b>[No]</b> ( <i>n o</i> ) and if <b>[Stop type]</b> ( <i>ℓ ℓ ℓ</i> ) is set to <b>[Fast stop]</b> ( <i>F 5 ℓ</i> ). The ramp that is enabled ( <b>[Deceleration]</b> ( <i>d ℓ ℓ</i> ) or <b>[Deceleration 2]</b> ( <i>d ℓ ℓ</i> )) is then divided by this coefficient when stop requests are sent. Value 0 corresponds to a minimum ramp time.	0 to 10	4

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > FUN- > ADC-


Code	Name / Description	Adjustment range	Factory setting
<a href="#">d C i</a>	<a href="#">[DC injection assign.]</a>		<a href="#">[No] (n o)</a>
 <b>WARNING</b>			
<p><b>UNINTENDED MOVEMENT</b></p> <ul style="list-style-type: none"> <li>Do not use DC injection to generate holding torque when the motor is at a standstill.</li> <li>Use a holding brake to keep the motor in the standstill position.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>			
<p>DC injection braking is initiated when the assigned input or bit changes to state 1.                      If the input returns to state 0 and the run command is still active, the motor will only restart if <a href="#">[2/3 wire control] (L C C)</a> page 85 is set to <a href="#">[2 wire] (P C)</a> and if <a href="#">[2 wire type] (L C L)</a> is set to <a href="#">[Level] (L E L)</a> or <a href="#">[Fwd priority] (P F o)</a>. If not, a new run command must be sent.  <b>Note:</b> This function cannot be used with certain other functions. Follow the instructions on page 163.</p>			
<a href="#">n o</a> <a href="#">L i l</a> ...	<p><a href="#">[No] (n o)</a>: Not assigned  <a href="#">[LI1] (L i l)</a>: Logical input LI1  <a href="#">[...] (...)</a>: See the assignment conditions on page 153</p>		
<a href="#">i d C</a>	<a href="#">[DC inject. level 1]</a>	0.1 to 1.41 In (2)	0.64 In (2)
 <b>NOTICE</b>			
<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <p>Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>			
<p>Level of DC injection braking current activated via logic input or selected as stop mode.                      This parameter can be accessed if <a href="#">[Type of stop] (S E E)</a> is set to <a href="#">[DC injection] (d C i)</a> or if <a href="#">[DC injection assign.] (d C i)</a> is not <a href="#">[No] (n o)</a>.</p>			
<a href="#">L d i</a>	<a href="#">[DC injection time 1]</a>	0.1 to 30 s	0.5 s
 <b>NOTICE</b>			
<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b></p> <p>Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>			
<p>Maximum current injection time <a href="#">[DC inject. level 1] (i d C)</a>. After this time, the injection current becomes <a href="#">[DC inject. level 2] (i d C 2)</a>.                      This parameter can be accessed if <a href="#">[Type of stop] (S E E)</a> is set to <a href="#">[DC injection] (d C i)</a> or if <a href="#">[DC injection assign.] (d C i)</a> is not set to <a href="#">[No] (n o)</a>.</p>			

Code	Name / Description	Adjustment range	Factory setting
<span style="color: green;">, d C 2</span>  <span style="color: blue;">★</span> <span style="border: 1px solid black; border-radius: 50%; padding: 2px;">↻</span> (1) (3)	<span style="color: blue;">[DC inject. level 2]</span>	0.1 In (2) to <span style="color: blue;">[DC inject. level 1]</span> <span style="color: green;">( , d C )</span>	0.5 In (2)
	<b>NOTICE</b> <b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b>		
Injection current activated by logic input or selected as stop mode, once period of time <span style="color: blue;">[DC injection time 1]</span> <span style="color: green;">( t d i )</span> has elapsed. This parameter can be accessed if <span style="color: blue;">[Type of stop]</span> <span style="color: green;">( 5 t t )</span> is set to <span style="color: blue;">[DC injection]</span> <span style="color: green;">( d C i )</span> or if <span style="color: blue;">[DC injection assign.]</span> <span style="color: green;">( d C i )</span> is not set to <span style="color: blue;">[No]</span> <span style="color: green;">( n o )</span> .			
<span style="color: green;">t d C</span>  <span style="color: blue;">★</span> <span style="border: 1px solid black; border-radius: 50%; padding: 2px;">↻</span> (1) (3)	<span style="color: blue;">[DC injection time 2]</span>	0.1 to 30 s	0.5 s
	<b>NOTICE</b> <b>OVERHEATING AND DAMAGE TO THE MOTOR</b> Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor. <b>Failure to follow these instructions can result in equipment damage.</b>		
Maximum injection time <span style="color: blue;">[DC inject. level 2]</span> <span style="color: green;">( , d C 2 )</span> for injection, selected as stop mode only. This parameter can be accessed if <span style="color: blue;">[Stop type]</span> <span style="color: green;">( 5 t t )</span> is set to <span style="color: blue;">[DC injection]</span> <span style="color: green;">( d C i )</span> .			
<span style="color: green;">d o t d</span>  <span style="color: green;">n 5 t</span> <span style="color: green;">r n P</span>	<span style="color: blue;">[Dis. operat opt code]</span> Disable operation stop mode.	<span style="color: green;">[Ramp stop]</span> <span style="color: green;">( r n P )</span>	
	<span style="color: green;">[Freewheel]</span> <span style="color: green;">( n 5 t )</span> : Disable drive function <span style="color: green;">[Ramp stop]</span> <span style="color: green;">( r n P )</span> : Ramp stop then disable drive function		

- (1) The parameter can also be accessed in the [SETTINGS] ( 5 E t - ) menu.
- (2) In corresponds to the rated drive current indicated in the Installation manual and on the drive nameplate.
- (3) These settings are independent of the [AUTO DC INJECTION] ( R d C - ) function.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.











Parameter that can be modified during operation or when stopped.

Parameters described in this page can be accessed by:

DRI- > CONF > FULL > FUN- > JOG-

## AUTO DC INJECTION

Code	Name / Description	Adjustment range	Factory setting
<i>F u n -</i>	<b>[APPLICATION FUNCT.] (continued)</b>		
<i>R d C -</i>	<b>[AUTO DC INJECTION]</b>		
<i>R d C</i>	<b>[Auto DC injection]</b>		<b>[Yes] (4E5)</b>
   2 s	 <b>DANGER</b>		
	<p><b>HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH</b>            If the parameter <b>[Auto DC injection] (RdC)</b> is set to <b>[Continuous] (CE)</b>, DC injection is always active, even if the motor does not run.</p> <ul style="list-style-type: none"> <li>Verify that using this setting does not result in unsafe conditions.</li> </ul> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p>		
 <b>WARNING</b>			
<p><b>UNINTENDED MOVEMENT</b></p> <ul style="list-style-type: none"> <li>Do not use DC injection to generate holding torque when the motor is at a standstill.</li> <li>Use a holding brake to keep the motor in the standstill position.</li> </ul> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>			
<p>Automatic current injection on stopping (at the end of the ramp).  <b>Note:</b> There is an interlock between this function and <b>[Motor fluxing] (FLU)</b> page 95. If <b>[Motor fluxing] (FLU)</b> is set to <b>[Continuous] (FCE)</b>, <b>[Auto DC injection] (RdC)</b> must be <b>[No] (no)</b>.  <b>Note:</b> <b>[Auto DC injection] (RdC)</b> is set to <b>[No] (no)</b> when <b>[Motor control type] (CLE)</b> page 105 is set to <b>[Sync. mot.] (SYN)</b>.  <b>[Auto DC injection] (RdC)</b> is forced to <b>[No] (no)</b> when <b>[Brake assignment] (BLE)</b> page 194 is not set to <b>[No] (no)</b>.            This parameter gives rise to the injection of current even if a run command has not been sent. It can be accessed with the drive running.</p>			
<i>no</i>	<b>[No] (no):</b> No injection		
<i>4E5</i>	<b>[Yes] (4E5):</b> Adjustable injection time		
<i>CE</i>	<b>[Continuous] (CE):</b> Continuous standstill injection		
<i>S d C 1</i>	<b>[Auto DC inj. level 1]</b>	0 to 1.2 In (2)	0.7 In (2)
  (1)	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b>            Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.  <b>Failure to follow these instructions can result in equipment damage.</b></p>		
<p>Level of standstill DC injection current <b>[Auto DC injection] (RdC)</b> is not <b>[No] (no)</b>.</p>			
<i>t d C 1</i>	<b>[Auto DC inj. time 1]</b>	0.1 to 30 s	0.5 s
  (1)	<b>NOTICE</b>		
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b>            Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.  <b>Failure to follow these instructions can result in equipment damage.</b></p>		
<p>Standstill injection time. This parameter can be accessed if <b>[Auto DC injection] (RdC)</b> is not set to <b>[No] (no)</b>.            If <b>[Motor control type] (CLE)</b> page 105 is set to <b>[Sync. mot.] (SYN)</b>, this time corresponds to the zero speed maintenance time.</p>			


Code	Name / Description	Adjustment range	Factory setting																		
5 d C 2	[Auto DC inj. level 2]	0 to 1.2 In (2)	0.5 In (2)																		
★ (1)	<b>NOTICE</b>																				
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b>                      Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.  <b>Failure to follow these instructions can result in equipment damage.</b></p>																				
2nd level of standstill DC injection current. This parameter can be accessed if [Auto DC injection] (A d C) is not [No] (n o).																					
6 d C 2	[Auto DC inj. time 2]	0 to 30 s	0 s																		
★ (1)	<b>NOTICE</b>																				
	<p><b>OVERHEATING AND DAMAGE TO THE MOTOR</b>                      Verify that the connected motor is properly rated for the DC injection current to be applied in terms of amount and time in order to avoid overheating and damage to the motor.  <b>Failure to follow these instructions can result in equipment damage.</b></p>																				
2nd standstill injection time. This parameter can be accessed if [Auto DC injection] (A d C) is set to [Yes] (Y E S).																					
	<table border="1"> <thead> <tr> <th>AdC</th> <th>SdC2</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>YES</td> <td>x</td> <td></td> </tr> <tr> <td>Ct</td> <td>≠ 0</td> <td></td> </tr> <tr> <td>Ct</td> <td>= 0</td> <td></td> </tr> <tr> <td colspan="2">Run command</td> <td></td> </tr> <tr> <td colspan="2">Speed</td> <td></td> </tr> </tbody> </table>	AdC	SdC2	Operation	YES	x		Ct	≠ 0		Ct	= 0		Run command			Speed				
AdC	SdC2	Operation																			
YES	x																				
Ct	≠ 0																				
Ct	= 0																				
Run command																					
Speed																					

(1) The parameter can also be accessed in the [SETTINGS] (5 E E -) menu.

(2) In corresponds to the rated drive current indicated in the Installation manual and on the drive nameplate.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.



Parameter that can be modified during operation or when stopped.



To change the assignment of this parameter, press the ENT key for 2 s.



Parameters described in this page can be accessed by:






DRI- > CONF > FULL > FUN- > PSS-


## JOG


Code	Name / Description	Adjustment range	Factory setting
<b>F u n -</b>	<b>[APPLICATION FUNCT.] (continued)</b>		
<b>J o g -</b>	<b>[JOG]</b> <b>Note:</b> This function cannot be used with certain other functions. Follow the instructions on page 163.		
<b>J o g</b>	<p><b>[JOG]</b></p> <p>Pulse operation. The JOG function is only active if the command channel and the reference channels are on the terminals. The function is active when the assigned input or bit is at 1. Example: 2-wire control operation (tCC = 2C).</p> <p>The diagram shows the relationship between several signals during JOG operation. The top signal is Motor frequency, which ramps up (labeled 'Ramp DEC/DE2') and then ramps down (labeled 'Ramp forced to 0.1 s'). Below it is the Reference signal, which follows the motor frequency. The JOG reference signal is shown as a pulse that triggers the JOG operation. The LI (JOG) signal is a digital input that goes high when the JOG function is active. The Forward and Reverse signals are digital outputs that indicate the direction of the motor. The JOG pulse is shown as a narrow pulse that occurs during the forward ramp.</p>	[LI3] (L, 3)	
<b>n o</b> <b>L I 1</b> <b>...</b>	<p><b>[No] (n o):</b> Not assigned <b>[LI1] (L I 1):</b> Logical input LI1 <b>[...] (...):</b> See the assignment conditions on page 153 (not <b>[Cd00]</b> (C d 0 0) to <b>[Cd15]</b> (C d 1 5))</p>		
<b>J G F</b> ★ ⌚ (1)	<p><b>[Jog frequency]</b></p> <p>Reference in jog operation. This parameter can be accessed if <b>[JOG] (J o g)</b> is not set to <b>[No] (n o)</b>.</p>	0 to 10 Hz	10 Hz


Parameters described in this page can be accessed by:


DRI- > CONF > FULL > FUN- > PSS-

Code	Name / Description	Adjustment range	Factory setting
   (1)	<b>[Jog delay]</b> Anti-repeat delay between 2 consecutive jog operations. This parameter can be accessed if <b>[JOG]</b> (  ) is not set to <b>[No]</b> (  ).	0 to 2.0 s	0.5 s

(1) The parameter can also be accessed in the **[SETTINGS]** () menu.

 These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and adjusted from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

 Parameter that can be modified during operation or when stopped.

 2 s To change the assignment of this parameter, press the ENT key for 2 s.